
Bobcat®

Service Manual

S150, S160 Skid-Steer Loader

S/N 529711001 & Above
S/N 529811001 & Above
S/N A8M011001 - A8M059999
S/N 529911001 - 529959999
S/N 530011001 - 530059999
S/N AC3011001 - AC3059999
S/N AC3211001 - AC3259999



EQUIPPED WITH BOBCAT INTERLOCK CONTROL SYSTEM (BICS)

6904126 (5-08)

Printed in U.S.A.

© Bobcat Company 2008

MidWestTech | Bobcat S150, S160 Skid Steer Loader Service Manual | Publication 690412... Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

ACCESS PANEL (INSIDE) 50-01
ACCESS PANEL (INSIDE) (SJC) 50-01
AIR CLEANER 70-01
AIR CLEANER SERVICE 10-01
AIR CONDITIONING SYSTEM FLOW 80-01
ALTERNATOR 60-01

BACK-UP ALARM SYSTEM 60-01
BATTERY 60-01
BLOWER FAN 80-01
BOBCAT CONTROLLER (ACS) 60-01
BOBCAT CONTROLLER (MAIN) 60-01
BOBCAT CONTROLLER (SJC) (DRIVE) 60-01
BOBCAT INTERLOCK CONTROL SYSTEM (BICS) 60-01
BOB-TACH (HAND LEVER) 10-01, 50-01
BOB-TACH (POWER) 10-01
BOB-TACH ([POWER-OPTION) 50-01
BOB-TACH (POWER) BLOCK 20-01
BRAKE (SINGLE SPEED) 40-01
BRAKE (TWO-SPEED) 40-01
BUCKET POSITION VALVE 20-01

CALIBRATION 60-01
CAMSHAFT AND TIMING GEARS 70-01
CASE DRAIN FILTER 30-01
CHAINCASE 40-01
CHARGE PRESSURE 30-01
COMPRESSOR 80-01
CONDENSER 80-01
CONTROL HANDLE/LEVER 50-01
CONTROL HANDLE/LEVER (ACS) 50-01
CONTROL HANDLE/LEVER (SJC) 50-01
CONTROL PANEL 50-01
CONTROL PANEL (SJC) 50-01
CONTROL PANEL SETUP 60-01
CONTROL PEDALS AND LINKAGE 50-01
CONTROL PEDALS (ACS) 50-01
CONTROL SYSTEM (ACS) 60-01
CONVERSIONS SPEC-01
CRANKSHAFT AND PISTONS 70-01
CYLINDER (BOB-TACH) 20-01
CYLINDER (LIFT) 20-01
CYLINDER (TILT) 20-01
CYLINDER HEAD 70-01

DIAGNOSTICS SERVICE CODES 60-01
DRIVE BELT 30-01
DRIVE COMPONENTS 40-01

ELECTRICAL/HYD. CONTROLS 60-01
ELECTRICAL/HYD. CONTROLS REFERENCE (SJC) 60-01
ELECTRICAL SYSTEM INFORMATION 60-01
ENGINE COOLING SYSTEM 10-01
ENGINE LUBRICATION SYSTEM 10-01
ENGINE COOLING SYSTEM 70-01
ENGINE INFORMATION 70-01
ENGINE SPEED CONTROL 70-01
ENGINE SPEED CONTROL (SJC) 70-01
EVAPORATOR 80-01
EVAPORATOR/HEATER UNIT 80-01
EXPANSION VALVE 80-01

FINAL DRIVE TRANSMISSION (CHAINCASE) 10-01
FLYWHEEL AND HOUSING 70-01
FLYWHEEL RPM SENSOR 60-01
FRONT AUXILIARY HYDRAULIC COUPLER BLOCK 20-01
FUEL SYSTEM 10-01, 70-01
FUEL TANK 50-01

HEATER COIL 80-01
HEATER VALVE 80-01
HIGH FLOW VALVE 20-01
HYDRAULIC CONNECTION SPECS SPEC-01
HYDRAULIC CONTROL VALVE (ACS) OR (SJC) 20-01
HYDRAULIC CONTROL VALVE (STANDARD) 20-01
HYDRAULIC/HYDROSTATIC FILTERS 20-01
HYDRAULIC FLUID RESERVOIR 20-01
HYDRAULIC/HYDROSTATIC FLUID SPECIFICATIONS SPEC-01
HYDRAULIC/HYDROSTATIC SYSTEM 10-01
HYDRAULIC PUMP (STANDARD) 20-01
HYDRAULIC PUMP (STANDARD) (HIGH FLOW) 20-01
HYDRAULIC PUMP (SJC) 20-01
HYDRAULIC PUMP (SJC) (HIGH FLOW) 20-01
HYDRAULIC SYSTEM INFORMATION 20-01
HYDROSTATIC MOTOR 30-01
HYDROSTATIC MOTOR (TWO SPEED) 30-01
HYDROSTATIC MOTOR CARRIER (SINGLE ANDTWO-SPEED WITH MANUAL CONTROLS) 30-01
HYDROSTATIC MOTOR CARRIER (SINGLE ANDTWO-SPEED WITH SJC CONTROLS) 30-01
HYDROSTATIC PUMP 30-01
HYDROSTATIC PUMP (SJC) 30-01
HYDROSTATIC SYSTEM INFORMATION 30-01

INSTRUMENT PANELS 60-01

MidWestTech | Bobcat S150, S160 Skid Steer Loader Service Manual | Publication 690412... Order the manual at mid-west-tech.com >

LIFT ARMS 50-01
LIFT ARM BYPASS CONTROL VALVE 20-01
LIFT ARM SUPPORT DEVICE 10-01
LIFTING AND BLOCKING THE LOADER 10-01
LIGHTS 60-01
S150 LOADER SPECIFICATIONS SPEC-01
S160 LOADER SPECIFICATIONS SPEC-01
LOADER STORAGE AND RETURN TO SERVICE 10-01
LUBRICATING THE LOADER 10-01
LUBRICATION SYSTEM 70-01

MAIN RELIEF VALVE 20-01
MAINTENANCE CLOCK 60-01
MUFFLER 70-01
OIL COOLER 20-01
OPERATOR CAB 10-01, 50-01
OPERATOR SEAT 50-01
OPERATOR SEAT (SUSPENSION) 50-01

PASSWORD SETUP (IF EQUIPPED WITH KEYLESS START) 60-01
PIVOT PINS 10-01

REAR AUXILIARY DIVERTER VALVE 20-01
REAR DOOR 50-01
REAR GRILL 50-01
RECEIVER/DRIER 80-01
REGULAR MAINTENANCE 80-01
REMOTE START TOOL KIT-MEL1563 10-01
REMOTE START TOOL (SERVICE TOOL) KIT - 6689779 10-01

SEAT BAR 50-01
SEAT BAR SENSOR 60-01
SERVICE PC (LAPTOP COMPUTER) 60-01
SERVICE SCHEDULE 10-01
SPARK ARRESTOR MUFFLER 10-01
STARTER 60-01
STEERING DRIFT COMPENSATION 60-01
STOPPING THE ENGINE AND LEAVING THE LOADER 10-01
SYSTEM CHARGING AND RECLAMATION 80-01

THERMOSTAT 80-01
TORQUE SPECIFICATIONS FOR BOLTS SPEC-01
TOWING THE LOADER 10-01
TRACK CARRIAGE COMPONENTS 40-01
TRACTION LOCK 60-01
TRANSPORTING THE LOADER ON A TRAILER ..10-01
TROUBLESHOOTING 80-01
TURBOCHARGER 70-01
TWO-SPEED VALVE 30-01

WHEEL SPEED SENSOR (SJC) 60-01
WINDOW (FRONT DOOR) 50-01
WINDOW (REAR) 50-01
WINDOW (SIDE) 50-01
WINDOW (TOP) 50-01

MidWestTech | Bobcat S150, S160 Skid Steer Loader Service Manual | Publication 690412... Order the manual at mid-west-tech.com >

CONTENTS

FOREWORD II

SAFETY INSTRUCTIONS V

FIRE PREVENTION VII

SERIAL NUMBER LOCATIONS IX

DELIVERY REPORT X

BOBCAT LOADER IDENTIFICATION XI

SAFETY AND MAINTENANCE 10-01

HYDRAULIC SYSTEM 20-01

HYDROSTATIC SYSTEM 30-01

DRIVE SYSTEM 40-01

MAIN FRAME 50-01

ELECTRICAL SYSTEM & ANALYSIS 60-01

ENGINE SERVICE 70-01

HEATING, VENTILATION, AIR CONDITIONING 80-01


SPECIFICATIONS SPEC-01

MidWestTech | Bobcat S150, S160 Skid Steer Loader Service Manual | Publication 690412...

Order the manual at mid-west-tech.com >

Handle Lock Solenoid Removal And Installation


Figure 60-130-24



Disconnect the harness connector (Item 1) **[Figure 60-130-24]** from the handle sensor connector.

Disconnect the harness connector (Item 2) **[Figure 60-130-24]** from the handle lock solenoid connector.

Figure 60-130-25




Remove the two screws (Item 1) **[Figure 60-130-25]** holding the handle lock solenoid to the handle.

Installation: Tighten the screws to 32-38 in.-lb. (3.6-4.3 N•m) torque.

Remove handle lock solenoid assembly from handle.

Handle Lock Solenoid Disassembly And Assembly


Figure 60-130-26



Remove solenoid (Item 1) from the solenoid mount (Item 2) **[Figure 60-130-26]**.

Installation: Apply a drop of oil to the solenoid threads and tighten solenoid to 35-40 ft.-lb. (47-54 N•m) lubed torque.

Figure 60-130-27



Check the O-ring (Item 1) **[Figure 60-130-27]** for damage. Replace as necessary.

MidWestTech | Bobcat S150, S160 Skid Steer Loader Service Manual | Publication 690412... Order the manual at mid-west-tech.com >

Specifications (Kubota V2003-M-DI-T (Turbo) (Cont'd)

All dimensions are given in inches. Respective metric dimensions are given in millimeters enclosed by parentheses.

Crankshaft

Crankshaft Alignment Limit Permitted	0.00079 (0,02)
Oil Clearance Between Journal & Bearing #1	0.0016-0.0046 (0,04-0,118)
Limit Permitted	0.0079 (0,2)
Journal O.D. #1	2.3591-2.3598 (59,921-59,940)
Bearing I.D. #1	2.3614-2.3637 (59,98-60,039)
Oil Clearance Between Journal & Bearing #2	0.0016-0.0041 (0,04-0,104)
Limit Permitted	0.0079 (0,2)
Journal O.D. #2	2.3591-2.3598 (59,921-59,940)
Bearing I.D. #2	2.3614-2.3632 (59,98-60,025)
Oil Clearance Between Crank Pin & Bearing	0.0010-0.0034 (0,025-0,087)
Limit Permitted	0.0079 (0,2)
Crank Pin O.D.	1.8488-1.8494 (46,96-46,97)
Crank Pin Bearing I.D.	1.8504-1.8522 (47,0-47,046)
Crankshaft Side Clearance	0.0059-0.0138 (0,15-0,35)
Limit Permitted	0.0197 (0,5)

Timing Gear


Timing Gear Backlash:	
Crank Gear-Idle Gear	0.0016-0.0044 (0,0415-0,1122)
Allowable Limit	0.0059 (0,15)
Idle Gear-Cam Gear	0.0016-0.0045 (0,0415-0,1154)
Allowable Limit	0.0059 (0,15)
Idle Gear-Injection Pump Gear	0.0016-0.0045 (0,0415-0,1154)
Allowable Limit	0.0059 (0,15)
Crank Gear-Oil Pump Gear	0.0016-0.0043 (0,0415-0,109)
Allowable Limit	0.0059 (0,15)
Clearance Between Idle Gear Shaft & Idle Gear Bushing:	
Idle Gear	0.001-0.0026 (0,025-0,066)
Allowable Limit	0.0039 (0,10)
Idle Gear Bushing I.D.	1.4961-1.4970 (38,0-38,025)
Allowable Limit	0.0039 (0,10)
Idle Gear Shaft O.D.	1.4944-1.4951 (37,959-37,975)
Idle Gear Side Clearance Idle Gear	0.0079-0.020 (0,2-0,51)
Allowable Limit	0.0315 (0,8)

Thermostat

Valve Opening Temperature	176.9-182.3°F (80.5-83.5°C)
Valve Fully Open	203°F (95°C)

MidWestTech | Bobcat S150, S160 Skid Steer Loader Service Manual | Publication 690412... Order the manual at mid-west-tech.com >

Troubleshooting Tree (Cont'd)




B-21492

MidWestTech | Bobcat S150, S160 Skid Steer Loader Service Manual | Publication 690412... Order the manual at mid-west-tech.com >

WIRING SCHEMATIC
(MAINFRAME)
S150 (S/N 529712668 - 529713732)
(S/N 529911972 - 529912502)
S160 (S/N 529811322 - 529811712)
(S/N 530011367 - 530011803)

(PRINTED MAY 2007)

7123793



Order the manual at mid-west-tech.com >