
Bobcat®

Service Manual
T250 Compact Track Loader

S/N A5GS11001 - A5GS19999
S/N A5GT11001 - A5GT19999



EQUIPPED WITH BOBCAT INTERLOCK CONTROL SYSTEM (BICS)

6986682 (5-08)

Printed in U.S.A.

© Bobcat Company 2008

MidWestTech | Bobcat T250 Compact Track Skid Loader Service Manual | Publication 698... Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

ACCESS PANEL (INSIDE) 50-01
ACCESS PANEL (INSIDE) (SJC) 50-01
AIR CLEANER 70-01
AIR CLEANER SERVICE 10-01
AIR CONDITIONING SYSTEM FLOW 80-01
ALTERNATOR 60-01

BACK-UP ALARM SYSTEM 60-01
BATTERY 60-01
BOBCAT CONTROLLER (ACS) 60-01
BOBCAT CONTROLLER (MAIN) 60-01
BOBCAT CONTROLLER (SJC) (DRIVE) 60-01
BOBCAT INTERLOCK CONTROL SYSTEM (BICS) 60-01
BLOWER FAN 80-01
BOB-TACH (HAND LEVER) 10-01, 50-01
BOB-TACH (POWER - OPTION) 10-01, 50-01
BOB-TACH (POWER) BLOCK 20-01
BRAKE 40-01
BUCKET POSITION VALVE 20-01

CAB DOOR 50-01
CALIBRATION (SELECTABLE JOYSTICK CONTROL) (SJC) 60-01
CAMSHAFT AND TIMING GEARS 70-01
CASE DRAIN FILTER 30-01
CHARGE PRESSURE 30-01
COMPRESSOR 80-01
CONDENSER 80-01
CONTROL HANDLE / LEVER 50-01
CONTROL HANDLE / LEVER (ACS) 50-01
CONTROL HANDLE / LEVER (SJC) 50-01
CONTROL PANEL (SJC) 50-01
CONTROL PANEL 50-01
CONTROL PANEL SETUP 60-01
CONTROL PEDALS AND LINKAGES 50-01
CONTROL PEDALS (ACS) 50-01
CONTROL SYSTEM (ACS) 60-01
CONVERSIONS SPEC-01
CRANKSHAFT AND PISTONS 70-01
CYLINDER HEAD 70-01
CYLINDER (LIFT) 20-01
CYLINDER (BOB-TACH) 20-01
CYLINDER (TILT) 20-01

DIAGNOSTICS SERVICE CODES 60-01
DRIVE BELT 30-01

ELECTRICAL / HYDRAULIC CONTROLS 60-01
ELECTRICAL / HYDRAULIC CONTROLS (SJC) 60-01
ELECTRICAL SYSTEM INFORMATION 60-01
ENGINE COOLING SYSTEM 10-01, 70-01
ENGINE INFORMATION 70-01
ENGINE LUBRICATION SYSTEM 10-01
ENGINE SPEED CONTROL 70-01
ENGINE SPEED CONTROL (SJC) 70-01
EVAPORATOR 80-01
EVAPORATOR / HEATER UNIT 80-01
EXHAUST GAS RECIRCULATION (EGR) SYSTEM 80-01
EXPANSION VALVE 80-01

FLYWHEEL AND HOUSING 70-01
FLYWHEEL RPM SENSOR 60-01
FRONT AUXILIARY HYDRAULIC COUPLER BLOCK 20-01
FUEL SYSTEM 10-01, 70-01
FUEL TANK 50-01

HEATER COIL 80-01
HEATER VALVE 80-01
HYDRAULIC CONNECTION SPECIFICATIONS SPEC-01
HYDRAULIC CONTROL VALVE (ACS) OR (SJC) 20-01
HYDRAULIC CONTROL VALVE (STANDARD) 20-01
HYDRAULIC FLUID RESERVOIR 20-01
HYDRAULIC / HYDROSTATIC FILTERS 20-01
HYDRAULIC / HYDROSTATIC FLUID SPECIFICATIONS SPEC-01
HYDRAULIC / HYDROSTATIC SYSTEM 10-01
HYDRAULIC PUMP (STANDARD) 20-01
HYDRAULIC PUMP (STANDARD) (HIGH FLOW) 20-01
HYDRAULIC PUMP (SJC) (HI FLOW) 20-01
HYDRAULIC PUMP (SJC) 20-01
HYDRAULIC SYSTEM INFORMATION 20-01
HYDROSTATIC MOTOR 30-01
HYDROSTATIC PUMP 30-01
HYDROSTATIC PUMP (SJC) 30-01
HYDROSTATIC SYSTEM INFORMATION 30-01

INSTRUMENT PANEL 60-01

JOYSTICK CONTROL 50-01

LIFT ARMS 50-01
LIFT ARM BYPASS CONTROL VALVE 20-01
LIFT ARM SUPPORT DEVICE 10-01
LIFTING AND BLOCKING THE LOADER 10-01
LIGHTS 60-01
T250 LOADER SPECIFICATIONS SPEC-01
LOADER STORAGE AND RETURN TO SERVICE 10-01
LUBRICATION SYSTEM 70-01
LUBRICATING THE LOADER 10-01

MAIN RELIEF VALVE 20-01
MAINTENANCE CLOCK 60-01
MUFFLER 70-01

MidWestTech | Bobcat T250 Compact Track Skid Loader Service Manual | Publication 698... Order the manual at mid-west-tech.com >

OIL COOLER 20-01
OPERATOR CAB 10-01, 50-01
OPERATOR SEAT - SUSPENSION 50-01

PASSWORD SETUP 60-01
PIVOT PINS 10-01

REAR AUXILIARY DIVERTER VALVE 20-01
REAR DOOR 50-01
REAR GRILL 50-01
RECEIVER / DRIER 80-01
REGULAR MAINTENANCE 80-01
REMOTE START TOOL KIT-MEL1563 10-01
REMOTE START TOOL (SERVICE TOOL) KIT-6689779 10-01

SEAT BAR 50-01
SEAT BAR SENSOR 60-01
SERVICE PC (LAPTOP COMPUTER) 60-01
SERVICE SCHEDULE 10-01
SPARK ARRESTOR MUFFLER 10-01
SPEED SENSORS (SJC) 60-01
STARTER 60-01
STEERING DRIFT COMPENSATION 60-01
STOPPING THE ENGINE AND LEAVING THE LOADER 10-01
SYSTEM CHARGING AND RECLAMATION 80-01

THERMOSTAT 80-01
TORQUE SPECIFICATIONS FOR BOLTS SPEC-01
TOWING THE LOADER 10-01
TRACK CARRIAGE COMPONENTS 40-01
TRACTION LOCK 60-01
TRANSPORTING LOADER ON A TRAILER 10-01
TROUBLESHOOTING 80-01
TURBOCHARGER 70-01

WINDOW (FRONT DOOR) 50-01
WINDOW (REAR) 50-01
WINDOW (SIDE) 50-01
WINDOW (TOP) 50-01

ACS- ADVANCED CONTROL SYSTEM
AHC- ADVANCED HAND CONTROL SYSTEM
BICS™-BOBCAT INTERLOCK CONTROL SYSTEM

MidWestTech | Bobcat T250 Compact Track Skid Loader Service Manual | Publication 698... Order the manual at mid-west-tech.com >

CONTENTS

DELIVERY REPORT X

FOREWORD II

LOADER IDENTIFICATION XI

SAFETY INSTRUCTIONS V

SERIAL NUMBER LOCATIONS IX

SAFETY AND MAINTENANCE 10-01

HYDRAULIC SYSTEM 20-01

HYDROSTATIC SYSTEM 30-01

DRIVE SYSTEM 40-01

MAIN FRAME 50-01

ELECTRICAL SYSTEM & ANALYSIS 60-01

ENGINE SERVICE 70-01


HEATING, VENTILATION, AIR CONDITIONING 80-01

SPECIFICATIONS SPEC-01

MidWestTech | Bobcat T250 Compact Track Skid Loader Service Manual | Publication 698... Order the manual at mid-west-tech.com >

Testing


Figure 50-112-1



The tools listed will be needed to do the following procedure:

MEL1608-Joystick Test Harness **[Figure 50-112-1]**
MEL1563 or 6689779-Remote Start Tool
Multimeter

Figure 50-112-2




Raise the lift arms and install an approved lift arm support device. (See Installing on Page 10-20-1.)

Raise the operator cab. (See Raising on Page 10-30-2.)

Connect the remote start tool to the loader. (See REMOTE START TOOL KIT-MEL1563 on Page 10-60-1.)

At the back side of the control panel, locate the left joystick wire connector (Item 1) **[Figure 50-112-2]**.

Figure 50-112-3



Disconnect the joystick harness connector (Item 1) from the loader wiring harness (Item 2) **[Figure 50-112-3]**.


Install the test harness (Item 3) **[Figure 50-112-3]** between the two connectors.

Turn the remote start key to ON position without starting the loader.

Check the voltage between pin 3 and pin 5 on the joystick test harness (Item 3) **[Figure 50-112-3]**.

The voltage should be between 2.45 and 2.55 volts.

Figure 50-112-4



Repeat the procedure at the right joystick wiring harness connector (Item 1) **[Figure 50-112-4]**. (If needed.)

MidWestTech | Bobcat T250 Compact Track Skid Loader Service Manual | Publication 698... Order the manual at mid-west-tech.com >

Specifications (Cont'd)

All dimensions are given in inches. Respective metric dimensions are given in millimeters enclosed by parentheses.

Timing Gear

Timing Gear Backlash	
Crank Gear - Idler Gear	0.00193 - 0.00759 in. (0,049 - 0,193 mm)
Allowable Limit	0.0087 in. (0,22 mm)
Idler Gear - Cam Gear	0.00193 - 0.00744 in. (0,049 - 0,189 mm)
Allowable Limit	0.0087 in. (0,22 mm)
Idle Gear - Injection Pump Gear	0.00119 - 0.00649 in. (0,0300 - 0,165 mm)
Allowable Limit	0.0087 in. (0,22 mm)
Clearance Between Idle Gear Shaft And Idle Gear Bushing	0.0020 - 0.0035 in. (0.050 - 0.091 mm)
Allowable Limit	0.0039 in. (0,10 mm)
Idle Gear Bushing I.D.	1.7727 - 1.7736 in. (45,025 - 45,050 mm)
Idle Gear Shaft O.D.	1.7701 - 1.7706 in. (44,959 - 44,975 mm)
Idle Gear Side Clearance	0.0059 - 0.011 in. (0,15 - 0,30 mm)
Allowable Limit	0.04 in. (0,9 mm)

Cylinder Head

Cylinder Head Surface Flatness - Allowable Limit	0.002 in. (0,05 mm)
Compression Pressure	504 PSI / 250 RPM (34,749 bar / 250 RPM)
Compression Pressure - Allowable Limit	371 PSI / 250 RPM (25,579 bar / 250 RPM)
Compression Ratio	19.0
Variance Among Cylinder - Allowable Limit	10% or less
Firing Order	1-3-4-2


Piston And Piston Ring

Piston Pin Bore I.D.	1.1811 - 1.1816 in. (30,000 - 30,013 mm)
Allowable Limit	1.183 in. (30,05 mm)
Clearance Between Compression Ring 1 and Ring Groove	0.002 - 0.003 in. (0,05 - 0,09 mm)
Allowable Limit	0.0059 in. (0,15 mm)
Clearance Between Compression Ring 2 and Ring Groove	0.00367 - 0.00472 in. (0,0930 - 0,120 mm)
Allowable Limit	0.0079 in. (0,20 mm)
Clearance Between Oil Ring And Ring Groove	0.0008 - 0.0023 in. (0.020 - 0,060 mm)
Allowable Limit	0.0059 in. (0,15 mm)
Ring Gap	
Compression Ring 1	0.012 - 0.017 in. (0,30 - 0,45 mm)
Allowable Limit	0.0492 in. (1,25 mm)
Compression Ring 2	0.012 - 0.017 in. (0,30 - 0,45 mm)
Allowable Limit	0.0492 in. (1,25 mm)
Oil Ring	0.0099 - 0.017 in. (0,25 - 0,45 mm)
Allowable Limit	0.0492 in. (1,25 mm)

MidWestTech | Bobcat T250 Compact Track Skid Loader Service Manual | Publication 698... Order the manual at mid-west-tech.com >

HVAC Repair And Leaks

Figure 80-30-3



Whenever the A/C system is opened to the atmosphere or there has been a leak in the system, the receiver/drier (Item 1) **[Figure 80-30-3]** must be changed.


Never leave hose fittings, compressor fittings or components uncapped while working on the A/C system.

MidWestTech | Bobcat T250 Compact Track Skid Loader Service Manual | Publication 698... Order the manual at mid-west-tech.com >

WIRING SCHEMATIC
(MAINFRAME)
T250 (S/N A5GS11001 - A5GS19999)
(S/N A5GT11001 - A5GT19999)

(PRINTED FEBRUARY 2008)

7123800



Order the manual at mid-west-tech.com >