
Bobcat®

Operation & Maintenance Manual
CT225 Compact Tractor

S/N ABFJ11001 & Above



6986915 (5-09) Revised (3-10) (3)

Printed in U.S.A.

© Bobcat Company 2010

MidWestTech | Bobcat CT225 Compact Tractor Operation & Maintenance Manual | Publica... Order the manual at mid-west-tech.com >

CONTENTS

FOREWORD 5

SAFETY & TRAINING RESOURCES 15

OPERATING INSTRUCTIONS 27

LOADER SYSTEM 109

PREVENTIVE MAINTENANCE 125

MACHINE SIGN TRANSLATIONS 183

SPECIFICATIONS 207

WARRANTY 219

ALPHABETICAL INDEX 223

REFERENCE INFORMATION

Write the correct information for YOUR Bobcat compact tractor in the spaces below. Always use these numbers when referring to your Bobcat compact tractor.

Compact Tractor Serial Number _____

Engine Serial Number _____

Loader Serial Number (If Equipped) _____

NOTES: _____

YOUR BOBCAT DEALER:

ADDRESS:

PHONE:

Bobcat Company
P.O. Box 128
Gwinner, ND 58040-0128
UNITED STATES OF AMERICA

Doosan Benelux SA
Drève Richelle 167
B-1410 Waterloo
BELGIUM

MidWestTech | Bobcat CT225 Compact Tractor Operation & Maintenance Manual | Publica... Order the manual at mid-west-tech.com >

FOREWORD

This Operation & Maintenance Manual was written to give the owner / operator instructions on the safe operation and maintenance of the Bobcat compact tractor. READ AND UNDERSTAND THIS OPERATION & MAINTENANCE MANUAL BEFORE OPERATING YOUR BOBCAT COMPACT TRACTOR. If you have any questions, see your Bobcat dealer. This manual may illustrate options and accessories not installed on your compact tractor.

BOBCAT COMPANY IS IS0 9001 CERTIFIED 7

REGULAR MAINTENANCE ITEMS 7

SERIAL NUMBER LOCATIONS 8
- Compact Tractor Serial Number 8
- Engine Serial Number 8
- Loader Serial Number (Optional) 9

DELIVERY REPORT 9

COMPACT TRACTOR IDENTIFICATION 10

COMPACT TRACTOR IDENTIFICATION (WITH OPTIONAL LOADER AND REAR BALLAST) 11

COMPACT TRACTOR IDENTIFICATION (WITH OPTIONAL THREE-POINT IMPLEMENT AND FRONT BALLAST) 12


FEATURES, ACCESSORIES AND ATTACHMENTS 13
- Standard Items 13
- Options And Accessories 13
- Loader (Optional) 13
- Implements - Three-Point Hitch 13
- Implements - Mid-Mount 13
- Implements - Front Mount 13

MidWestTech | Bobcat CT225 Compact Tractor Operation & Maintenance Manual | Publica... Order the manual at mid-west-tech.com >

OPERATOR CONTROLS AND INSTRUMENT PANELS

Overview


Figure 7



REF	DESCRIPTION
A	Instrument Panel (See Instrument Panel on Page 31.)
B	Floor Controls (See Floor Controls on Page 32.)
C	Right Console (See Right Console on Page 33.)
D	Left Console (See Left Console on Page 33.)

Instrument Panel

Figure 8




REF	DESCRIPTION	FUNCTION / OPERATION
1	Fuel Gauge	Shows amount of fuel in the tank.
2	Tachometer	Shows engine RPM.
3	Engine Temperature Gauge	Shows engine coolant temperature.
4	Hourmeter	Records the total operating hours of compact tractor.
5	Parking Brake Indicator Light	Light comes on when parking brake is activated. Off when brake is released.
6	Engine Oil Pressure Warning Light	Light comes on when pressure is below allowable range. STOP the engine if the light comes ON.
7	Charging System Light	Light comes on when battery voltage is low.
8	Glow Plug Light	Light comes on when glow plugs are activated. (Glow plugs may stay activated after starting.)
9	High Beam Indicator Light	Light is on when the front lights are on high.
10	Right Directional Signal Indicator	On when turn signal switch is activated for right turn.
11	Left Directional Signal Indicator	On when turn signal switch is activated for light turn.
12	PTO Indicator Light	On when PTO is engaged (rear or mid).
13	Steering Wheel	----
14	Lights / Turn Signal Switch / Horn	OFF/ LOW/ HIGH Beam; Lever up for right turn. Lever center position OFF. Lever down for left turn. Push for horn.
15	Hazard / Flasher Lights Switch	Press to right to activate flasher. Press to left to turn OFF.
16	Key Switch	(See STARTING THE ENGINE on Page 59.)
17	Engine Speed Control Lever	Move lever back to increase engine RPM, forward to decrease engine RPM.

MidWestTech | Bobcat CT225 Compact Tractor Operation & Maintenance Manual | Publica... Order the manual at mid-west-tech.com >

Fuel Filter


Remove water from or replace the fuel filter at the correct interval. (See SERVICE SCHEDULE on Page 131.)

Figure 204



The fuel filter assembly consists of the following: Locking Collar (Item1), Bowl (Item 2), O-ring (Item 3), O-ring (Item 4), Filter (Item 5), and Spring (Item 6) **[Figure 204]**.

Figure 205



Removing Water:

The fuel filter is located under the engine cover on the right side of the engine **[Figure 205]**.

Clean the area around the filter housing.

Move the fuel shut off lever to the OFF position (Item 1) **[Figure 205]**.

Place a drain pan under the fuel filter.

Remove the locking collar (Item 2) **[Figure 205]** at the filter element and remove the fuel bowl and filter.

Remove the filter and drain the fuel, water and any sediment into the drain pan. Dispose of the used fuel in an environmentally safe manner.

Reinstall the filter and bowl. Turn the lever to the ON position **[Figure 206]**.

Replacing Filter:

Clean the area around the filter housing.

Move the fuel shut off lever to the OFF position (Item 1) **[Figure 205]**.

Place a drain pan under the fuel filter.


Remove the locking collar (Item 2) **[Figure 205]** at the filter element and remove the fuel bowl and filter.

Remove the filter and drain the fuel, water and any sediment into the drain pan. Dispose of the used fuel and filter in an environmentally safe manner.

Put clean oil on the O-rings.

Install the new fuel filter, bowl and locking collar.

Figure 206



Return the shutoff lever to the ON position (Item 1) **[Figure 206]**.


Remove air from the fuel system. (See Removing Air From The Fuel System on Page 152.)


MidWestTech | Bobcat CT225 Compact Tractor Operation & Maintenance Manual | Publica... Order the manual at mid-west-tech.com >

CT225 SPECIFICATIONS

Machine Dimensions (Standard Machine)

- Dimensions are given for a compact tractor equipped with tires as shown in the table below. All dimensions are shown in inches. Respective metric dimensions are given in millimeters enclosed by parentheses.
- Where applicable, specification conform to SAE, ANSI or ISO standards and are subject to change without notice.





MS-2574S

	AG TIRES	GENERAL PURPOSE TIRES	TURF TIRES
A	97.0 (2464 mm)	95.3 (2420 mm)	96.4 (2449 mm)
B	66.5 (1690 mm)	64.8 (1645 mm)	65.9 (1674 mm)
C	33.8 (859 mm)	32.1 (814 mm)	33.2 (843 mm)
D	11.0 (280 mm)	9.3 (236 mm)	10.4 (265 mm)
D *	11.0 (280 mm)	9.3 (236 mm)	10.4 (265 mm)
E	8.2 (209 mm)	6.5 (164 mm)	7.6 (193 mm)
F	58.7 (1491 mm)	57.0 (1447 mm)	58.1 (1476 mm)
G	51.1 (1298 mm)	54.0 (1372 mm)	53.1 (1349mm)
H	43.9 (1115 mm)	45.5 (1156 mm)	44.7 (1135 mm)
J	44.1 (1121 mm)	47.3 (1202 mm)	49.3 (1252 mm)
J +	52.7 (1339 mm)	N/A	N/A
K	55.4 (1407 mm)	63.9 (1623 mm)	63.0 (1600 mm)
K +	63.9 (1623 mm)	N/A	N/A
* Equipped with optional mid PTO.		+ Adjustable AG Rims set to maximum width.	

MidWestTech | Bobcat CT225 Compact Tractor Operation & Maintenance Manual | Publica... Order the manual at mid-west-tech.com >

Safe Operation Is The Operator's Responsibility

Safety Alert Symbol

This symbol with a warning statement means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.

WARNING

Operator must have instructions before running the machine. Untrained operators can cause injury or death.

W-2001-1285

IMPORTANT

This notice identifies procedures which must be followed to avoid damage to the machine.

I-2019-0284

DANGER

The signal word DANGER on the machine and in the manuals indicates a hazardous situation which, if not avoided, will result in death or serious injury.

D-1002-1107

WARNING

The signal word WARNING on the machine and in the manuals indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

W-2044-1107

The Bobcat machine and attachment / implement must be in good operating condition before use.

Check all of the items on the Bobcat Service Schedule Decal under the 8-10 hour column or as shown in the Operation & Maintenance Manual.

Safe Operation Needs A Qualified Operator

For an operator to be qualified, he or she must not use drugs or alcoholic drinks which impair alertness or coordination while working. An operator who is taking prescription drugs must get medical advice to determine if he or she can safely operate a machine and the attachment / implement.

A Qualified Operator Must Do The Following:

Understand the Written Instructions, Rules and Regulations

- The written instructions from Bobcat Company include the Delivery Report, Operation & Maintenance Manual, Operator's Handbook, Safety Manual and machine signs (decals).
- Check the rules and regulations at your location. The rules may include an employer's work safety requirements. Regulations may apply to local driving requirements or use of a Slow Moving Vehicle (SMV) emblem. Regulations may identify a hazard such as a utility line.

Have Training with Actual Operation

- Operator training must consist of a demonstration and verbal instruction. This training is given by your Bobcat dealer before the product is delivered.
- The new operator must start in an area without bystanders and use all the controls until he or she can operate the machine and attachment / implement safely under all conditions of the work area. Fasten seat belt securely when Roll-Over Protective Structure (ROPS) is up and locked. DO NOT wear the seat belt if ROPS is down.

Know the Work Conditions

- Know the weight of the materials being handled. Avoid exceeding the machine and attachment / implement load capacities. Material which is very dense will be heavier than the same volume of less dense material. Reduce the size of load if handling dense material.
- The operator must know any prohibited uses or work areas, for example, he or she needs to know about excessive slopes.
- Know the location of any underground lines. Call local utilities or the TOLL FREE phone number found in the *Before Operation* Section of this manual.
- Wear tight fitting clothing. Always wear safety glasses when doing maintenance or service. Safety glasses, hearing protection, or respiratory equipment are required for some work. See your Bobcat dealer about Bobcat Safety equipment for your machine.

SI CT-1008

MidWestTech | Bobcat CT225 Compact Tractor Operation & Maintenance Manual | Publica... Order the manual at mid-west-tech.com >