CASE

PROFESSIONAL PARTNER

PARTS CATALOG
LOADER BACKHOE

580M
SERIES 3

71114321 NA

Issued 01Jul 08

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-01		RADIATOR - MOUNTING
02-02		DEAERATION SYSTEM - MOUNTING
02-04		AIR CLEANER - AIR INTAKE PARTS
02-05		AIR CLEANER ASSY
02-06		MUFFLER, ASPIRATED - EXHAUST SYSTEM
02-07		ENGINE - MOUNTING
02-07A		ENGINE - BLOCK HEATER
02-08		ENGINE
02-09		CYLINDER BLOCK
02-10		CYLINDER BLOCK
02-11		OIL PUMP, PAN
02-12		CRANKCASE COVERS
02-13		CYLINDER BLOCK - COVERS
02-14		CRANKCASE COVERS
02-15		BREATHER - ENGINE
02-16		CYLINDER HEAD
02-17		CYLINDER HEAD - COVERS
02-18		CYLINDER HEAD - VALVE MECHANISM
02-19		MANIFOLD - INTAKE
02-20		EXHAUST MANIFOLD
02-21		CRANKSHAFT
02-22		CONNECTING ROD
02-23		PISTON - ENGINE
02-24		FLYWHEEL - ENGINE
02-25		PULLEY - CRANKSHAFT
02-26		DYNAMIC BALANCER, GEARS & SHAFTS
02-28		CAMSHAFT
02-29		TURBOCHARGER
02-30		ENGINE OIL DIPSTICK
02-31		OIL PUMP - ENGINE
02-32		OIL FILTERS - ENGINE
02-33		PIPING - ENGINE OIL
02-34		HEAT EXCHANGER - ENGINE
02-35		WATER PUMP
02-36		COOLING SYSTEM - ENGINE
02-37		THERMOSTAT - ENGINE COOLING SYSTEM
02-38		WATER PUMP - CONTROL
02-39		FAN DRIVE
02-41		ENGINE - LIFT HOOK
02-42		ALTERNATOR MOUNTING
03-01		FUEL LINES, RESERVOIR
03-01A	01	WATER SEPARATOR FILTER
03-01B	01	WATER SEPARATOR FILTER
03-02		CONTROLS - THROTTLE, HAND
03-03		CONTROLS - THROTTLE, FOOT
03-04		FUEL INJECTION PUMP
03-05		FUEL INJECTION SYSTEM
03-06		FUEL INJECTION SYSTEM
03-07		INJECTION EQUIPMENT - PIPING
03-08		FUEL FILTER
03-09		FUEL PUMP

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03-10	PIPING - FUEL
03-11	FUEL INJECTION SYSTEM
04-01	STARTER
04-02	ALTERNATOR
04-03	STARTER MOUNTING - ALTERNATOR MOUNTING
04-04	HARNESS, ENGINE - MOUNTING AND CONNECTIONS
04-05	BATTERY, SINGLE
04-06	BATTERY, DUAL - COLD START
04-06A	COLD START GRID HEATER
04-07	HARNESS, FRONT CONSOLE - SWITCHES
04-08	HARNESS, FRONT CONSOLE - MOUNTING
04-09	HARNESS, SIDE CONSOLE - SWITCHES
04-10	INSTRUMENT PANEL, FRONT - COVERS
04-11	INSTRUMENT PANEL, SIDE - COVERS (RIGHT-HAND SIDE)
04-12	INSTRUMENT CLUSTER
04-13	ELECTRICAL - LAMPS, ROPS CANOPY
04-14	ELECTRICAL - LAMPS, ROPS CAB
04-15	LAMP ASSY (ROPS CANOPY MODELS)
04-16	HORN - ALARM, BACKUP
04-17	BEACON, ROTATING (CAB OR CANOPY MODELS)
04-18	ANTENNA, RADIO - HARNESS, RADIO
04-19	ELECTRICAL - BACKHOE AUXILIARY HYDRAULIC, UNI-DIRECTIONAL
04-20	ELECTRICAL - BACKHOE AUXILIARY HYDRAULIC, WITH PILOT CONTROLS
05-01	STEERING WHEEL - COLUMN
05-02	HYDRAULICS - STEERING
05-02A	HYDRAULICS - STEERING (COMFORT STEER)
05-03	STEERING COLUMN
05-04	AXLE, FRONT (86990837) - MOUNTING
05-05	AXLE, FRONT (86990837) - HOUSING
05-06	AXLE, FRONT (86990837) - HOUSING, SWIVEL
05-07	AXLE, FRONT (86990837) - CYLINDER, STEERING
05-08	AXLE, FRONT (86990837) - HUB AND BEARINGS
05-09	WHEELS, FRONT - TIRES
06-01	AXLE, FRONT DRIVE - MOUNTING
06-02	AXLE, FRONT DRIVE - HOUSING
06-03	AXLE, FRONT DRIVE - HOUSING, SWIVEL
06-04	AXLE, FRONT DRIVE - CYLINDER, STEERING
06-05	AXLE, FRONT DRIVE - SHAFTS, AXLE
06-06	AXLE, FRONT DRIVE - PLANETARY
06-07	AXLE, FRONT DRIVE - DIFFERENTIAL
06-08	AXLE, FRONT DRIVE - RING AND PINION
06-09	DRIVE SHAFT, FRONT AXLE
06-10	COOLING SYSTEM - TRANSMISSION
06-11	TRANSMISSION - MOUNTING
06-12	TRANSMISSION ASSY, 2WD - FILTER, OIL
06-13	TRANSMISSION ASSY, 2WD - HOUSING
06-14	TRANSMISSION ASSY, 2WD - PUMP, OIL
06-15	TRANSMISSION ASSY, 2WD - SHIFTER MECHANISM
06-16	TRANSMISSION ASSY, 2WD - SHAFT, REVERSE & PRIMARY
06-17	TRANSMISSION ASSY, 2WD - SHAFT, INPUT & PTO
06-18	TRANSMISSION ASSY, 2WD - SHAFT, SECONDARY

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

06-19		TRANSMISSION ASSY, 2WD - VALVE, CONTROL
06-20		TRANSMISSION ASSY, 4WD - FILTER, OIL
06-21		TRANSMISSION ASSY, 4WD - HOUSING
06-22		TRANSMISSION ASSY, 4WD - PUMP, OIL
06-23		TRANSMISSION ASSY, 4WD - SHIFTER MECHANISM
06-24		TRANSMISSION ASSY, 4WD - SHAFT, REVERSE & PRIMARY
06-25		TRANSMISSION ASSY, 4WD - SHAFT, INPUT & PTO
06-26		TRANSMISSION ASSY, 4WD - SHAFT, SECONDARY
06-27		TRANSMISSION ASSY, 4WD - SHAFT, OUTPUT
06-28		TRANSMISSION ASSY, 4WD - VALVE, CONTROL
06-29		TRANSMISSION ASSY, 4WD - VALVE, SOLENOID
06-30		WHEELS, REAR - TIRES
06-31		AXLE, REAR DRIVE - MOUNTING
06-32		AXLE, REAR - DIFFERENTIAL LOCK
06-33		87395372 AXLE, REAR DRIVE - HOUSING
06-34		87395372 AXLE, REAR DRIVE - DIFFERENTIAL
06-35		87395372 AXLE, REAR DRIVE - RING AND PINION
06-36		87395372 AXLE, REAR DRIVE - DIFFERENTIAL LOCK
06-37		87395372 AXLE, REAR DRIVE - PLANETARY
06-38		DRIVE SHAFT, REAR AXLE
07-01		TRANSMISSION ASSY, 2WD - BRAKE, PARKING
07-01	01	TRANSMISSION ASSY, 4WD - BRAKE, PARKING
07-02		AXLE, REAR DRIVE - BRAKE, DIFFERENTIAL
07-03		BRAKE - PEDALS
07-04		HYDRAULICS - BRAKE MASTER CYLINDER
07-05		BRAKE LINES TO TRANSMISSION - 2WD
07-05A		BRAKE LINES TO TRANSMISSION - 4WD
07-06		BRAKE LINES TO AXLES
07-07		CYLINDER ASSY - BRAKE MASTER
08-01		HYDRAULICS - PUMP, FILTER AND LOADER VALVE
08-02		HYDRAULICS - LOADER VALVE AND FILTER TO BACKHOE VALVE
08-03		HYDRAULICS - COOLER, RETURN LINES AND FILTER
08-04		HYDRAULICS - CYLINDER, LOADER LIFT
08-05		HYDRAULICS - CYLINDER, LOADER BUCKET
08-06		HYDRAULICS - CYLINDER, LOADER CLAM
08-07		HYDRAULICS - CYLINDER, LOADER CLAM
08-07A		HYDRAULICS - LOADER CLAM, AT ACCUMULATOR W/ ELECTRICAL (MODELS WITHOUT PILOT CONTROLS)
08-07B		HYDRAULICS - LOADER CLAM, AT ACCUMULATOR W/ ELECTRICAL (MODELS WITH PILOT CONTROLS)
08-08		HYDRAULICS - CYLINDER, BACKHOE STABILIZER (MODELS WITHOUT PILOT CONTROLS)
08-08A		HYDRAULICS - CYLINDER, BACKHOE STABILIZER (WITH PILOT CONTROLS)
08-09		HYDRAULICS - CYLINDER, BACKHOE SWING (WITHOUT PILOT CONTROLS)
08-09A		HYDRAULICS - CYLINDER, BACKHOE SWING (WITH PILOT CONTROLS)
08-10		HYDRAULICS - CYLINDER, BACKHOE BOOM
08-10A		HYDRAULICS - BACKHOE BOOM LOCK AND ELECTRICAL CIRCUIT
08-11		HYDRAULICS - CYLINDER, BACKHOE DIPPER
08-12		HYDRAULICS - CYLINDER, BACKHOE BUCKET (MODELS WITHOUT EXTENDABLE DIPPER)

Order the manual at mid-west-tech.com >