845B
865B
885B
Motor Grader
Tier III

Parts Catalog

Print No. 71114365
Issued 1/2012

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

	FIGURE	SEQ.
AFTER COOLER	02-21	01
AIR CLEANER	02-16	01
AIR CLEANER (84187203)	02-17	01
AIR CONDITIONER ELECTRICAL SYSTEM	04-30	01
ALTERNATOR - 4892318	04-02	01
ARTICULATION CYLINDER	08-61	01
ARTICULATION CYLINDER	09-11	01
ARTICULATION HYDRAULIC SYSTEM	08-19	01
ARTICULATION JOINT	09-10	01
ASSEMBLY RADIATOR	02-34	01
BATTERY AND HARNESS	04-04	01
BATTERY LEFT SUPPORT	09-13	01
BATTERY RIGHT SUPPORT	09-14	01
BEACON LIGHT - COMPONENTS	04-31	01
BLADE (12 FEET) - ASSEMBLY	09-15	01
BLADE (13 FEET) - ASSEMBLY	09-16	01
BLADE (14 FEET) - ASSEMBLY	09-17	02
BRAKE - STEERING HYDRAULIC SYSTEM	07-10	02
BRAKE - STEERING HYDRAULIC SYSTEM	07-11	01
BRAKE CONTROL, PEDAL	07-07	01
BRAKE HYDRAULIC SYSTEM	07-08	01
BRAKE HYDRAULIC SYSTEM	07-09	01
BRAKE HYDRAULIC SYSTEM	07-09	02
BRAKE HYDRAULIC SYSTEM	07-10	01
BREATHER - ENGINE	02-31	01
BREATHER - ENGINE	02-43	01
CAB	09-36	01
CAB LOW PROFILE, COVERINGS	09-43	02
CAB LOW PROFILE, DOOR RH - LH	09-40	02
CAB, AIR CONDITIONER DUCTS	09-50	01
CAB, AIR CONDITIONER SYSTEM	09-51	01
CAB, CENTRAL AIR DUCT	09-45	01
CAB, COVERINGS	09-43	01
CAB, DOME LIGHT AND SPEAKER	09-48	01
CAB, DOOR RH - LH	09-40	01
CAB, ELECTRICAL SYSTEM	09-49	01
CAB, EVAPORATOR BOX	09-52	01
CAB, FIXED GLASS LOWER WIPER - OPTIONAL	09-47	03
CAB, FRONT WINDSHIELD WIPER	09-47	01
CAB, GLASSES	09-38	01
CAB, LOCK DOOR	09-41	01
CAB, REAR PLATE	09-42	01
CAB, REAR WIPER - OPTIONAL	09-47	02
CAB, REAR-VIEW MIRROR	09-46	01
CAB, ROOF COVERINGS	09-44	01
CAB, WATER RESERVOIR	09-49	02
CAB, WINDOW	09-39	01
CAB, WINDOW LOWER WIPER - OPTIONAL	09-47	04
CAMSHAFT	02-11	01
CENTER MOLDBOARD FLOAT	08-28	01
CIRCLE REDUCTION GEAR	09-02	01
CIRCLE SHIFT CYLINDER	08-59	01
CIRCLE SHIFT HYDRAULIC SYSTEM	08-08	01
CIRCLE TURN HYDRAULIC SYSTEM	08-14	01
CONNECTING ROD AND BEARING	02-14	01
CRANKSHAFT	02-15	01

Order the manual at mid-west-tech.com >

CYLINDER BLOCK - MAIN BEARINGS	02-04	01
CYLINDER BLOCK - PLUGS AND PISTONS	02-10	01
CYLINDER HEAD	02-08	01
CYLINDER HEAD - COVERS	02-06	01
CYLINDER HEAD - VALVE MECHANISM	02-07	01
DECALS	09-54	01
DECALS	09-54	02
DIAGNOSTIC TEST PANEL	08-32	01
DIFERENTIAL HYDRAULIC BLOCK	08-25	01
DIPSTICK AND INTRODUCTION CAP	02-26	01
DOZER BLADE AND SKID PLATES	09-22	01
DOZER BLADE FLOAT CONTROL	08-17	01
ELECTRICAL SYSTEM	04-18	01
ELECTRICAL SYSTEM, FLOOR - (DIRECT DRIVE)	04-11	01
ELECTRICAL SYSTEM, FLOOR - (TORK CONVERTER)	04-11	02
ELECTRICAL SYSTEM, FPT ENGINE	04-12	01
ELECTRICAL SYSTEM, FPT ENGINE	04-13	01
ELECTRICAL SYSTEM, FPT ENGINE	04-14	01
ELECTRICAL SYSTEM, FPT ENGINE	04-15	01
ELECTRICAL SYSTEM, FRONT FRAME	04-10	01
ELECTRICAL SYSTEM, LATERAL CONSOLE	04-17	01
ELECTRICAL SYSTEM, LATERAL CONSOLE	04-21	01
ELECTRICAL SYSTEM, LATERAL CONSOLE	04-23	01
ELECTRICAL SYSTEM, LATERAL CONSOLE - FUSES	04-22	01
ELECTRICAL SYSTEM, REAR FRAME	04-06	01
ELECTRICAL SYSTEM, REAR FRAME	04-07	01
ELECTRICAL SYSTEM, REAR FRAME	04-08	01
ELECTRICAL SYSTEM, REAR FRAME	04-09	01
ENGINE - COOLING SYSTEM	02-45	01
ENGINE - LIFT HOOKS	02-05	01
ENGINE - PISTON	02-13	01
ENGINE AND SUPPORTS	02-01	01
ENGINE AND SUPPORTS	02-02	01
ENGINE AND SUPPORTS	02-03	01
ENGINE HOOD - DAMPER AND BRACKET	09-31	01
ENGINE HOOD AND GRILLE	09-30	01
FAN DRIVE	02-37	01
FAN DRIVE	02-38	01
FAN DRIVE	02-39	01
FAN DRIVE REVERSER SYSTEM	02-40	01
FAN DRIVE REVERSER SYSTEM	02-41	01
FAN DRIVE REVERSER SYSTEM	02-42	01
FAN HYDRAULIC MOTOR	08-65	01
FIRE EXTINGUISHER	09-28	01
FLOOR AND INSULATING	09-06	01
FLYWHEEL HOUSING	02-28	01
FRONT AXLE - ASSEMBLY	06-04	01
FRONT AXLE - SIDE STEERING KNUCKLE - ASSEMBLY	06-05	01
FRONT AXLE WHEEL HUB	06-06	01
FRONT AXLE WHEEL HUB	06-06	02
FRONT CHASSIS	09-09	01
FRONT COUNTERWEIGHT	09-26	01
FRONT GEAR COVER	02-09	01
FRONT WHEEL LEAN CYLINDER	08-55	01
FRONT WHEEL LEAN PIPING	08-18	01
FUEL FILTER	03-07	01
FUEL INJECTION PUMP	03-08	01
FUEL INJECTION SYSTEM - DRAIN LINE	03-12	01

Order the manual at mid-west-tech.com >

FUEL INJECTION SYSTEM - INJECTOR	03-10	01
FUEL INJECTION SYSTEM - MODULE, ENGINE CONTROL	03-14	01
FUEL INJECTION TUBES	03-09	01
FUEL LINES	03-01	01
FUEL PIPING	03-11	01
FUEL TANK	03-03	01
FUEL TANK	03-04	01
GEAR COVER - REAR HOUSING	02-27	01
GEAR COVER PLATE - POWER TAKE - OFF	02-29	01
HARNESS, ELECTRICAL SYSTEM	04-05	01
HARNESS, ENGINE ELECTRONIC CONTROL MODULE	03-13	01
HYDRAULIC PUMP - STEERING AND BRAKE	07-12	01
HYDRAULIC PUMP - STEERING AND BRAKE	07-12	02
HYDRAULIC TANK ASSY	08-01	01
HYDRAULIC TANK, FILTERS	08-02	01
INLET VALVE	08-46	01
INSPECTION COVER	09-37	01
INSTRUMENT PANEL, FRONT CONSOLES	04-26	01
INSTRUMENT PANEL, FRONT CONSOLES	04-27	01
INSTRUMENT PANEL, FRONT CONSOLES	04-28	01
INSTRUMENT PANEL, OPTIONALS	04-25	01
INSTRUMENT PANEL, STD - (DIRECT DRIVE)	04-24	02
INSTRUMENT PANEL, STD - (TORK CONVERTER)	04-24	01
INTAKE MANIFOLD	02-18	01
LH LADDER ASSY	09-07	01
LOCK VALVE	08-40	01
LOCK VALVE	08-37	01
MAIN PUMP ASSY	08-41	01
MAIN PUMP, BODY	08-42	01
MAIN PUMP, DRUM	08-43	01
MANIFOLD - EXHAUST	02-19	01
MOLBOARD HYDRAULIC SYSTEM	08-09	01
MOLDBOARD DRAWBAR AND CICLE	09-01	01
MOLDBOARD HYDRAULIC SYSTEM	08-06	01
MOLDBOARD HYDRAULIC SYSTEM	08-07	01
MOLDBOARD LEAN SYSTEM	09-21	01
MOLDBOARD LEFT AND RIGHT EXTENSION	09-18	01
MOLDBOARD LIFT CYLINDER	08-56	01
MOLDBOARD LIFT HYDRAULIC ACCUMULATOR	08-27	01
MOLDBOARD LIFT PIPING	08-12	01
MOLDBOARD LIFT PIPING	08-13	01
MOLDBOARD PITCH CYLINDER	08-57	01
MOLDBOARD REINFORCEMENT	09-19	01
MOLDBOARD SHIFT HYDRAULIC ACCUMULATOR	08-26	01
MOLDBOARD SIDE SHIFT	09-20	01
MOLDBOARD SIDE SHIFT CYLINDER	08-60	01
MUFFLER AND EXHAUST PIPE	02-20	01
OIL FILTER AND COOLER	02-32	01
OIL PUMP, RESERVOIR	02-25	01
OPERATOR'S CONSOLE	05-04	01
OPERATOR'S CONSOLE	05-07	01
OPERATOR'S CONSOLE	05-03	01
OPERATOR'S CONSOLE	05-05	01
OPERATOR'S CONSOLE	05-06	01
OPERATOR'S CONSOLE - CLAMPS	05-02	01
OPERATOR'S CONSOLE - STEERING HYDRAULIC SYSTEM	05-01	01
OUTLET VALVE	08-54	01
PARKING BRAKE	07-03	01

Order the manual at mid-west-tech.com >