9050B Excavator
P.I.N. EAC0501122 and After

Parts Catalog

Bur 7-2391

CASE

Order the manual at mid-west-tech.com >

PICTORIAL SECTION INDEX

GENERAL 1



ENGINE 2



FUEL 3



ELECTRICAL 4



TRACKS/ STEERING 5



POWER TRAIN 6



HYDRAULICS 8



CHASSIS AND MOUNTED EQUIPMENT 9

NUMERICAL INDEX 10

MidWestTech | Case 9050B Excavator Parts Catalog | Publication 7-2391 Order the manual at mid-west-tech.com >

GENERAL INFORMATION

Indexes

Section 1 of this catalog contains a SN and P.I.N. location guide, alphabetical index, pictorial index of the sections included, and pictorial index(es) for quick location of hoses and tubes (and other system components in some catalogs). An alphabetical index also appears at the beginning of each section. Section 10 is the Numerical Index which lists all part numbers in alpha/numeric order with their page location and reference number.

Illustrations

The arrangement of this parts catalog is for easy identification of parts. All parts are illustrated in "exploded views" in proper relation to each other. Reference numbers used in the illustrations refer to those on the text pages. The text pages list reference number, part number, part description and the quantity required.

Abbreviations

P.I.N. "Product Identification Number"

SN "Serial Number"

NSS "Not Serviced Separately" in the part number column indicates this part is not available for service.

REF "Reference" in the part number column indicates this part has special service information. The page where this information can be found is given in the part description column.

UAR "Use As Required" in the quantity required column indicates the number of parts used is determined by service needs.

Right-Hand and Left-Hand Identification

The reference to right-hand and left-hand in this catalog is identified by the operator standing at the rear of the basic unit (without rear attachment), looking toward the front of the machine (in normal forward travel). For pages covering any machine attachments, right-hand and left-hand are defined by the operator sitting in the position for proper operation of the attachment.

Catalog Revisions and Supplements

Changes to the product may make it necessary to revise or add pages to this catalog. A cover sheet will list all pages released in a revision or supplement. Each new or revised page will have a new issue date. All revised and new pages must be put into the parts catalog as soon as they are received.

Parts Orders

Orders must specify product model, all necessary serial numbers, correct part number, complete description, quantity required, method of shipment, and shipping address.

Text Format Explanation

An assembly may contain service items. The component parts of an assembly or subassembly are indented. The quantity required column lists the number of assemblies required for a completed machine, and the number of components required in a complete assembly or subassembly.

The example below illustrates the use of indents and other text page elements explained on this page.

HYDRAULIC FILTER

REF.	PART NO.	DESCRIPTION	REQ'D.
1	D4356734	FILTER ASSEMBLY - hydraulic oil, P.I.N. 7534840 and after	1
	D61903	HEAD ASSEMBLY - filter	1
2	NSS	HEAD - filter, order D61903 head assembly	1
3	D58199	VALVE - bypass	1
	D43800	KIT - filter element, replaces D35700 element kit	1
4	NSS	ELEMENT - filter, order D43800 element kit	1
5	A27994	O-RING - filter	1
6	D61948	HOUSING -filter	1
7	REF	CANOPY - ROPS, order from Machinery Price List	1
8	843065C1	HOSE - 3353 mm (132 inch)) long, reservoir to pump	1
9	113-323	BOLT - hex, 7/16 NC x 1-3/4 inch	2
10	814-8030	BOLT - hex, 8 - 1.25 x 30 mm	4

MidWestTech | Case 9050B Excavator Parts Catalog | Publication 7-2391 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Adjuster - track 5-15,5-17
Air Cleaner System 2-11,2-13
Air Conditioner ..... 4-25,9-63 - 9-71,9-99
Air Restriction Indicator Switch 2-11,4-5
Alarm - travel 4-9
Alternator Relay 4-13,4-15
Antenna - radio 9-83
Antidrift Valve 8-165
Arm
  Control Lines 8-57,8-59
  Cylinder 8-191
  Cylinder Lines 8-65,8-67
  Cylinder Supply Lines 8-61,8-63
Arm and Cylinder
  2.63M (8 ft 8 in) & 3.23M (10 ft 7 in) 9-113
  4.03M (13 ft 3 in) 9-115
Ashtray 9-83
Auxiliary Equipment Option
  Supply and Cylinder Line
    Mounting ..... 8-129 - 8-135
Auxiliary Hydraulic Controls 9-79

B

Batteries, Battery Cables and Mounting 4-11
Battery Cables 4-3,4-7,4-11
Battery Relay 4-13,4-15
Belt - seat 9-49,9-53
Boom
  Control Lines 8-49,8-51
  Cylinder 8-189
  Cylinder Lines 8-55
  Pilot Lines 8-53
Boom Lubrication Lines 9-107,9-109
Boom, Mounting Pins and Cylinders 9-111
Bucket
  Control Lines 8-69
  Cylinder 8-193,8-195
  Cylinder Lines ..... 8-75 - 8-79
  Cylinder Supply Lines 8-71,8-73
Buckets ..... 9-119 - 9-133
Bucket Teeth 9-135,9-137
Bypass Oil Filter and Lines 8-19

C

Cab
  Air Conditioner 9-63-9-71,9-99
  Door 9-93
  Electrical System 4-19
  Fan 9-101,9-103
  Floor, Mounting and Mats 9-73
  Front Window Assembly 9-87
  Lower Front Window 9-89

C

Cab - continued
  Miscellaneous Parts 9-83,9-85
  Rear Console/ Panels (w/o AC) 9-95
  Rear Console/Panels (w/AC) 9-97
  Roof Panel Assembly 9-89
  Vandal Guards 9-91
  Windows and Seals 9-81
Cables - battery 4-3,4-7,4-11
Cables - ground 4-9
Carrier Roller - track 5-19,5-21
Chain - track 5-7,5-9
Cluster - instrument 4-17
Cold Start 2-15
Console - instrument 4-17,4-19
Console Box Control Panel Assemblies 9-47
Control Component Mounting and Hose
  Supports ..... 8-29 - 8-33
Control Component Mounting and Hose
  Supports - cab 8-35
Controller - electrical system 4-19
Controller - motor driver 4-19
Control Lines
  Arm 8-57,8-59
  Boom 8-49,8-51
  Bucket 8-69
  Swing 8-81,8-83
  Travel ..... 8-91 - 8-95
Control Panel Assemblies 9-47
Control Signal Lines 8-37,8-39
Control Valve
  Drain Lines 8-109
  Housings and Miscellaneous
    Components 8-161
  Main Pilot Valves 8-163
  Manually Operated 8-153
  Miscellaneous Valves and
    Components ..... 8-167 - 8-175
  Mounting 8-159
  Pedal Operated 8-155,8-157
  Pilot Lines 8-43
  Pilot Control Solenoid 8-177
  Supply Lines 8-13,8-15
  Working Circuit Relief Valves 8-165,8-167
Coolant Overflow Reservoir 2-9
Cooling System Hose Supports 8-17
Cooling System Supply and Return Lines 8-17
Cooling Systems
  Engine 2-5,2-7
  Return Line 8-17
  Supply Line 8-17
Counterweight 9-13
Covers - access 5-3,5-5

MidWestTech | Case 9050B Excavator Parts Catalog | Publication 7-2391 Order the manual at mid-west-tech.com >