9060B Excavator
P.I.N. EAC0601026 and After
Parts Catalog

Bur 7-2401

This Catalog Replaces Bur 7-2400

MidWestTech | Case 9060B Excavator Parts Catalog | Publication 7-2401

Order the manual at mid-west-tech.com >

PICTORIAL SECTION INDEX

GENERAL 1


ENGINE 2


FUEL 3


ELECTRICAL 4


STEERING 5


POWER TRAIN 6


HYDRAULICS 8


CHASSIS AND MOUNTED EQUIPMENT 9

NUMERICAL INDEX 10

MidWestTech | Case 9060B Excavator Parts Catalog | Publication 7-2401 Order the manual at mid-west-tech.com >

GENERAL INFORMATION

Indexes

Section 1 of this catalog contains a SN and P.I.N. location guide, alphabetical index, pictorial index of the sections included, and pictorial index(es) for quick location of hoses and tubes (and other system components in some catalogs). An alphabetical index also appears at the beginning of each section. Section 10 is the Numerical Index which lists all part numbers in alpha/numeric order with their page location and reference number.

Illustrations

The arrangement of this parts catalog is for easy identification of parts. All parts are illustrated in "exploded views" in proper relation to each other. Reference numbers used in the illustrations refer to those on the text pages. The text pages list reference number, part number, part description and the quantity required.

Abbreviations

P.I.N. "Product Identification Number"

SN "Serial Number"

NSS "Not Serviced Separately" in the part number column indicates this part is not available for service.

REF "Reference" in the part number column indicates this part has special service information. The page where this information can be found is given in the part description column.

UAR "Use As Required" in the quantity required column indicates the number of parts used is determined by service needs.

Right-Hand and Left-Hand Identification

The reference to right-hand and left-hand in this catalog is identified by the operator standing at the rear of the basic unit (without rear attachment), looking toward the front of the machine (in normal forward travel). For pages covering any machine attachments, right-hand and left-hand are defined by the operator sitting in the position for proper operation of the attachment.

Catalog Revisions and Supplements

Changes to the product may make it necessary to revise or add pages to this catalog. A cover sheet will list all pages released in a revision or supplement. Each new or revised page will have a new issue date. All revised and new pages must be put into the parts catalog as soon as they are received.

Parts Orders

Orders must specify product model, all necessary serial numbers, correct part number, complete description, quantity required, method of shipment, and shipping address.

Text Format Explanation

An assembly may contain service items. The component parts of an assembly or subassembly are indented. The quantity required column lists the number of assemblies required for a completed machine, and the number of components required in a complete assembly or subassembly.

The example below illustrates the use of indents and other text page elements explained on this page.

HYDRAULIC FILTER

REF.	PART NO.	DESCRIPTION	REQ'D.
1	D4356734	FILTER ASSEMBLY - hydraulic oil, P.I.N. 7534840 and after	1
	D61903	HEAD ASSEMBLY - filter	1
2	NSS	HEAD - filter, order D61903 head assembly	1
3	D58199	VALVE - bypass	1
	D43800	KIT - filter element, replaces D35700 element kit	1
4	NSS	ELEMENT - filter, order D43800 element kit	1
5	A27994	O-RING - filter	1
6	D61948	HOUSING -filter	1
7	REF	CANOPY - ROPS, order from Machinery Price List	1
8	843065C1	HOSE - 3353 mm (132 inch) long, reservoir to pump	1
9	113-323	BOLT - hex, 7/16 NC x 1-3/4 inch	2
10	814-8030	BOLT - hex, 8 - 1.25 x 30 mm	4

MidWestTech | Case 9060B Excavator Parts Catalog | Publication 7-2401 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Adjuster - track 5-9
Air Cleaner System 2-11,2-13
Air Conditioner, Heater & Hoses ..... 9-71 - 9-77B
Air Restriction Indicator Switch 2-11,2-13
Alarm - travel 4-7,4-13, 4-13B
Alternator 2-3,4-7
Antenna - radio 4-3,9-57
Arm
  Control Lines ..... 8-55 - 8-61,8-115,8-121
  Cylinder 8-123,8-145
  Cylinder Lines 8-59,8-61
  Cylinder Supply Lines 8-61
Arm Lubrication
  2.49 M (8 ft. 2 in.) Arm 9-89
  3.35 M (11 ft.) Arm 9-87
  4.00 M (13 ft. 1 in.) Arm 9-85
  5.38 M (17 ft. 8 in.) Arm 9-83
Arms and Linkage 9-91
Auxiliary Hydraulic Control-Pedal and
  Floormat 6-19
Auxiliary Hydraulics ..... 8-99 - 8-113
Auxiliary Hydraulics Solenoid Valve 8-13

B

Batteries and Mounting 4-7,4-19
Battery Cables 4-7,4-9,4-11
Battery Relay 4-15,4-15B
Belt - air conditioning compressor 9-71,9-71B
Belt - fan 2-5
Belt - seat 9-47
Boom
  Control Lines ..... 8-45 - 8-53,8-115 - 8-119
  Cylinder 8-119,8-141,8-143
  Cylinder Lines 8-49
Boom Lubrication Lines 9-79
Boom, Mounting Pins and Cylinders 9-81
Bucket
  Control Lines 8-63
  Cylinder 8-147
  Cylinder Lines 8-67
  Cylinder Supply Lines 8-65
Buckets ..... 9-93 - 9-105
Bucket Teeth 9-107,9-109
Bypass Oil Filter and Lines 8-23

C

Cab
  Air Conditioner ..... 9-71 - 9-73D, 9-77B
  Door 9-69
  Electrical System 4-3,4-5
  Fan 4-25
  Floor, Mounting and Mats 9-55

C

Cab - continued
  Floor Mounted Air Conditioner ..... 9-73 - 9-77B
  Front Window Assembly 9-63
  Lower Front Window 9-65
  Miscellaneous Parts 9-59,9-61
  Rear Console / Panels (without Air
    Conditioning) 9-75
  Rear Console / Panels (with Air
    Conditioning) 9-77
  Roof Panel Assembly 9-65
  Vandal Guards 9-67
  Windows and Seals 9-57
Cables - battery 4-7,4-9,4-11
Carrier Roller - track 5-11
Chain - track 5-5
Cluster - instrument 4-3,4-17
Cold Start System 2-15
Console Box Side Covers 9-39,9-43
Control Component Mounting and
  Hose Supports ..... 8-25 - 8-31
Control Console Linkage ..... 9-39 - 9-45
Controller 4-3,4-27
Control Lines
  Arm ..... 8-55 - 8-61, 8-115,8-121
  Boom ..... 8-45 - 8-53,8-115 - 8-119
  Bucket ..... 8-63 - 8-67
  Counterweight Removal ..... 8-131 - 8-139
  Signal 8-33
  Swing ..... 8-69 - 8-77
  Travel ..... 8-79 - 8-91
Control Panel Assemblies 4-33,9-73,9-75
Control Signal Lines 8-33
Control Valve
  Drain Lines 8-93
  Free Swing 8-203
  Housings and Miscellaneous
    Components 8-179
  Main Control Valve ..... 8-177 - 8-199
  Main Pilot Valves 8-183,8-185
  Manually Operated 8-211
  Miscellaneous Valves and
    Components ..... 8-187,8-193 - 8-199
  Mounting 8-177
  Pedal Operated 8-213
  Pilot Lines 8-35,8-37
  Pilot Control Solenoid 8-201
  Pressure and Return
    Lines ..... 8-35 - 8-43,8-93 - 8-97
  Supply Lines 8-13
  Working Circuit Relief Valves 8-191
Cooler - hydraulic oil 8-15

MidWestTech | Case 9060B Excavator Parts Catalog | Publication 7-2401 Order the manual at mid-west-tech.com >