# Small Wheel Loaders
# 21D, 121D and 221D

## Service Manual

7-29240

CASE CONSTRUCTION

MidWestTech | Case 21D, 121D, 221D Small Wheel Loader Service Manual | Publication 7-29240

Order the manual at mid-west-tech.com >

**FOREWORD** ..... 1
Using the Technical Handbook ..... 1
Servicing and repair ..... 1

**FUNDAMENTAL SAFETY INSTRUCTIONS** ..... 2

**Warnings and symbols** ..... 2

**Danger in the event of non-obser-vance of the safety instructions** ..... 2

**Organizational measures** ..... 3

**Selection and qualification of personnel** ..... 4

**OPERATING, SAFETY INSTRUCTIONS**
Standard operation ..... 4

**MAINTENANCE, SAFETY INSTRUCTIONS** ..... 5

**WARNING OF SPECIAL DANGERS**
Electric energy ..... 6
Gas, dust, steam and smoke ..... 6
Hydraulic and pneumatic equipment ..... 7
Noise ..... 7
Oil, grease and other chemical substances ..... 7

**TRANSPORTING AND TOWING - RECOMMISSIONING** ..... 7

**REPAIR WORK - SAFETY INSTRUCTIONS** ..... 8

**ACCUMULATORS** ..... 9

**Safety instructions** ..... 9

**ENGINE** ..... 10

**Engine - repair instructions** ..... 10

**Assisted starting (jump-starting) - Safety instructions** ..... 10

**WELDING OPERATIONS**
Welding operations - safety instructions ..... 11

MidWestTech | Case 21D, 121D, 221D Small Wheel Loader Service Manual | Publication 7... Order the manual at mid-west-tech.com >

MidWestTech | Case 21D, 121D, 221D Small Wheel Loader Service Manual | Publication 7-29240



# Page 3 - 4

| NAME | DESCRIPTION | PAGE | |
|---|---|---|---|
| A3H43 | DIRECTION LEFT LAMP | 3 / 2 | |
| A3H44 | DIRECTION RIGHT LAMP | 3 / 2 | |
| A3H11 | HIGH BEAM LAMP | 3 / 2 | |
| E12.1 | LICENSE PLATE LIGHT | 3 / 5 | OPT. |
| E12.2 | LICENSE PLATE LIGHT | 3 / 5 | OPT. |
| E1E1 | HEADLIGHT LEFT | 3 / 0 | |
| E1E2 | PARKING LIGHT LEFT | 3 / 5 | |
| E1E3 | DIRECTION INDICATOR FRONT LEFT | 3 / 4 | |
| E2E1 | HEADLIGHT RIGHT | 3 / 1 | |
| E2E2 | PARKING LIGHT RIGHT | 3 / 6 | |
| E2E3 | DIRECTION INDICATOR FRONT RIGHT | 3 / 3 | |
| E5E1 | TAIL LIGHT REAR LEFT | 3 / 5 | |
| E5E2 | BRAKE LIGHT LEFT | 3 / 1 | |
| E5E3 | DIRECTION INDICATOR REAR LEFT | 3 / 4 | |
| E6E1 | TAIL LIGHT REAR RIGHT | 3 / 4 | |
| E6E2 | BRAKE LIGHT RIGHT | 3 / 1 | |
| E6E3 | DIRECTION INDICATOR REAR RIGHT | 3 / 3 | |
| F1A | LEFT HIGH BEAM LIGHT | 3 / 2 | |
| F1B | RIGHT LOW BEAM LIGHT FUSE | 3 / 1 | |
| F3B | BRAKE LIGHTS & DIRECTION LIGHTS FUSE | 3 / 3 | |
| F6A | RIGHT HIGH BEAM LIGHT | 3 / 2 | |
| F6C | LEFT LOW BEAM LIGHT FUSE | 3 / 2 | |
| F8A | WARNING LIGHTS & HORN SWITCH FUSE | 3 / 2 | |
| F8B | FRONT LEFT & REAR RIGHTS TAIL LIGHTS FUSE | 3 / 4 | |
| F8C | FRONT RIGHT, REAR LEFT TAIL LIGHTS & LICENSE PLATE LIGHT FUSE | 3 / 4 | |
| K20.1 | FLASHER UNIT | 3 / 3 | |
| K23 | FRONT WIPER RELAY | 3 / 2 | |
| K5.1 | HIGH BEAM LIGHTS RELAY | 3 / 1 | |
| K5.2 | LOW BEAM LIGHTS RELAY | 3 / 1 | |
| M3 | FRONT WIPER MOTOR | 3 / 2 | |
| M4 | PUMP WASHER FRONT | 3 / 3 | |
| S1B | BRAKE LIGHTS SWITCH | 3 / 1 | |
| S20 | WARNING SWITCH | 3 / 3 | |
| S23 | STEERING SWITCH | 3 / 1 | |
| S5 | LIGHTS SWITCH | 3 / 5 | |
| | | | |
| A90.2 | RADIO | 4 / 3 | OPT. |
| A90.3 | SPEAKER LEFT | 4 / 3 | |
| A90.4 | SPEAKER RIGHT | 4 / 3 | |
| A3H41 | WORKING LIGHTS LAMP | 4 / 3 | |
| E20 | CIGARETTES PLUG | 4 / 2 | |
| E3.1 | WORKING LIGHT FRONT LEFT | 4 / 4 | |
| E3.4 | WORKING LIGHT REAR RIGHT | 4 / 4 | OPT. (L; LW) |
| E4.1 | WORKING LIGHT FRONT RIGHT | 4 / 4 | |
| E4.4 | WORKING LIGHT REAR LEFT | 4 / 5 | OPT. (L; LW) |
| E9 | INTERIOR LIGHT | 4 / 2 | |
| F1C | HORN FUSE | 4 / 1 | |
| F2C | REAR WORKING LIGHTS FUSE | 4 / 5 | |
| F3A | WIPER MOTORS & RADIO FUSE | 4 / 1 | |
| F7C | RADIO & CIGARETTES LIGHTER FUSE | 4 / 2 | |
| F9A | FRONT WORKING LIGHTS FUSE | 4 / 4 | |
| F9B | GIRATORY BEACON FUSE | 4 / 5 | |
| H7 | HORN | 4 / 0 | |
| H7.1 | HORN | 4 / 0 | |
| K7 | HORN RELAY | 4 / 0 | |
| M3.1 | REAR WIPER MOTOR | 4 / 1 | |
| M4.1 | PUMP WASHER REAR | 4 / 1 | |
| S3.1 | REAR WIPER SWITCH | 4 / 1 | |
| S36 | GIRATORY BEACON SWITCH | 4 / 5 | |
| S6.1 | FRONT WORKING LIGHTS SWITCH | 4 / 4 | |
| S6.2 | REAR WORKING LIGHTS SWITCH | 4 / 5 | |
| X121.1 | GIRATORY BEACON PLUG | 4 / 5 | |

| Ind. | Änd.-Nr./Change-No | Datum/Date | Name | Bearb.Abt./Written department 03350 | | |
|---|---|---|---|---|---|---|
| 04 | | | | | Datum/Date | Name |
| 04 | | | | Bearb./Written | 27.07.00 | SIK |
| 02 | | | | Gepr./Checked | | |
| 01 | | | | Norm/St.Check | | |

| Typ | BG | UBG | CH |
|---|---|---|---|
| 955 | 32 | 050 | 50 |
| 80WKZ W50H | | | |

D&K Drenstein & Koppel Aktiengesellschaft

Ursprung/Origin

Benennung/Description
WIRING DIAGRAM
PARTS DESCRIPTION

Sach-Nr. / Part-No 3004800

A4 | Bett Sheet 10 | F.K. D.S.No | Blätter Sheets

Ers. für Substitut for | Ers. durch Substituted

Order the manual at mid-west-tech.com >