Small Wheel Loaders
321D

Service Manual

7-29290

CASE CONSTRUCTION

MidWestTech | Case 321D Small Wheel Loader Service Manual | Publication 7-29290

Order the manual at mid-west-tech.com >

FOREWORD 1
Using the Technical Handbook 1
Servicing and repair 1

FUNDAMENTAL SAFETY INSTRUCTIONS 2

Warnings and symbols 2

Danger in the event of non-obser-vance of the safety instructions 2

Organizational measures 3

Selection and qualification of personnel 4

OPERATING, SAFETY INSTRUCTIONS
Standard operation 4

MAINTENANCE, SAFETY INSTRUCTIONS 5

WARNING OF SPECIAL DANGERS
Electric energy 6
Gas, dust, steam and smoke 6
Hydraulic and pneumatic equipment 7
Noise 7
Oil, grease and other chemical substances 7

TRANSPORTING AND TOWING - RECOMMISSIONING 7

REPAIR WORK - SAFETY INSTRUCTIONS 8

ACCUMULATORS 9

Safety instructions 9

ENGINE 10

Engine - repair instructions 10

Assisted starting (jump-starting) - Safety instructions 10

WELDING OPERATIONS
Welding operations - safety instructions 11

Order the manual at mid-west-tech.com >

MidWestTech | Case 321D Small Wheel Loader Service Manual | Publication 7-29290

Page 3 - 4

NAME	DESCRIPTION	PAGE	
A3H43	DIRECTION LEFT LAMP	3 / 2	
A3H44	DIRECTION RIGHT LAMP	3 / 2	
A3H11	HIGH BEAM LAMP	3 / 2	
E12.1	LICENSE PLATE LIGHT	3 / 5	OPT.
E12.2	LICENSE PLATE LIGHT	3 / 5	OPT.
E1E1	HEADLIGHT LEFT	3 / 0	
E1E2	PARKING LIGHT LEFT	3 / 5	
E1E3	DIRECTION INDICATOR FRONT LEFT	3 / 4	
E2E1	HEADLIGHT RIGHT	3 / 1	
E2E2	PARKING LIGHT RIGHT	3 / 6	
E2E3	DIRECTION INDICATOR FRONT RIGHT	3 / 3	
E5E1	TAIL LIGHT REAR LEFT	3 / 5	
E5E2	BRAKE LIGHT LEFT	3 / 1	
E5E3	DIRECTION INDICATOR REAR LEFT	3 / 4	
E6E1	TAIL LIGHT REAR RIGHT	3 / 4	
E6E2	BRAKE LIGHT RIGHT	3 / 1	
E6E3	DIRECTION INDICATOR REAR RIGHT	3 / 3	
F1A	LEFT HIGH BEAM LIGHT	3 / 2	
F1B	RIGHT LOW BEAM LIGHT FUSE	3 / 1	
F3B	BRAKE LIGHTS & DIRECTION LIGHTS FUSE	3 / 3	
F6A	RIGHT HIGH BEAM LIGHT	3 / 2	
F6C	LEFT LOW BEAM LIGHT FUSE	3 / 2	
F8A	WARNING LIGHTS & HORN SWITCH FUSE	3 / 2	
F8B	FRONT LEFT & REAR RIGHTS TAIL LIGHTS FUSE	3 / 4	
F8C	FRONT RIGHT, REAR LEFT TAIL LIGHTS & LICENSE PLATE LIGHT FUSE	3 / 4	
K20.1	FLASHER UNIT	3 / 3	
K23	FRONT WIPER RELAY	3 / 2	
K5.1	HIGH BEAM LIGHTS RELAY	3 / 1	
K5.2	LOW BEAM LIGHTS RELAY	3 / 1	
M3	FRONT WIPER MOTOR	3 / 2	
M4	PUMP WASHER FRONT	3 / 3	
S1B	BRAKE LIGHTS SWITCH	3 / 1	
S20	WARNING SWITCH	3 / 3	
S23	STEERING SWITCH	3 / 1	
S5	LIGHTS SWITCH	3 / 5	
A90.2	RADIO	4 / 3	OPT.
A90.3	SPEAKER LEFT	4 / 3	
A90.4	SPEAKER RIGHT	4 / 3	
A3H41	WORKING LIGHTS LAMP	4 / 3	
E20	CIGARETTES PLUG	4 / 2	
E3.1	WORKING LIGHT FRONT LEFT	4 / 4	
E3.4	WORKING LIGHT REAR RIGHT	4 / 4	OPT. (L; LW)
E4.1	WORKING LIGHT FRONT RIGHT	4 / 4	
E4.4	WORKING LIGHT REAR LEFT	4 / 5	OPT. (L; LW)
E9	INTERIOR LIGHT	4 / 2	
F1C	HORN FUSE	4 / 1	
F2C	REAR WORKING LIGHTS FUSE	4 / 5	
F3A	WIPER MOTORS & RADIO FUSE	4 / 1	
F7C	RADIO & CIGARETTES LIGHTER FUSE	4 / 2	
F9A	FRONT WORKING LIGHTS FUSE	4 / 4	
F9B	GIRATORY BEACON FUSE	4 / 5	
H7	HORN	4 / 0	
H7.1	HORN	4 / 0	
K7	HORN RELAY	4 / 0	
M3.1	REAR WIPER MOTOR	4 / 1	
M4.1	PUMP WASHER REAR	4 / 1	
S3.1	REAR WIPER SWITCH	4 / 1	
S36	GIRATORY BEACON SWITCH	4 / 5	
S6.1	FRONT WORKING LIGHTS SWITCH	4 / 4	
S6.2	REAR WORKING LIGHTS SWITCH	4 / 5	
X121.1	GIRATORY BEACON PLUG	4 / 5	

Ind.	Änd.-Nr./Change-No	Datum/Date	Name	Bearb./Abt./written department	03350
04					
04				Bearb./Written	04.08.00 SIK
02				Gepr./Checked	
01				Norm/St.Check	

958	32	050	50
Typ	BG	UBG	CH
80WKZ W80H			

Orenstein & Koppel Aktiengesellschaft

Benennung/Description

WIRING DIAGRAM
PARTS DESCRIPTION

Sach-Nr. / Part-No 3004820

A4 | Blatt/Sheet 10 | F.K. D.S.No | 1 Blätter/Sheets

Ers. für / Substitut for | Ers. durch / Substituted

Order the manual at mid-west-tech.com >