# NEW HOLLAND CONSTRUCTION

# LW 50



# OPERATOR'S MANUAL

73179333.04
December, 1999

NEW HOLLAND

Reprinted

MidWestTech | New Holland LW 50 Wheel Loader Operator's Manual | Publication 73179333 Order the manual at mid-west-tech.com >

## PART 2 - OPERATION


**OPERATION - SAFETY INSTRUCTIONS** ..... 13

**DESCRIPTION OF THE MACHINE**

Layout of the machine ..... 15
Basic unit ..... 16
Chassis ..... 16
Drive unit ..... 16
Axles ..... 16
Brakes ..... 16
Hydraulic system ..... 16
Electrical system ..... 16
Working equipment ..... 16
Noise and vibration levels ..... 17
Noise level outside the machine ..... 17
Noise level at the operator's ear ..... 17
Vertical vibration level at the operator's seat ..... 18
Vibration level at hands and arms ..... 18
CE Mark ..... 18

**STABILITY**

Centre of gravity position during transport ..... 19
Rated load at stability limit ..... 20

**SIGNS**

Warning and instruction signs ..... 21
Machine number ..... 23
Engine number ..... 23
Axle number ..... 23
Travel pump number ..... 23
Travel motor number ..... 23
Attachments ..... 23

**DRIVER'S CAB**

Entering and leaving the machine - Safety instructions ..... 24

**Driver's cab door**

Opening the door ..... 25
Closing the door ..... 25
Sliding window ..... 25
Emergency exit ..... 26
Documentation ..... 26

**Adjustment of driver's cab**

Setting of weight-dependent suspension ..... 27


MidWestTech | New Holland LW 50 Wheel Loader Operator's Manual | Publication 73179333 Order the manual at mid-west-tech.com >

Adjustment of position ..... 27
Backrest ..... 27
Adjustment of seat inclination ..... 27
Height adjustment of seat ..... 27

**WARNING, CONTROL AND MONITORING ELEMENTS**
Driver's stand, overall layout ..... 29

**Warning and control elements** ..... 30

**Switches and pushbuttons** ..... 34

**Monitoring elements and pedals**
Monitoring elements ..... 37
Pedals ..... 37

**Hand levers and other equipment** ..... 38

**PUTTING THE MACHINE INTO OPERATION** ..... 40

**Refuelling**
Refuelling - Safety instructions ..... 40
Refuelling ..... 40

**Electrical system key-switch**
Starting and stopping the engine ..... 41
Starting ..... 41
Engine does not start ..... 42
Stopping the engine ..... 42

**Heating and ventilation**
Ventilation ..... 43
Heating ..... 44
Fan ..... 44

**Signal horn, direction indicator and main beam** ..... 45

**Cab interior lighting** ..... 46

**Front screen wiper / washer** ..... 46

**Rear screen wiper / washer** ..... 47

**Cigarette lighter / Socket outlet** ..... 47

**DRIVING**
Driving - Safety instructions ..... 48

**Adjustment of steering column**
Steering column - Safety instructions ..... 49

MidWestTech | New Holland LW 50 Wheel Loader Operator's Manual | Publication 73179333 Order the manual at mid-west-tech.com >