NEW HOLLAND CONSTRUCTION

EC240



73183065
FEBRUARY 2001

OPERATOR'S MANUAL

NEW HOLLAND

Reprinted

MidWestTech | New Holland EC240 Crawler Excavator Operator's Manual | Publication 731... Order the manual at mid-west-tech.com >

Applying the superstructure holding brake 77
Releasing the superstructure holding brake 77
Swing; changing the mode of operation 78
Superstructure holding brake - emergency operation 79

Working with backhoe or grab equipment (SAE-control)
Raising and lowering boom 81
Extending and retracting stick 81
Swing superstructure 81
Filling and emptying backhoe 81
Opening and closing grab 81
Rotating grab 81
Activate the Power assist function 81
Activate the Power Boost function 81
Activate the horn 81
Power assist, function 82
Switching the power assist on 82
Switching the power assist off 82
Power Boost, function 83
Switching the Power Boost function on 83

Operating methods 84

Working operation in case of PCS failure
Switching the proportional valve over to emergency operation 86

After daily operation
Shutting off the machine 87

WORKING EQUIPMENT 88

Assembling working equipment - safety instructions
Protective roof against falling objects 89

Securing the machine 89

Attaching and detaching the grab equipment
Attaching and detaching the grab equipment - Safety instructions 90
Attaching the grab 90
Detaching the grab 91
Selecting the backhoe / grab equipment 92

Detaching / attaching the backhoe bucket 93

Corrosion protection for pins and bearings (bushings and hubs)
Part nos. for Voler A.C. 94
Application of Voler A.C. 94

MidWestTech | New Holland EC240 Crawler Excavator Operator's Manual | Publication 731... Order the manual at mid-west-tech.com >

HYDRAULIC HAMMER 96

Working with the hydraulic hammer, safety instructions 96

Working with a hydraulic hammer

Switching on the hydraulic hammer 97

Switching off the hydraulic hammer 97

SCRAP SHEARS 98

Working with scrap shears, safety instructions 98

Working with scrap shears

Switching on the scrap shears 99

Switching off the scrap shears 99

LIFTING-GEAR OPERATION 100

Lifting-gear operation - safety instructions 100

Loading hooks on backhoe buckets and couplers

Loading hook capacity 101

Excavator load capacity 101

Overload warning system

Function of overload warning system 102

Activating overload warning system 102

Testing the overload warning system 103

Deactivating overload warning system 103

Pipe-fracture safety system, function 104

OPTIONAL EQUIPMENT

Rotary beacon 105

Switch rotary beacon ON 105

Switch rotary beacon OFF 105

Switching on the floodlamps at the rear of the cab 106

Radio 107

Refuelling system

Refuelling with the refuelling system, safety instructions 108

Refuelling with the refuelling system 109

Driver's seat - adjusting the lumbar support

Adjusting the lumbar support 110

Driver's seat with pneumatic suspension and integrated heating

Adjusting the pneumatic suspension 111

Fore-and-aft adjustment 111

Adjusting the seat cushion 111

MidWestTech | New Holland EC240 Crawler Excavator Operator's Manual | Publication 731... Order the manual at mid-west-tech.com >

Adjusting the backrest 111
Adjusting the armrests 111
Adjusting the lumbar support 112
Switching on the seat heating 112
To switch on the seat heating: 112
To switch off the seat heating: 112

Multi-position boom

Description of multi-position boom 113
Working with the multi-position boom 113
Lowering boom upper section 113
Raising boom upper section 113
Transporting the machine with multi-position boom 113

Air conditioner

Switching the air conditioner on / off 114

KEYBOARD, FURTHER FUNCTIONS

Service (key 16), function 115
Display (key 18), function 116
To indicate the engine revolutions 116
To indicate the time of day 116
Display, setting the contrast 117
Setting the time 118
Immobilizer, deactivate / activate 119

MidWestTech | New Holland EC240 Crawler Excavator Operator's Manual | Publication 731... Order the manual at mid-west-tech.com >