NEW HOLLAND CONSTRUCTION

LW80.B



OPERATOR'S MANUAL

73183076.00
FEBRUARY 2001

Reprinted

NEW HOLLAND

MidWestTech | New Holland LW80.B Wheel Loader Operator's Manual | Publication 73183... Order the manual at mid-west-tech.com >

PART 1 - INTRODUCTION

PREFACE

After-Sales-Service 3

Warnings and symbols 4

Designated use 4

Organizational measures 5

Selection and qualification of personnel 6

OPERATING, SAFETY INSTRUCTIONS

Standard operation 6

MAINTENANCE, SAFETY INSTRUCTIONS 7

WARNING OF SPECIAL DANGERS

Electric energy 8

Gas, dust, steam and smoke 8

Hydraulic and pneumatic equipment 9

Noise 9

Oil, grease and other chemical substances 9

TRANSPORTING AND TOWING - RECOMMISSIONING 9

MidWestTech | New Holland LW80.B Wheel Loader Operator's Manual | Publication 73183... Order the manual at mid-west-tech.com >

PART 2 - OPERATION

OPERATION - SAFETY INSTRUCTIONS 13

DESCRIPTION OF THE MACHINE

Layout of the machine 16
Basic unit 17
Chassis 17
Drive unit 17
Axles 17
Brakes 17
Hydraulic system 17
Electrical system 17
Working equipment 17

Noise and vibration levels

Noise level outside the machine 18
Noise level at the operator's ear 18
Vertical vibration level at the operator's seat 18
Vibration level at hands and arms 18
CE Mark 19

STABILITY

Centre of gravity position during transport 20
Rated load at stability limit 21

Warning and instruction signs

Machine number 24
Engine number 24
Axle number 24
Travel pump number 24
Travel motor number 24
Attachments 24

DRIVER'S CAB

Entering and leaving the machine - Safety instructions 25

Driver's cab door

Opening the door 26
Closing the door 26
Fold-down window 26
Emergency exit 27
Documentation 27
Cab interior lighting 28
Roller blind 28

Adjusting the operator's seat

MidWestTech | New Holland LW80.B Wheel Loader Operator's Manual | Publication 73183... Order the manual at mid-west-tech.com >

Adjusting the weight-oriented suspension 29
Weight adjustment 29
Height adjustment 29
Fore-and-aft adjustment 30
Backrest adjustment 30
Adjusting the right armrest 31
Height adjustment 31
Fore-and-aft adjustment 31

WARNING, MONITORING AND CONTROL ELEMENTS 32

Driver's stand, overall layout 33

Warning and control lamps 34

Switches and pushbuttons 38

PUTTING THE MACHINE INTO OPERATION 42

Refuelling
Refuelling - Safety instructions 42
Refuelling 42

Electrical system ON / OFF
Battery main switch 43

Immobilizer 43

Electrical system key-switch
Starting and stopping the engine 44
Starting 44
Engine does not start 45
Stopping the engine 45

Ventilation and heating
Ventilation 46
Heating 47
Fan 47

Horn, travel direction indicator, main beam and windscreen wiper / -washer 48

Lighting 50

Rear screen wiper / washer 50

Cigarette lighter / Socket outlet 51

DRIVING 51

Driving - Safety instructions 51

MidWestTech | New Holland LW80.B Wheel Loader Operator's Manual | Publication 73183... Order the manual at mid-west-tech.com >