OPERATOR'S MANUAL

Excavator Crawlers EC35



NEW HOLLAND
CONSTRUCTION

MidWestTech | New Holland EC35 Crawler Excavator Operator's Manual | Publication 7318...

Order the manual at mid-west-tech.com >

1 Introduction 1

1.1 General 1
1.2 Warranty and Maintenance 2
1.3 Notes on using the operator's manual 2
1.4 Environmental standards 3
1.5 Symbols 3
1.6 Copyright 5

2 Safety and prevention of accidents 6

2.1 Introductory remarks 6
2.2 Proper use 6
2.3 General safety notes 7
2.4 Operation 7
2.5 Danger zone 8
2.6 Transport of persons 8
2.7 Stability 8
2.8 Travel operation 9
2.9 Operation 9
2.10 Guides 10
2.11 Danger of falling objects 10
2.12 Working in the vicinity of underground power lines 10
2.13 Working in the vicinity of overhead power lines 11
2.14 Operation in closed rooms 11
2.15 Work stoppages 11
2.16 Crane operations 12
2.17 Change of work attachments, maintenance, repair 12
2.18 Recovery, loading, transportation 13
2.19 Monitoring and inspections 14
2.20 Fire protection 14
2.21 Emergency exit 14
2.22 Other dangers 14

3 Technical data 16

3.1 Views 16
3.2 Engine 19
3.3 Electrical system 19
3.4 Travel mechanism 19
3.5 Hydraulic system 21
3.6 Lubricants 22
3.6.1 Filling quantities 22
3.6.2 Fuel, lubricant and coolant specifications 23
3.7 Specific ground pressure 24
3.8 Sound level values 24
3.9 Dimensions and weights 24
3.10 Carrying capacities 25
3.11 Working envelope for grab operations 26
3.12 Work attachments 27
3.13 Optional equipment 27

MidWestTech | New Holland EC35 Crawler Excavator Operator's Manual | Publication 7318... Order the manual at mid-west-tech.com >

Table of contents

4 Operation 29

4.1 First commissioning 29
4.2 Display elements and operator controls 30
4.3 Engine 32
4.3.1 Starting the engine 32
4.3.2 Monitoring during operation 33
4.3.3 Switching off the engine 33
4.4 Driver's seat 34
4.5 Heating / Ventilation 34
4.5.1 Heating 34
4.5.2 Ventilation 34
4.6 Front window 35
4.7 Driving and steering 36
4.8 Rubber crawler chains 37
4.7 Parking the machine 38

5 Working operation of the machine 39

5.1 General 39
5.2 Actuating the work functions 40
5.2.1 Actuating the work equipment 40
5.2.2 Actuation - Articulation 40
5.2.3 Actuation - Dozer blade 41
5.2.4 Actuation - Additional control circuit 41
5.3 Changing work attachments 42
5.3.1 General 42
5.3.2 Assembly of work attachments 43
5.3.3 Clamshell grab 44
5.3.4 Hydraulic rock breaker 45
5.4 Removing the cab 46

6 Recovery and transport of the machine 47

6.1 Recovery of the machine 47
6.2 Loading the machine by use of a crane 47
6.3 Transport of the machine 48

7 Care and maintenance 49

7.1 General notes 49
7.2 Inspection parts and aids 50
7.3 Care and cleaning 51
7.4 Notes for winter operation 51
7.5 Work before putting into operation 52
7.5.1 Checking the engine oil level 52
7.5.2 Cooling system 52
7.5.3 Hydraulic oil level 52
7.5.4 Fuel level 53
7.5.5 Windscreen wash/wipe system 53
7.5.6 Oil level of the crawler gear unit 54
7.5.7 Tension of crawler chains 54
7.5.8 Electrical equipment 54

MidWestTech | New Holland EC35 Crawler Excavator Operator's Manual | Publication 7318... Order the manual at mid-west-tech.com >

7.6 Inspection and maintenance work ... 55
7.6.1 Changing the engine oil ... 55
7.6.2 Engine oil filter ... 55
7.6.3 Fuel system ... 56
7.6.4 Air filter and air intake ... 57
7.6.5 Water radiator ... 59
7.6.6 Cleaning the hydraulic oil radiator ... 60
7.6.7 Checking the V-belts ... 61
7.6.8 Checking the valve lash ... 62
7.6.9 Battery ... 63
7.6.10 Hydraulic oil ... 64
7.6.11 Hydraulic oil return line filter ... 65
7.6.12 Hydraulic oil tank - ventilation filter ... 65
7.6.13 Oil change in crawler gear unit ... 66
7.6.14 Tension of crawlers ... 67
7.6.15 Swing connection ... 68
7.7 Maintenance and inspection plans ... 70
7.7.1 Daily and weekly tasks ... 70
7.7.2 Overview of lubricating points ... 72
7.7.3 Inspection plan ... 74
7.8 Shutdown ... 76
7.8.1 Preservation (temporary shutdown) ... 76
7.8.2 During shutdown ... 76
7.8.3 After shutdown ... 76

8 Operating problems ... 77

8.1 General ... 77
8.2 Engine ... 77
8.3 Machine is not driving ... 77
8.4 Insufficient travel power ... 77
8.5 Excavator equipment is not working ... 78
8.6 Decrease in machine's performance ... 78
8.7 Machine is working too slowly and hydraulic oil is becoming too hot ... 78
8.8 Uppercarriage is swinging too far ... 78
8.9 Working cylinders are not working satisfactorily ... 79
8.10 Trouble in the electrical system ... 79

9 Appendix ... 81

9.1 Electrical system ... 81
9.2 Hydraulic system ... 86

Order no.
Vehicle identity no.
Date of printing 12/99

MidWestTech | New Holland EC35 Crawler Excavator Operator's Manual | Publication 7318... Order the manual at mid-west-tech.com >