689G Telescopic Handler

Parts Catalog

Bur 7-4371

Order the manual at mid-west-tech.com >

GENERAL INFORMATION

Indexes

Section 1 of this catalog contains a SN and P.I.N. location guide, alphabetical index, pictorial index of the sections included, and pictorial index(es) for quick location of hoses and tubes (and other system components in some catalogs). An alphabetical index also appears at the beginning of each section. Section 10 is the Numerical Index which lists all part numbers in alpha/numeric order with their page location and reference number.

Illustrations

The arrangement of this parts catalog is for easy identification of parts. All parts are illustrated in "exploded views" in proper relation to each other. Reference numbers used in the illustrations refer to those on the text pages. The text pages list reference number, part number, part description and the quantity required.

Abbreviations

P.I.N. "Product Identification Number"

SN "Serial Number"

NSS "Not Serviced Separately" in the part number column indicates this part is not available for service.

REF "Reference" in the part number column indicates this part has special service information. The page where this information can be found is given in the part description column.

UAR "Use As Required" in the quantity required column indicates the number of parts used is determined by service needs.

Right-Hand and Left-Hand Identification

The reference to right-hand and left-hand in this catalog is identified by the operator standing at the rear of the basic unit (without rear attachment), looking toward the front of the machine (in normal forward travel). For pages covering any machine attachments, right-hand and left-hand are defined by the operator sitting in the position for proper operation of the attachment.

Catalog Revisions and Supplements

Changes to the product may make it necessary to revise or add pages to this catalog. A cover sheet will list all pages released in a revision or supplement. Each new or revised page will have a new issue date. All revised and new pages must be put into the parts catalog as soon as they are received.

Parts Orders

Orders must specify product model, all necessary serial numbers, correct part number, complete description, quantity required, method of shipment, and shipping address.

Text Format Explanation

An assembly may contain service items. The component parts of an assembly or subassembly are indented. The quantity required column lists the number of assemblies required for a completed machine, and the number of components required in a complete assembly or subassembly.

The example below illustrates the use of indents and other text page elements explained on this page.

HYDRAULIC FILTER

REF.	PART NO.	DESCRIPTION	REQ'D.
1	D4356734	FILTER ASSEMBLY - hydraulic oil, P.I.N. 7534840 and after	1
	D61903	HEAD ASSEMBLY - filter	1
2	NSS	HEAD - filter, order D61903 head assembly	1
3	D58199	VALVE - bypass	1
	D43800	KIT - filter element, replaces D35700 element kit	1
4	NSS	ELEMENT - filter, order D43800 element kit	1
5	A27994	O-RING - filter	1
6	D61948	HOUSING -filter	1
7	REF	CANOPY - ROPS, order from Machinery Price List	1
8	843065C1	HOSE - 3353 mm (132 inch) long, reservoir to pump	1
9	113-323	BOLT - hex, 7/16 NC x 1-3/4 inch	2
10	814-8030	BOLT - hex, 8 - 1.25 x 30 mm	4

MidWestTech | Case 689G Telescopic Handler Parts Catalog | Publication 7-4371 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Accumulator -Hydraulic 4-11
Adapting Parts - Engine 2-3
Air Cleaner System 2-7,2-9
Air Intake Parts 2-7
Air Restriction Indicator 2-7
Alarm - Backup 4-9
Alternator and Mounting 4-15
Arm - Stabilizer 8-35
Auxiliary Hydraulics 8-29
Axle ..... 6-17 - 6-27
  Cylinder - Leveling 6-13,6-15
  Cylinder - Steering 6-27
  Differential 6-17,6-19
  Drive Shaft 6-29,6-31
  Housing 6-21
  Housing - Swivel 6-21
  Joint - Universal 6-21
  Lube Line 6-13
  Mounting 6-11
  Planetary 6-23,6-25
  Ring and Pinion Gear 6-17
  Shafts - Half 6-21
  Tie Rod Joints 6-21

B

Backup Alarm 4-9
Basic Hydraulic Circuit 8-9
Batteries and Mounting 4-3
Battery Cables 4-3
Belt - Fan 2-43
Belt - Seat 9-9
Block - Cylinder 2-25
Boom ..... 9-15 - 9-27
  Inner 9-21
  Intermediate 9-19
  Outer 9-17
Boom Chain 9-27
Boom Circuit - Hydraulic
  Compensating 8-21
  Controller to Main Control Valve 8-27
  Cylinder Lines 8-15,8-17
  Extension 8-15,8-17
Boom Cylinder, Lift 9-15
Boom Extension Cylinder 9-23
Boom Tilt Cylinder 9-29
Brake
  Hydraulic Circuit and Lines 7-5
  Linkage 7-3
  Parking 4-11,7-7
  Pedal 7-3
  Valve 6-9,7-3
Buckets 9-39

C

Cab
  Door 9-13
  Fan-Defroster 4-39,4-51
  Washer - Windshield 4-45
  Windows and Seals 9-13
  Wipers - Windshield and Rear Window 9-13
Cables-Battery 4-3
Camshaft and Gear 2-33
Cap - Fuel Tank 3-3B
Cap - Radiator 2-11
Carriages 9-39
Chain - Boom 9-27
Charging Pump - Transmission 6-49
Chassis Harness 4-7
Circuits - Basic Hydraulic ..... 8-79 - 8-13
Cluster - Instrument 4-17
Column - Steering 5-3
Cooler Hydraulics 8-3
Connecting Rods 2-39
Console
  Covers 4-5,4-17,9-5
  Harness and Lamps 4-17
Controls
  Auxiliary Hydraulic 8-29
  Parking Brake 7-7
  Transmission 6-3,6-5
  Throttle 3-5,3-7
Control Valves
  Brake 6-9,7-3
  Main ..... 8-45 - 8-53
  Steering 5-3,5-9
Coolant Overflow Reservoir 2-11,2-3B
Cooler - Engine Oil 2-31
Cooling System - Hydraulic 2-11,8-3
Covers
  Covers - Boom End 9-7
  Cylinder Head 2-29
  Floor 9-5
  Frame - Main 9-3
  Timing and Front Gears 2-23
Crankshaft 2-35
Cylinder Block 2-25
Cylinder Head 2-21
Cylinder Head Cover 2-29
Cylinders - Hydraulic
  Axle Leveling 6-13
  Boom Lift 9-15
  Carriage Tilt 9-29
  Compensating 9-15
  Stabilizer 8-35
  Steering 6-27
  Telescopic Crowd 9-23

MidWestTech | Case 689G Telescopic Handler Parts Catalog | Publication 7-4371 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

D

Decals....9-41 - 9-45
Defrost Fan....4-39,4-51
Differential - Axle....6-17,6-19
Dipstick....2-41
Dome Lamp....4-41
Door - cab....9-13
Drive Shaft - Axle....6-29 ,6-31

E

Electrical Circuits and Components
- Alarm - Backup....4-9
- Alternator....4-15
- Battery and Cables....4-3
- Defroster Fan....4-39,4-51
- Dome Lamp....4-41
- Fuses....4-5,4-37 - 4-45
- Gauges....4-17
- Harness
  - Chassis....4-7
  - Console....4-17
  - Defroster....4-39
  - Engine....4-7
  - Heater....4-37
  - Instrument Panel....4-7
  - Turn Signal and Flasher....4-25,4-31
  - Work Lamp....4-19
- Heater....4-37
- Horn and Relay....4-5,4-47,4-49
- Ignition Switch....4-5
- Instrument Panel....4-5,4-17
- Lamp
  - Console....4-17
  - Dome....4-41
  - Signal and Flasher....4-27,4-29,4-33,4-35
  - Work....4-21,4-23,4-33,4-35
- Switches
  - Ignition....4-5
  - Lamp - Work....4-19,4-31
  - Parking Brake....4-11
  - Pressure....4-11
  - Turn Signal and Flasher....4-31
- Starter....4-15
- Senders
  - Air Filter Restriction....2-7
  - Fuel Level....3-3B
  - Oil Pressure....4-13
  - Temperature - Transmission....4-13
  - Temperature - Water....4-13
- Windshield Washer....4-45
- Wipers....4-43,9-13

E

Engine and Fuel Injection Components
- Adapting Parts - Engine....2-3
- Air Cleaner....2-7,2-9
- Air Restriction Indicator....2-7
- Belt - Fan....2-43
- Block - Cylinder....2-25
- Camshaft and Gear....2-33
- Connecting Rods....2-39
- Coolant Overflow Reservoir....2-11,2-11B
- Cooler - Engine Oil....2-31
- Cover - Cylinder Head....2-29
- Covers - Front and Timing Gear....2-23
- Crankshaft....2-35
- Cylinder Block....2-25
- Cylinder Head....2-21
- Cylinder Head Cover....2-29
- Dipstick....2-41
- Exhaust Manifold....2-17
- Exhaust System....2-5
- Exhaust Valve....2-21
- Fan and Belt....2-43
- Filter - Engine Oil....2-31
- Flywheel and Housing....2-27,2-35
- Fuel Filter....3-15,3-19
- Fuel Injection Nozzle....3-9
- Fuel Injection Pump and Drive....3-9
- Fuel Lines....3-3,3-9 - 3-13,3-19,3-21
- Fuel Pump - Lift and Transfer....3-17
- Head - Cylinder....2-21
- Idler Gear and Cover....2-23
- Intake Valve....2-21
- Manifolds -Intake and Exhaust....2-15,2-17
- Muffler....2-5
- Oil Cooler....2-31
- Oil Filler Cap....2-29
- Oil Filter and Cooler....2-31
- Oil Pan....3-41
- Oil Pump....2-37
- Pistons and Connecting Rods....2-39
- Pump - Oil....2-37
- Pump - Water....2-13
- Push Rods....2-19
- Radiator....2-11
- Rings - piston....2-39
- Rocker Arms....2-19
- Sleeves - Cylinder....2-25
- Thermostat and Housing....2-13
- Turbocharger....2-15
- Valves - Intake and Exhaust....2-21
- Valve Mechanism....2-19
- Water Pump System....2-13

Engine Mounting....2-3

MidWestTech | Case 689G Telescopic Handler Parts Catalog | Publication 7-4371 Order the manual at mid-west-tech.com >