OPERATOR'S MANUAL

Wheel Loaders LW90 - LW110 - LW130 - LW130TC



Reprinted

NEW HOLLAND
CONSTRUCTION

MidWestTech | New Holland LW90, LW110, LX130, LW130TC Wheel Loader Operator's Ma...

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

TITLE	PAGE
Safety rules	I-VII
To the owner	VIII
Safety components	1
Identification data	2
Machine identifications plates	3
Stability	4
Noise and vibration levels	5
Safety plates and their locations of the machine	7
Preliminary instructions and run-in period	10
Operating instructions	11
Instrument panel	12
Warning and indicator lights	13
Keystart switch	15
Control switches	16
Controls	18
Cab	26
Driver's seat adjustment	28
Fire protection	28
Cab heating and ventilation	29
Windscreen wiper	30
Safety belt	31
Accessories	31
Radio	32
Auxiliary 12V power socket	33
Outer 24V power sockets	33
Maintenance access panels	34
Automatic bucket return-to-dig system	35
Maximum boom height control system	35
Precautions for operation in cold weather	36
Prolonged machine storage	36
Moving the machine	37
Towing	38
Transporting the machine	39
Safety when maneuvering	43
Road transfers	47
Run-in period	49
Before starting the engine	49
Pre-start checks	49
Instructions for the starting and stopping of the loader	50
Loader operation	53
Equipment	58
Periodical inspections	61
Maintenance and filling chart	62
Maintenance points	63
Fuel system	64
Alternator and fan belts	66
Transmission	66
Hydraulic system	67
Axles	69
Batteries	69
Greaser points	70
Tires	72
Cab air cleaner	73
Fuses	73
Troubleshooting chart	75
Specifications	79
LW130 TOOL CARRIER	82
Mantenance operations "TOOL CARRIER" Equipment	88
Monthly inspections	89
Machine groups electric diagrams	91

MidWestTech | New Holland LW90, LW110, LX130, LW130TC Wheel Loader Operator's Ma... Order the manual at mid-west-tech.com >