OPERATOR'S MANUAL

LW230
Wheel Loader



75131029

MidWestTech | New Holland LW230 Wheel Loader Operator's Manual | Publication 751310...

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

TITLE	PAGE
Safety rules	I-VIII
Identification data	1
Stability	2
Noise and vibration levels	3
Safety plates and their locations on the machine	4
Safety components	8
Preliminary instructions and run-in period	9
Operating instructions	10
Instrumental panel	11
Warning and indicator lights	12
Keystart switch	14
Control switches	15
Controls	17
Cab	23
Driver's seat adjustement	25
Fire protection	25
Cab heating and ventilation	26
Windscreen wiper	27
Safety belt	28
Radio	29
Auxiliary 12 V power socket	30
Outer 24 V power sockets	30
Precautions for operation in cold weather	31
Prolonged machine storage	31
Moving the machine	32
Removal of the bucket	32
Towing	33
Travelling with chain	34
Transporting the machine	34
Measures to be taken in case of emergency	35
Exhausted batteries	35

TITLE	PAGE
Releasing the parking brake	37
Safety when manoeuvring	38
Road transfers	42
Run-in period	47
Before starting the engine	47
Pre-start checks	47
Starting the engine	48
Driving the loader	49
Stopping the loader	50
Instructions to lower the attachment to the ground with the engine off	51
Loader operation	52
Maintenance	62
Tools	64
Access panels for maintenance operations	65
Position of filling plugs/caps	66
Main greasing points	67
Fluid capacity and maintenence interventions tables	68
Every 10 working hours	70
Every 50 working hours	73
Every 250 working hours	75
Tires and wheels	81
Every 500 working hours	82
Every 1000 working hours	86
Every 2000 working hours	92
Variable periodic operations	96
Fuses	96
Specifications	99
Troubleshooting chart	100
Machine groups electric diagrams	105

MidWestTech | New Holland LW230 Wheel Loader Operator's Manual | Publication 751310... Order the manual at mid-west-tech.com >