NEW HOLLAND

MOTOR GRADER

G140

OPERATOR'S MANUAL

75314441 NA

Issued 11-2005

NEW HOLLAND

www.newhollandconstruction.com

MidWestTech | New Holland G140 Motor Grader Operator's Manual | Publication 75314441...

Order the manual at mid-west-tech.com >

INDEX

Safety rules 8
Symbology 12
Identification data 21
Technical data 22
Main dimensions 25
Preliminary instructions 27
Run-in period 30
Hand signals 31
Operator's compartment 34
Controls and instruments 35
LH lift cylinder control lever 35
Ripper control lever 35
Blade side displacement control lever 35
Blade tilt control lever 35
Circle rotation control lever 35
Headlights control lever 36
Electronic monitor 36
Optional differential lock 38
Gear and diagnosis indicator 39
Steering wheel tilt knob 39
Inching pedal 39
Console tilt pedal 39
Brake pedal 39
Accelerator and decelerator pedal 39
Circle side desplacement control lever 39
Machine articulation control lever 39
Wheel lean control lever 40
Blade raise lever 40
Alert sign 40
Fuse box 40
Throttle control lever 40
Gear selector lever 41
Switch board 41

MidWestTech | New Holland G140 Motor Grader Operator's Manual | Publication 7531... Order the manual at mid-west-tech.com >


INDEX

Electronic instrument cluster 43
Master battery switch 43
Auxiliary power outlet 43
Starter switch 43
Air conditioning 44
Parking brake 46
Cab 46
Seat adjustment 46
Preliminary inspection 48
Operation 49
- Engine starting 49
- Engine stopping 49
- Engine speed changes 49
- Towing 50
- Cutting a slope 53
- Scarifying 53
- Stopping the machine 53
- Typical operations 55

Maintenance 58
- General note 58
- Lubrification and service guide 59
- Lubricant specifications 61
- Key to tipe and grade of lubricants 65
- Every 10 operating hours 64
- Every 50 operating hours 65
- Every 100 operating hours 66
- Every 250 operating hours 67
- Every 500 operating hours 69
- Every 1000 operating hours 72
- Every 2000 operating hours 73
- Periodics services 74
- Electrical schematic 83

MidWestTech | New Holland G140 Motor Grader Operator's Manual | Publication 7531... Order the manual at mid-west-tech.com >

MAIN DIMENSIONS



DIMENSIONS

A.	Blade width	12' 0"	(3658 mm)
B.	Distance outside tires	8' 3"	(2510 mm)
C.	Distance between tire centres	7' 0"	(2134 mm)
D.	Maximum machine height	10' 11.5"	(3340 mm)
E.	Height to the top of the exhaust	10' 10.8"	(3323 mm)
F.	Height to top of blade cylinder	10' 0"	(3047 mm)
G.	Stationary tire radius	2' 0"	(610 mm)
H.	Distance from tandem axle to frame articulation pivot	6' 5"	(1958 mm)
I.	Blade base	8' 5"	(2562 mm)
J.	Distance between tandam axles	5' 2"	(1594 mm)
K.	Distance between tandem center and wheels	2' 7"	(797 mm)
L.	Distance between wheels	20' 5"	(6219 mm)

MidWestTech | New Holland G140 Motor Grader Operator's Manual | Publication 7531... Order the manual at mid-west-tech.com >

OPERATOR´S COMPARTMENT

3 - WHEEL ANGLE CONTROL LEVER

The front wheel angle control lever, tilts the wheels to the left or to the right, thereby maintaining the stability to dump or dig, and to facilitate or decrease the machine´s turning radius. Move the lever forward to tilt the wheels to the left or to the rear to tilt the wheels to the right. After reaching the desired position, release the lever and will return to neutral.

4 - BLADRAIAR ISE LEVER

Use this lever to raise or lower the right end of the blade. Move the lever forward to lower or to the rear to raise. After reaching the desired height, release the lever and it will return to neutral.


5 - WARII G BUZZER

Operate this buzzer whenever the machine is in hazardous situations.



GROUP 4

Fuse box, hand throttle control lever, transmission control lever, switch panel, instrument panel (electronic), master battery switch, power outlet and ignition switch.




1- Fuse box
2- Hand throttle control lever
3- Transmission control lever
4- Switch panel
5- Instrument cluster (electronic)
6- Master battery switch
7- Power outlet
8- Ignition switch
9- Transmission inspection points

1 - FUSE BOX

The fuse box houses all machine fuses, as shown below.
For proper identiication of the location of each fuse, check the electrical wiring diagram (A).



2 - HAND THROTTLE CONTROL LEVER



Engine speed will be low with the throttle lever all the way to the rear and high with the lever all the way forward.

MidWestTech | New Holland G140 Motor Grader Operator's Manual | Publication 7531... Order the manual at mid-west-tech.com >


MAINTENANCE

1- Water pump pulley
2- Engine flywheel pulley
3- 1/2" (13 mm) square hole
4- Belt tensioner
5- Alternator

Measure belt deflection midway between the longest span between the pulley.
Maximum allowable deflection is 9,5 to 12,7mm (3/8 to 1/2").
Remove the belt using a 1/2" square socket handle.

CHECKING BELT AND TENSIONER

After removing the belt check belt carefully for damage.




BELT TENSIONER

A belt tensioner pulley must be able to turn freely, without any point showing any resistance, sticking, etc., when turned by hand. Check condition of the belt tensioner bearing.


REINSTALLING THE BELT

Using a 1/2" socket handle and acting on the tensioner slot, fit the belt checking carefully that the poly-V ribs properly engage the existing grooves in the alternator pulley and vibration damper.



EVERY 500 OPERATING HOURS

19- FUEL FILTERS
Change



Fuel filter

Thoroughly clean the area around the fuel filters head, 1 and 2.

Remove filters and thoroughly clean the filter head gasket mating furface.

Replace the filter and sealing rings. Fill fuel filter and lubricate the sealing rings with new engine oil.

MidWestTech | New Holland G140 Motor Grader Operator's Manual | Publication 7531... Order the manual at mid-west-tech.com >

INSTRUÇÕES DE OPERAÇÃO / QUICK OPERATION INSTRUCTIONS



Chave de Ignição (Key switch) Chave geral (Master switch)

Dar partida no motor:
a)Alavanca de marcha em neutro e acelerador em marcha lenta.
b)Ligar a chave geral.
c)Dar partida na chave de ignição.


Engine starting
a)Gear selector lever in neutral position and throttle lever at low position.
b)Turn on master switch.
c)Turn on key switch.




Alavanca de marchas (Gear selector lever):

Movimentar a máquina:
a)Acionar o pedal da embreagem.
b)Soltar o freio de mão.
c)Levantar a trava da alavanca de marchas e movimentar a alavanca para frente ou para trás.
d)Soltar o pedal da embreagem lentamente.

To move the machine:
a)Press inching pedal.
b)Release parking brake lever.
c)Lift gear selector lever lock and move the lever to forward or reverse.
d)Release inching pedal slowly.



Pedal da Embreagem (Inching Control Pedal)



Alav. de inclinação das rodas e articulação do chassis:
(Wheel lean control lever and frame articulation lever)
Atenção: Não acionar a alavanca de inclinação das rodas com o parafuso trava montado na barra de inclinação e também a alavanca de articulação chassis com o pino de travamento montado nos chassis.
Warning: Do not move the wheel lean lever with lock bolt locked and do not move the articulation frame lever with the lock pin locked on frames.




Parafuso Trava – Eixo Dianteiro
(Lock Bolt – Front Axle)

Alavanca de Controle da Lâmina:
(Blade Control Lever)
Atenção: Cuidado ao deslocar a lâmina para não danificar a escada / pneus.


Warning: Be careful when moving the moldboard to avoid step / tires damage.






Alavancas de controle da lâmina
(Blade control levers)

Pino travamento chassis
(Frames lock pin)



MidWestTech | New Holland G140 Motor Grader Operator's Manual | Publication 7531... Order the manual at mid-west-tech.com >

MAINTENANCE



Locate the swing motor pinion such as to achieve an engaging position.


Make sure that the center line of the circle turn motor pinión, the center of the circle are aligned.


Supporting one of the sides of the referenced pinion tooth against the side of one circle tooth, act on the front guide radial clearance adjusting bolt to provide a 0.76 mm clearance between the non-supported side of the pinion engaged tooth and the circle tooth. Note that during adjustment of the teeth clearance, the front guide wear plate should rest on the innner race of the circle.

After adjustment of the radial clearance of the front guide is completed and all nuts tightened, adjust the two rear guides to provide a maximum clearance of 0.76 mm between the inner circle race and the guide wear plates (curved), at the adjusting bolts of the wear plates.

Lock adjusting bolts with their lock nuts. Tighten the guide nuts and operate the circle to check for 360° free rotation.


If the circle does not rotate freely, redo the adjusment, by gradually increasing clearance between the sides of the teeth until the specified limit is achieved.







40- CIRCLE CARRIER BAR BALL NUTS
Check



Draw bar ball nuts

Check coupling ball nuts.
Torque to 75 to 91 kgm (540 to 660 lbs.ft).

MidWestTech | New Holland G140 Motor Grader Operator's Manual | Publication 7531... Order the manual at mid-west-tech.com >