585G, 586G, 588G
Forklift

Parts Catalog

7-5443NA

Issued March, 1999
Revised May, 2005

CASE
CONSTRUCTION

MidWestTech | Case 585G, 586G, 588G Forklift Parts Catalog | Publication 7-5443

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-01	RADIATOR - FAN SHROUD
02-02	RADIATOR ASSY
02-03	AIR CLEANER - AIR INTAKE PARTS
02-04	AIR CLEANER ASSY - PRECLEANER ASSY
02-05	MUFFLER - EXHAUST SYSTEM
02-06	COLD START SYSTEM
02-07	ENGINE - MOUNTING
02-08	WATER PUMP SYSTEM, 4-390 EMISSIONS CERTIFIED ENGINE
02-09	FRONT GEAR COVER, 4-390 EMISSIONS CERTIFIED ENGINE
02-10	MANIFOLDS, 4-390 EMISSIONS CERTIFIED ENGINE
02-11	FILTER AND COOLER - OIL, 4-390 EMISSIONS CERTIFIED ENGINE
02-12	OIL PUMP, PAN - HEATER, 4-390 EMISSIONS CERTIFIED ENGINE
02-13	CYLINDER HEAD - COVER, 4-390 EMISSIONS CERTIFIED ENGINE
02-14	CYLINDER HEAD - VALVE MECHANISM, 4-390 EMISSIONS CERTIFIED ENGINE
02-15	CAMSHAFT, 4-390 EMISSIONS CERTIFIED ENGINE
02-16	CYLINDER BLOCK, 4-390 EMISSIONS CERTIFIED ENGINE
02-17	CRANKSHAFT, 4-390 EMISSIONS CERTIFIED ENGINE
02-18	FLYWHEEL AND HOUSING, 4-390 EMISSIONS CERTIFIED ENGINE
02-19	PISTONS - CONNECTING RODS, 4-390 EMISSIONS CERTIFIED ENGINE
02-20	GASKET KIT, 4-390 EMISSIONS CERTIFIED ENGINE
02-21	GASKET KIT, 4-390 EMISSIONS CERTIFIED ENGINE
02-22	GASKET KIT, 4TA-390 EMISSIONS CERTIFIED ENGINE, BASIC SERVICE ENGINE
03-01	FUEL TANK AND LINES
03-02	CONTROLS - THROTTLE
03-03	FUEL INJECTION SYSTEM, 4-390 EMISSIONS CERTIFIED ENGINE
03-04	FUEL FILTER - PUMP, TRANSFER, 4-390 EMISSIONS CERTIFIED ENGINE
03-05	FUEL INJECTION - PUMP AND DRIVE, 4-390 EMISSION CERTIFIED ENGINE
03-06	FUEL INJECTION - NOZZLE, 4-390 EMISSIONS CERTIFIED ENGINE
04-01	ALTERNATOR
04-02	STARTER
04-02A	STARTER
04-03	MOUNTING - STARTER AND ALTERNATOR
04-04	BATTERY - CABLES
04-05	BATTERY, DUAL - CABLES
04-06	FUSE AND FUSE BLOCK - RELAY PANEL
04-07	HARNESS - CHASSIS
04-08	HARNESS - CONSOLE
04-09	COVERS - SWITCH, ROCKER
04-10	LAMPS, TRACTOR CANOPY - INSTRUMENT CLUSTER
04-11	LAMP ASSY, FLOOD
04-12	LAMP ASSY
04-13	ALARM - BACKUP
05-01	STEERING WHEEL - STEERING COLUMN
05-02	HYDRAULICS - STEERING
05-03	PUMP ASSY - STEERING HAND
05-04	STEERING COLUMN
05-05	CYLINDER ASSY - STEERING
05-06	AXLE, REAR - SPINDLES
05-07	HUB AND BEARINGS, REAR WHEEL
05-08	AXLE, REAR (377979A1 / 86990837) - MOUNTING (IF USED)
05-09	AXLE, REAR (377979A1 / 86990837) - HOUSING (IF USED)
05-10	AXLE, REAR (377979A1 / 86990837) - HOUSING, SWIVEL (IF USED)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

05-11	AXLE, REAR (377979A1 / 86990837) - CYLINDER, STEERING (IF USED)
05-12	AXLE, REAR (377979A1 / 86990837) - HUB AND BEARINGS (IF USED)
05-13	WHEELS, REAR
06-01	AXLE, REAR DRIVE - MOUNTING
06-02	AXLE, REAR DRIVE - MOUNTING
06-03	AXLE, REAR DRIVE - HOUSING
06-04	AXLE, REAR DRIVE - HOUSING, SWIVEL
06-05	AXLE, REAR DRIVE - CYLINDER, STEERING
06-06	AXLE, REAR DRIVE - SHAFTS, AXLE
06-07	AXLE, REAR DRIVE - PLANETARY
06-08	AXLE, REAR DRIVE - DIFFERENTIAL
06-09	AXLE, REAR DRIVE - RING AND PINION
06-10	AXLE, REAR DRIVE - HOUSING
06-11	AXLE, REAR DRIVE - HOUSING, SWIVEL
06-12	AXLE, REAR DRIVE - CYLINDER, STEERING
06-13	AXLE, REAR DRIVE - SHAFTS, AXLE
06-14	AXLE, REAR DRIVE - PLANETARY
06-15	AXLE, REAR DRIVE - DIFFERENTIAL
06-16	AXLE, REAR DRIVE - RING AND PINION
06-17	AXLE, REAR DRIVE - HOUSING
06-18	AXLE, REAR DRIVE - HOUSING, SWIVEL
06-19	AXLE, REAR DRIVE - CYLINDER, STEERING
06-20	AXLE, REAR DRIVE - SHAFTS, AXLE
06-21	AXLE, REAR DRIVE - PLANETARY
06-22	AXLE, REAR DRIVE - DIFFERENTIAL
06-23	AXLE, REAR DRIVE - RING AND PINION
06-24	AXLE, REAR - DRIVE SHAFT
06-25	AXLE, REAR - DRIVE SHAFT
06-26	TRANSMISSION COOLING SYSTEM
06-27	TRANSMISSION - MOUNTING
06-28	TRANSMISSION ASSY - FILTER, OIL
06-29	TRANSMISSION ASSY (2WD) - HOUSING
06-30	TRANSMISSION ASSY (4WD) - HOUSING
06-31	TRANSMISSION ASSY - PUMP, OIL
06-32	TRANSMISSION ASSY - SHIFTER MECHANISM
06-33	TRANSMISSION ASSY - SHAFTS, IDLER AND PRIMARY
06-34	TRANSMISSION - ASSY SHAFT, INPUT
06-35	TRANSMISSION ASSY - SHAFT, SECONDARY
06-36	TRANSMISSION ASSY (4WD) - SHAFT, OUTPUT
06-37	TRANSMISSION ASSY - VALVE, CONTROL
06-38	TRANSMISSION ASSY (4WD) - SOLENOID VALVE
06-39	TRANSMISSION ASSY - FILTER, OIL
06-40	TRANSMISSION ASSY (2WD) - HOUSING
06-41	TRANSMISSION ASSY (4WD) - HOUSING
06-42	TRANSMISSION ASSY - PUMP, OIL
06-43	TRANSMISSION ASSY - SHIFTER MECHANISM
06-44	TRANSMISSION ASSY - SHAFT, IDLER AND PRIMARY
06-45	TRANSMISSION ASSY - SHAFT, INPUT
06-46	TRANSMISSION ASSY - SHAFT, SECONDARY
06-47	TRANSMISSION ASSY (4WD) - SHAFT, OUTPUT
06-48	TRANSMISSION ASSY (329081A1, A2, A3 OR 329082A1, A2, A3) - VALVE, CONTROL
06-48A	TRANSMISSION ASSY (87456845 OR 87456846) - VALVE, CONTROL

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

06-49	TRANSMISSION ASSY (4WD) - VALVE, SOLENOID
06-50	AXLE, FRONT - MOUNTING
06-51	AXLE, FRONT - DIFFERENTIAL LOCK
06-52	AXLE, FRONT - DIFFERENTIAL LOCK
06-53	AXLE, FRONT - HOUSING
06-54	AXLE, FRONT - DIFFERENTIAL
06-55	AXLE, FRONT - RING AND PINION
06-56	AXLE, FRONT - DIFFERENTIAL LOCK
06-57	AXLE, FRONT - PLANETARY
06-58	AXLE, FRONT DRIVE - HOUSING
06-59	AXLE, FRONT DRIVE - DIFFERENTIAL
06-60	AXLE, FRONT DRIVE - RING AND PINION
06-61	AXLE, FRONT DRIVE - DIFFERENTIAL LOCK
06-62	AXLE, FRONT DRIVE - PLANETARY
06-63	AXLE, FRONT DRIVE - HOUSING
06-64	AXLE, FRONT DRIVE - DIFFERENTIAL (384952A1 AXLE / 2 SPIDER DIFFERENTIAL)
06-64A	AXLE, REAR DRIVE - DIFFERENTIAL (87422891 AXLE / 4 SPIDER DIFFERENTIAL)
06-65	AXLE, FRONT DRIVE - RING AND PINION
06-66	AXLE, FRONT DRIVE - DIFFERENTIAL LOCK
06-67	AXLE, FRONT DRIVE - PLANETARY
06-68	DRIVE SHAFT, FRONT AXLE
06-69	DRIVE SHAFT, FRONT AXLE
06-70	WHEELS, DRIVE
07-01	AXLE, FRONT - BRAKE, DIFFERENTIAL
07-02	AXLE, FRONT - BRAKE, PARKING
07-03	AXLE, FRONT - DRIVE BRAKE, DIFFERENTIAL
07-04	AXLE, FRONT DRIVE - BRAKE, PARKING
07-05	AXLE, FRONT DRIVE - BRAKE, DIFFERENTIAL
07-06	AXLE, FRONT DRIVE - BRAKE, PARKING
07-07	BRAKE PEDALS - BRAKE MASTER CYLINDER MOUNTING
07-08	HYDRAULICS - BRAKES, MASTER
07-09	CYLINDER ASSY - BRAKE MASTER
07-10	CONTROLS - BRAKE, PARKING
08-01	HYDRAULICS - RETURN LINES
08-02	HYDRAULICS - RESERVOIR TO HYDRAULIC PUMP
08-03	HYDRAULICS - SIDE SHIFT
08-04	HYDRAULICS - FORKLIFT TILT
08-05	CYLINDER ASSY - FORKLIFT TILT
08-06	CYLINDER ASSY - SIDESHIFT
08-07	CYLINDER ASSY - MAST LIFT
08-07A	CYLINDER ASSY - MAST LIFT
08-07B	CYLINDER ASSY - MAST LIFT
08-07C	CYLINDER ASSY - MAST LIFT
08-07D	CYLINDER ASSY - MAST LIFT
08-08	CYLINDER ASSY - MAST LIFT
08-09	CYLINDER ASSY - MAST LIFT
08-10	CYLINDER ASSY - MAST LIFT
08-11	PUMP ASSY, 585G/586G
08-11A	PUMP ASSY, 588G
08-12	HYDRAULICS - LOAD CONTROL
08-13	ACCUMULATOR ASSY
08-14	FILTER ASSY, OIL

Order the manual at mid-west-tech.com >

HARNESS - CONSOLE

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		328892A2		1	HARNESS Console, Used With 328974A2, REF 12
1A		370134A1		1	HARNESS Console, Used With 370132A1, REF 12
2		283779A1		2	OUTLET Power
3		283781A1		2	CAP Plug
4		122740A1		1	SWITCH Horn
5		229364A1		1	SWITCH Cold Start, Ether, If Equipped
6		133715A1		1	SWITCH Rear Work Light
7		133711A1		1	SWITCH Driving Light
8		122736A1		1	SWITCH Flasher Lamp, Hazard
9		131691A1		1	SWITCH Turn Signal
10		283167A3		1	SWITCH Differential Lock
11		133716A1		1	SWITCH 4WD, If Equipped
12		328974A2		1	SWITCH Clutch Cutout Override, Used With 328892A2, REF 1
12A		370132A1		1	SWITCH Clutch Cutout Override, Used With 370134A1, REF 1A
13		126844A1		X	PLUG Switch Hole
		282775A1		1	SWITCH, IGNITION Incl. 14 - 17
14		NSS		1	NOT SERVICED SEPARATELY Switch, Key
15		D137820		1	HARNESS Ignition Switch To Ground
16		NSS		1	NOT SERVICED SEPARATELY Nut, Special, Key Switch Mounting
17		NSS		1	NOT SERVICED SEPARATELY Key, Set Of Two
18		278328A1		1	SWITCH Shuttle Shift, Forward / Neutral / Reverse Switch
19		236521A1		1	HALF COLLAR Shuttle Lever, Incl. Clamp And (2) Nuts
20		397990A1		2	SCREW M5 x 35; Replaces 368238A1 M5 x 30 Screw Used On Some Models, Also Replaces 558-100, Use With Loctite 242
		345-49		X	LOCTITE Loctite, 1 ml
21		515-24222		1	CLAMP 7/8 ID
22		614-10025		1	BOLT M10 x 25
23		892-11010		1	WASHER, LOCK M10
24		829-1410		1	NUT M10; 10.9
25		832-10406		2	NUT M6
26		892-11006		2	WASHER, LOCK M6

MidWestTech | Case 585G, 586G, 588G Forklift Parts Catalog | Publication 7-5443 Order the manual at mid-west-tech.com >

AXLE, REAR DRIVE - DIFFERENTIAL (87422891 AXLE / 4 SPIDER DIFFERENTIAL)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		87422891		1	AXLE, REAR Incl. Ref 1 - 19; Four Spider Differential; Also Includes Parts On Figures 06-63 - 06-67, 07-05, 07-06; Four Spider Differential; If Used
		87422527		1	SET Differential Service Kit For Converting 2 Spider Differentials to 4 Spider Differentials; Incl. Ref 1 - 6, 8, 12 - 14, 16 - 18
		292268A1		1	HOUSING Differential, Incl. Ref 1, 2
1		NSS		1	NOT SERVICED SEPARATELY Housing, Flange Half
2		NSS		1	NOT SERVICED SEPARATELY Housing, Plain Half
		294192A1		1	SET Differential Gear Set, Service Replacement, Incl. Ref 3 - 6, 16, 17
3		NSS		4	NOT SERVICED SEPARATELY Thrust, Spherical
4		NSS		4	NOT SERVICED SEPARATELY Sun Gear, 12T, No Longer Sold Separately, Must Be Replaced As a Set, For Service, Order 294192A1 Gear Set Kit
5		NSS		1	NOT SERVICED SEPARATELY Side Pinion Gear, No Longer Sold Separately, Must Be Replaced As a Set, For Service, Order 294192A1 Gear Set Kit
6		NSS		2	NOT SERVICED SEPARATELY
7		S300976		10	SCREW M12 x 90; 12.9
8		E135785		2	BEARING
9		P3034505		2	NUT Lock Ring
10		112486A1		2	SCREW M6 x 12
11		175959A1		2	BRACKET Bracket
12		292207A1		4	PIN, LARGE
13		292208A1		4	O-RING
14		190452A1		2	BUSHING
15		191067A1		1	SLEEVE
		294192A1		1	SET Differential Gear Set, Service Replacement, Incl. Ref 3 - 6, 16, 17
16		NSS		2	NOT SERVICED SEPARATELY Sun Gear, No Longer Sold Separately, Must Be Replaced As a Set, For Service, Order 294192A1 Gear Set Kit
17		NSS		1	NOT SERVICED SEPARATELY Side Pinion Gear, No Longer Sold Separately, Must Be Replaced As a Set, For Service, Order 294192A1 Gear Set Kit

Order the manual at mid-west-tech.com >

MAST - 5000/6000 LB

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		324494A3		1	MAST ASSEMBLY 4,5 M (15 ft), Hook, Incl. 1 - 21, 26 - 38, Also Incl. Parts On Figure 09-07, Ref 1 - 5
		329462A3		1	MAST ASSEMBLY 4,5 M (15 ft), Shaft, Incl. 1 - 21, 26 - 38, Also Incl. Parts On Figure 09-07, Ref 6 - 14
		341188A1		1	RAIL ASSY. Incl. 1 - 21, 26 - 38
1		341185A1		1	RAIL Outer
2		341186A1		1	RAIL Inner
3		341187A1		2	CYLINDER ASSY. Rail, See Figure 08-07
4		219-8		2	NIPPLE, LUBE 1/4 tpr x 17/32
5		339786A1		X	SHIM 0,76 mm (0,03 in)
6		339777A1		2	BOLT
7		492-11075		2	WASHER, LOCK 3/4"
8		339778A1		2	BOLT
		341184A1		2	CHAIN ASSY.(CE) Incl. 9 - 13
9		231-24412		4	NUT, LOCK 3/4
10		341172A1		4	ANCHOR Chain
11		341173A1		4	PIN
12		432-612		8	PIN, SPLIT (COTTER) 3/32" x 3/4"
13		341183A1		2	CHAIN (AGRICULTURE) Mounts Through Carriage Chain Anchor
14		339897A1		X	SHIM 0,76 mm (0,03 in)
15		339898A1		4	ROLLER Load
16		339787A1		2	BUSHING
17		103-21300		2	SNAP RING No. 300
18		339789A1		2	PIN
19		103-11125		4	SNAP RING
20		100-11156		4	SNAP RING
21		341171A1		2	SHEAVE Chain
22		329457A1		1	SHAFT Pivot,Mast
23		329795A1		1	BACKREST 1524 mm (60 in), Load
24		413-1024		4	BOLT 5/8 x 1-1/2
25		492-11062		4	WASHER, LOCK 5/8"
26		337776A1		1	BLOCK For Attaching Hose(s) See Figure 08-03, See Olofsson dealer for service of the manifold valve on all masts.
27		339834A1		2	PLUG
28		353019A1		1	VALVE

MidWestTech | Case 585G, 586G, 588G Forklift Parts Catalog | Publication 7-5443 Order the manual at mid-west-tech.com >