580M
Loader Backhoe

Parts Catalog

7-6081 NA

CASE
CONSTRUCTION

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02 -01	RADIATOR - MOUNTING (WITHOUT AIR CONDITIONING)
02 -02	RADIATOR - MOUNTING (WITH / WITHOUT AIR CONDITIONING)
02 -03	RADIATOR ASSY
02 -03A	RADIATOR ASSY (HEAVY DUTY)
02 -04	AIR CLEANER - AIR INTAKE PARTS
02 -05	AIR CLEANER - PRECLEANER ASSY (MODELS WITHOUT TURBOCHARGED ENGINE)
02 -06	AIR CLEANER - PRECLEANER ASSY (MODELS WITH TURBOCHARGED ENGINE)
02 -07	MUFFLER - EXHAUST SYSTEM (MODELS WITH TURBOCHARGED ENGINE)
02 -08	MUFFLER - EXHAUST SYSTEM (MODELS WITHOUT TURBOCHARGED ENGINE)
02 -09	COLD START SYSTEM
02 -10	ENGINE - MOUNTING
02 -11	WATER PUMP SYSTEM - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
02 -12	FRONT GEAR COVER - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
02 -13	MANIFOLDS - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
02 -14	TURBOCHARGER SYSTEM - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -15	TURBOCHARGER ASSY - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -16	OIL FILTER AND COOLER - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
02 -17	OIL PUMP AND OIL PAN - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE, IF USED
02 -18	OIL PUMP AND OIL PAN - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE, IF USED
02 -19	BALANCER, ENGINE - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -20	CYLINDER HEAD COVERS - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
02 -21	CYLINDER HEAD AND VALVE MECHANISM - 4-390 EMISSIONS CERTIFIED ENGINE
02 -22	CYLINDER HEAD AND VALVE MECHANISM - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -23	CAMSHAFT - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
02 -24	CYLINDER BLOCK - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -25	CYLINDER BLOCK - 4-390 EMISSIONS CERTIFIED ENGINE
02 -26	CRANKSHAFT - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
02 -27	FLYWHEEL AND HOUSING - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
02 -28	PISTONS AND CONNECTING ROD - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -29	PISTONS AND CONNECTING ROD - 4-390 EMISSIONS CERTIFIED ENGINE
02 -30	GASKET KIT, VALVE GRIND - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
02 -31	GASKET KIT, CYLINDER BLOCK - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
02 -32	GASKET KIT, BASIC SERVICE ENGINE - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
03 -01	FUEL LINES, RESERVOIR - FILTER, IN-LINE FUEL
03 -02	CONTROLS - THROTTLE, HAND
03 -03	CONTROLS - THROTTLE, FOOT
03 -04	FUEL INJECTION SYSTEM - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
03 -05	FUEL FILTER - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
03 -06	FUEL INJECTION PUMP AND DRIVE - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
03 -07	FUEL INJECTION NOZZLE - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
04 -01	STARTER
04 -02	ALTERNATOR
04 -03	STARTER MOUNTING - ALTERNATOR MOUNTING
04 -04	HARNESS, ENGINE - MOUNTING AND CONNECTIONS
04 -05	BATTERY - CABLES (MODELS WITHOUT COLD START)
04 -06	BATTERY, DUAL - COLD START
04 -07	HARNESS, FRONT CONSOLE - SWITCHES
04 -08	HARNESS, FRONT CONSOLE - MOUNTING
04 -09	HARNESS, SIDE CONSOLE - SWITCHES
04 -10	INSTRUMENT PANEL, FRONT - COVERS
04 -11	INSTRUMENT PANEL, SIDE - COVERS (RIGHT-HAND SIDE)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

04 -12	INSTRUMENT CLUSTER
04 -13	ELECTRICAL - LAMPS, ROPS CANOPY
04 -14	ELECTRICAL - LAMPS, ROPS CAB
04 -15	LAMP ASSY
04 -16	HORN - ALARM, BACKUP
04 -17	BEACON, ROTATING
04 -18	ANTENNA, RADIO - HARNESS, RADIO
04 -19	ELECTRICAL - BACKHOE AUXILIARY HYDRAULIC
05 -01	STEERING WHEEL - COLUMN
05 -02	HYDRAULICS - STEERING
05 -03	STEERING COLUMN
05 -04	CYLINDER ASSY - STEERING (D138954 / 437320A1 FRONT AXLE) (IF USED)
05 -05	AXLE, FRONT (D138954 / 437320A1) - SPINDLES (IF USED)
05 -06	AXLE, FRONT (D138954 / 437320A1) - HUB AND BEARINGS (IF USED)
05 -07	AXLE, FRONT (377979A1 / 86990837) - MOUNTING (IF USED)
05 -08	AXLE, FRONT (377979A1 / 86990837) - HOUSING (IF USED)
05 -09	AXLE, FRONT (377979A1 / 86990837) - HOUSING, SWIVEL (IF USED)
05 -10	AXLE, FRONT (377979A1 / 86990837) - CYLINDER, STEERING (IF USED)
05 -11	AXLE, FRONT (377979A1 / 86990837) - HUB AND BEARINGS (IF USED)
05 -12	WHEELS, FRONT - TIRES
06 -01	AXLE, FRONT DRIVE - MOUNTING
06 -02	AXLE, FRONT DRIVE - HOUSING
06 -03	AXLE, FRONT DRIVE - HOUSING, SWIVEL
06 -04	AXLE, FRONT DRIVE - CYLINDER, STEERING
06 -05	AXLE, FRONT DRIVE - SHAFTS, AXLE
06 -06	AXLE, FRONT DRIVE - PLANETARY
06 -07	AXLE, FRONT DRIVE - DIFFERENTIAL
06 -08	AXLE, FRONT DRIVE - RING AND PINION
06 -09	DRIVE SHAFT, FRONT AXLE
06 -10	COOLING SYSTEM - TRANSMISSION (WITHOUT AIR CONDITIONING)
06 -11	COOLING SYSTEM - TRANSMISSION (WITH AIR CONDITIONING)
06 -12	TRANSMISSION - MOUNTING
06 -13	TRANSMISSION ASSY - FILTER, OIL
06 -14	TRANSMISSION ASSY (2WD) - HOUSING
06 -15	TRANSMISSION ASSY (4WD) - HOUSING
06 -16	TRANSMISSION ASSY - PUMP, OIL
06 -17	TRANSMISSION ASSY - SHIFTER MECHANISM
06 -18	TRANSMISSION ASSY - SHAFT, IDLER AND PRIMARY
06 -19	TRANSMISSION ASSY - SHAFT, INPUT
06 -20	TRANSMISSION ASSY - SHAFT, SECONDARY
06 -21	TRANSMISSION ASSY (4WD) - SHAFT, OUTPUT
06 -22	TRANSMISSION ASSY - VALVE, CONTROL
06 -23	TRANSMISSION ASSY (4WD) - VALVE, SOLENOID
06 -24	WHEELS, REAR - TIRES
06 -25	AXLE, REAR DRIVE - MOUNTING
06 -26	AXLE, REAR - DIFFERENTIAL LOCK
06 -27	AXLE, REAR DRIVE - HOUSING
06 -28	AXLE, REAR DRIVE - DIFFERENTIAL
06 -29	AXLE, REAR DRIVE - RING AND PINION
06 -30	AXLE, REAR DRIVE - DIFFERENTIAL LOCK
06 -31	AXLE, REAR DRIVE - PLANETARY

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

06 -32	DRIVE SHAFT, REAR AXLE
07 -01	AXLE, REAR DRIVE - BRAKE, DIFFERENTIAL
07 -02	AXLE, REAR DRIVE - BRAKE, PARKING
07 -03	BRAKE - PEDALS
07 -04	HYDRAULICS - BRAKE MASTER CYLINDER
07 -05	CYLINDER ASSY - BRAKE MASTER
07 -06	CONTROLS - BRAKE, PARKING
08 -01	HYDRAULICS - PUMP, FILTER AND LOADER VALVE
08 -02	HYDRAULICS - PUMP AND LOADER VALVE TO BACKHOE VALVE
08 -03	HYDRAULICS - COOLER, RETURN LINES AND FILTER
08 -04	HYDRAULICS - CYLINDER, LOADER LIFT
08 -05	HYDRAULICS - CYLINDER, LOADER BUCKET
08 -06	HYDRAULICS - CYLINDER, LOADER CLAM
08 -07	HYDRAULICS - CYLINDER, LOADER CLAM
08 -08	HYDRAULICS - CYLINDER, BACKHOE STABILIZER
08 -09	HYDRAULICS - CYLINDER, BACKHOE SWING
08 -10	HYDRAULICS - CYLINDER, BACKHOE BOOM
08 -11	HYDRAULICS - CYLINDER, BACKHOE DIPPER
08 -12	HYDRAULICS - CYLINDER, BACKHOE BUCKET (MODELS WITHOUT EXTENDABLE DIPPER)
08 -13	HYDRAULICS - CYLINDER, BACKHOE BUCKET (MODELS WITH EXTENDABLE DIPPER)
08 -14	HYDRAULICS - CYLINDER, BACKHOE EXTENDABLE DIPPER
08 -15	HYDRAULICS - HAND HELD AUXILIARY
08 -16	HYDRAULICS - HAND HELD AUXILIARY (MODELS WITH 31 GALLON FUEL TANK)
08 -17	HYDRAULICS - HAND HELD AUXILIARY (MODELS WITH 40 GALLON FUEL TANK)
08 -18	HYDRAULICS - HAND HELD AUXILIARY (MODELS WITH 31 OR 40 GALLON FUEL TANK)
08 -19	HYDRAULICS - BACKHOE AUXILIARY
08 -20	HYDRAULICS - BACKHOE AUXILIARY
08 -20A	HYDRAULICS - BACKHOE BOOM LOCK AND ELECTRICAL CIRCUIT
08 -21	HYDRAULICS - RIDE CONTROL (297977A4 VALVE)
08 -21A	HYDRAULICS - RIDE CONTROL (86983598 SOLENOID VALVE)
08 -22	HYDRAULICS - COUPLER, LOADER TOOL QUICK
08 -23	HYDRAULICS - COUPLER, LOADER TOOL QUICK
08 -24	PUMP, EQUIPMENT HYDRAULIC
08 -25	VALVE ASSY - LOADER CONTROL, TWO SPOOL
08 -26	VALVE ASSY - LOADER CONTROL, THREE SPOOL
08 -27	VALVE SECTION - INLET
08 -28	VALVE SECTION - LOADER BUCKET
08 -29	VALVE SECTION - LOADER LIFT
08 -30	VALVE SECTION - OUTLET
08 -31	VALVE SECTION - LOADER CLAM
08 -32	VALVE ASSY - RELIEF, CIRCUIT
08 -33	VALVE ASSY - BACKHOE CONTROL, 6 SPOOL (WITHOUT EXTENDABLE DIPPER AND WITHOUT AUXILIARY HYDRAULICS)
08 -34	VALVE ASSY - BACKHOE CONTROL, 7 SPOOL (WITHOUT EXTENDABLE DIPPER AND WITH AUXILIARY HYDRAULICS)
08 -35	VALVE ASSY - BACKHOE CONTROL, 7 SPOOL (WITH EXTENDABLE DIPPER AND WITHOUT AUXILIARY HYDRAULICS)

Order the manual at mid-west-tech.com >

HYDRAULICS - HAND HELD AUXILIARY

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
32		218-5158		1	PLUG 1-1/16 Or, Incl. Ref 33, Inlet Port, Included With Ref 1
33		237-6012		1	O-RING 59/64 ID x 7/64, Boss Seal
38		191532A1		1	SWITCH Auxiliary Hydraulics; Attaches To Side Options Harness
40		121413A1		1	FUSE 15 amp
42		218-5576		1	TEE Incl. 43, Inlet Section, Lower Valve Port; For Attaching Parts, See Figure 05-02
43		237-6010		1	O-RING 3/4 ID x 3/32, Boss Seal
44		243338A1		1	HOSE 910 mm (35-7/8 in)
47		218-5064		1	CONNECTOR 1-1/16 fl x Or, Incl. Ref 48
48		237-6012		1	O-RING 59/64 ID x 7/64, Boss Seal
49		302474A1		1	HOSE 500 mm (19-11/16 in), Return, Outlet Port, To Tee At Backhoe Control Valve
50		D132982		2	LOOM 400 mm (15-3/4 in)
51		L18337		4	STRAP 15 in
52		136008A1		1	SUPPORT
53		814-10050		1	CAPSCREW M10 x 50
54		D143422		1	SHIN
55		D143797		1	SHOCK ABSORBER 5/8
55C		144477A1		1	SHOCK ABSORBER
56		R46493		1	SPACER
57		829-1410		1	NUT M10; 10.9
58		218-5138		1	FITTING 1-1/16-12 fl x Or, Incl. Ref 59
59		237-6012		1	O-RING 59/64 ID x 7/64, Boss Seal
60		130060A2		1	VALVE, PRESSURE RELIEF 19,000 kPa, Pilot Relief, See Figure 08-27; Remove Plug At Loader Valve Inlet Section and Replace With This Valve

MidWestTech | Case 580M Loader Backhoe Parts Catalog | Publication 7-6081NA Order the manual at mid-west-tech.com >

CYLINDER ASSY - BACKHOE STABILIZER

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		195503A1		1	CYLINDER ASSY. 102 ID x 553 mm strk, Right-Hand, Incl. Ref 2- 20
1		195504A1		1	CYLINDER 102 ID x 553 mm strk, Left-Hand, Incl. Ref 2 - 20
2		195505A1		1	TUBE Right-Hand
2		195506A1		1	TUBE Left-Hand
		NSS		1	NOT SERVICED SEPARATELY Gland, Cylinder, Incl. Ref 4 - 10
4		128135A2		1	GLAND
5		D95144		1	SEALRING
6		G101533		1	BUSHING, LARGE
		1542876C1		1	PACKAGE,SERVICE Incl. Ref 7, 8; Not Serviced Separately; Order 1543269C1 Seal Kit
7		NSS		1	NOT SERVICED SEPARATELY Rod Seal; Order 1543269C1 Seal Kit
8		NSS		1	NOT SERVICED SEPARATELY Buffer Seal; Order 1543269C1 Seal Kit
9		238-5239		1	O-RING 3-5/8 x 1/8
10		G109299		1	RING
11		276-2446		1	SCREW No. 8 x 3/8
12		123726A1		1	ROD, PISTON 51 mm (2 in) dia
13		G108123		1	PISTON
14		G102285		1	SEAL
15		G100440		1	RING
16		G100448		1	RING
17		28-2044		1	SCREW 1-1/4 NF x 2-3/4; 8; No Longer Used; Order Ref 20
18		G104989		1	WASHER No Longer Used; Ref 20
19		219-1		1	NIPPLE, LUBE 1/8 PT x 21/32
		1543269C1		1	KIT, GASKET Seal, Incl. Ref 5 - 10, 14 - 16
20		86982440		1	BOLT, SPECIAL 1,25 x 2,75; Incl. Washer; Replaces Ref 17 and 18

MidWestTech | Case 580M Loader Backhoe Parts Catalog | Publication 7-6081NA Order the manual at mid-west-tech.com >

FENDER COVER, LEFT-HAND - PANEL, REAR CLOSURE, STORAGE TRAY WITH CUP HOLDER

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
20		400544A2		1	TRAY Incl. 375094A3, 304061A1, 400077A1; No Longer Available; Order 86992243, Ref. 20A
		375094A2		1	TRAY
		304061A1		4	BUMPER
		400077A1		1	STRIP, METRES 1300 mm (51-3/16 in); Cut From 1977224C1
20A		86992243		1	TRAY ASSY. Cover Incl. 86992284, 400077A1
		NSS		1	NOT SERVICED SEPARATELY Tray
		86992284		4	BUMPER
		400077A1		1	STRIP, METRES 1300 mm (51-3/16 in); Cut From 1977224C1
21		397025A1		1	STRIP,PROTECTION
21A		398113A1		3	SCREW No. 10 x 3/4
21B		131-869		3	NUT No. 10
22		555-2		2	SCREW M6 x 20
22A		895-30109		2	WASHER 6,6 x 25 x 1,6 mm
23		833-40406		2	NUT M6
24		440-11014		2	SCREW No. 10 x 7/8; If Used
24		140-117		2	SCREW No 10 x 1; If Used
25		495-61020		4	WASHER 13/64 x 3/4 x 1/16
26		231-14109		2	NUT No. 10
27		378742A3		1	INSERT Swing Pin Holder
		REF			INSTRUCTION Rear Closure Panel/Canopy Models
28		360594A2		1	PANEL Used With 313238A1 and 384271A1 Decals; Decals Purchased Separately; No Longer Available; Order 87403455, Service Kit, Ref 40
29		614-8025		1	CAPSCREW M8 x 25
30		781-24820		4	SCREW M8 x 20
31		895-15008		5	WASHER 9 x 16 x 1,6 mm
32		832-10408		1	NUT M8
		411078A1		1	PLATE ASSY. Incl. 33 - 38; No Longer Available; Order 87403455, Service Kit, Ref 40
33		428407A1		1	PANEL
34		410440A1		2	PLATE Decal Mounting
35		384271A1		2	DECAL Warning, No Step
36		410436A1		2	PLATE Decal Mounting

MidWestTech | Case 580M Loader Backhoe Parts Catalog | Publication 7-6081NA Order the manual at mid-west-tech.com >