580 Super M
LOADER BACKHOE

Parts Manual

7-6091NA

CASE
CONSTRUCTION

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02 -01	RADIATOR - MOUNTING
02 -02	RADIATOR ASSY
02 -03	AIR CLEANER - AIR INTAKE PARTS
02 -04	AIR CLEANER - PRECLEANER ASSY
02 -05	MUFFLER - EXHAUST SYSTEM
02 -06	COLD START SYSTEM
02 -07	ENGINE - MOUNTING
02 -08	WATER PUMP SYSTEM - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -09	FRONT GEAR COVER - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -10	MANIFOLDS - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -11	TURBOCHARGER SYSTEM - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -12	TURBOCHARGER ASSY - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -13	OIL FILTER AND COOLER - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -14	OIL PUMP AND OIL PAN - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -15	BALANCER, ENGINE - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -16	CYLINDER HEAD COVERS - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -17	CYLINDER HEAD AND VALVE MECHANISM - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -18	CAMSHAFT - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -19	CYLINDER BLOCK - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -20	CRANKSHAFT - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -21	FLYWHEEL AND HOUSING - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -22	PISTONS AND CONNECTING ROD - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -23	GASKET KIT, VALVE GRIND - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -24	GASKET KIT, CYLINDER BLOCK - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -25	GASKET KIT, BASIC SERVICE ENGINE - 4T-390 EMISSIONS CERTIFIED ENGINE
03 -01	FUEL LINES, RESERVOIR - FILTER, IN-LINE FUEL
03 -02	CONTROLS - THROTTLE, HAND
03 -03	CONTROLS - THROTTLE, FOOT
03 -04	FUEL FILTER - 4T-390 EMISSIONS CERTIFIED ENGINE
03 -05	FUEL INJECTION SYSTEM - 4T-390 EMISSIONS CERTIFIED ENGINE
03 -06	ANEROID AND WASTEGATE SYSTEM - 4T-390 EMISSIONS CERTIFIED ENGINE
03 -07	FUEL INJECTION PUMP AND DRIVE - 4T-390 EMISSIONS CERTIFIED ENGINE
03 -08	FUEL INJECTION NOZZLE - 4T-390 EMISSIONS CERTIFIED ENGINE
04 -01	STARTER
04 -02	ALTERNATOR
04 -03	STARTER MOUNTING - ALTERNATOR MOUNTING
04 -04	HARNESS, ENGINE - MOUNTING AND CONNECTIONS
04 -05	BATTERY CABLES (MODELS WITHOUT COLD START)
04 -06	BATTERY, DUAL - COLD START
04 -07	HARNESS, FRONT CONSOLE - SWITCHES
04 -08	HARNESS, FRONT CONSOLE - MOUNTING
04 -09	ELECTRICAL - TRANSMISSION, POWERSHIFT
04 -10	HARNESS, SIDE CONSOLE - SWITCHES
04 -11	INSTRUMENT PANEL, FRONT - COVERS
04 -12	INSTRUMENT PANEL, SIDE - COVERS (RIGHT-HAND SIDE)
04 -13	INSTRUMENT CLUSTER
04 -14	ELECTRICAL - LAMPS, ROPS CANOPY
04 -15	ELECTRICAL - LAMPS, ROPS CAB
04 -16	LAMP ASSY (ROPS CANOPY MODELS)
04 -17	HORN - ALARM, BACKUP
04 -18	BEACON, ROTATING (CAB OR CANOPY MODELS)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

04 -19	ANTENNA, RADIO - HARNESS, RADIO
04 -20	ELECTRICAL - BACKHOE AUXILIARY HYDRAULIC
05 -01	STEERING WHEEL - COLUMN
05 -02	HYDRAULICS - STEERING
05 -03	STEERING COLUMN
05 -04	CYLINDER ASSY - STEERING (D138954 / 437320A1 FRONT AXLE) (IF USED)
05 -05	AXLE, FRONT (D138954 / 437320A1) - SPINDLES (IF USED)
05 -06	AXLE, FRONT (D138954 / 437320A1) - HUB AND BEARINGS (IF USED)
05 -07	AXLE, FRONT (377979A1 / 86990837) - MOUNTING (IF USED)
05 -08	AXLE, FRONT (377979A1 / 86990837) - HOUSING (IF USED)
05 -09	AXLE, FRONT (377979A1 / 86990837) - HOUSING, SWIVEL (IF USED)
05 -10	AXLE, FRONT (377979A1 / 86990837) - CYLINDER, STEERING (IF USED)
05 -11	AXLE, FRONT (377979A1 / 86990837) - HUB AND BEARINGS (IF USED)
05 -12	WHEELS, FRONT - TIRES
06 -01	AXLE, FRONT DRIVE - MOUNTING
06 -02	AXLE, FRONT DRIVE - HOUSING
06 -03	AXLE, FRONT DRIVE - HOUSING, SWIVEL
06 -04	AXLE, FRONT DRIVE - CYLINDER, STEERING
06 -05	AXLE, FRONT DRIVE - SHAFTS, AXLE
06 -06	AXLE, FRONT DRIVE - PLANETARY
06 -07	AXLE, FRONT DRIVE - DIFFERENTIAL
06 -08	AXLE, FRONT DRIVE - RING AND PINION
06 -09	DRIVE SHAFT, FRONT AXLE
06 -10	COOLING SYSTEM - TRANSMISSION (MODELS WITHOUT POWERSHIFT)
06 -11	COOLING SYSTEM - TRANSMISSION (MODELS WITH POWERSHIFT)
06 -12	TRANSMISSION - MOUNTING (MODELS WITHOUT POWERSHIFT)
06 -13	TRANSMISSION - MOUNTING (MODELS WITH POWERSHIFT)
06 -14	TRANSMISSION ASSY - FILTER, OIL (MODELS WITHOUT POWERSHIFT)
06 -15	TRANSMISSION ASSY (2WD) - HOUSING (MODELS WITHOUT POWERSHIFT)
06 -16	TRANSMISSION ASSY (4WD) - HOUSING (MODELS WITHOUT POWERSHIFT)
06 -17	TRANSMISSION ASSY - PUMP, OIL (MODELS WITHOUT POWERSHIFT)
06 -18	TRANSMISSION ASSY - SHIFTER MECHANISM (MODELS WITHOUT POWERSHIFT)
06 -19	TRANSMISSION ASSY - SHAFT, IDLER AND PRIMARY (MODELS WITHOUT POWERSHIFT)
06 -20	TRANSMISSION ASSY - SHAFT, INPUT (MODELS WITHOUT POWERSHIFT)
06 -21	TRANSMISSION ASSY - SHAFT, SECONDARY (MODELS WITHOUT POWERSHIFT)
06 -22	TRANSMISSION ASSY (4WD) - SHAFT, OUTPUT (MODELS WITHOUT POWERSHIFT)
06 -23	TRANSMISSION ASSY - VALVE, CONTROL (MODELS WITHOUT POWERSHIFT)
06 -24	TRANSMISSION ASSY (4WD) - VALVE, SOLENOID (MODELS WITHOUT POWERSHIFT)
06 -25	TRANSMISSION ASSY, POWERSHIFT - HOUSING
06 -26	TRANSMISSION ASSY, POWERSHIFT - HOUSING, REAR
06 -27	TRANSMISSION ASSY, POWERSHIFT - TORQUE CONVERTER
06 -28	TRANSMISSION ASSY, POWERSHIFT - PUMP, OIL
06 -29	TRANSMISSION ASSY, POWERSHIFT - CLUTCH, FORWARD DRIVE
06 -30	TRANSMISSION ASSY, POWERSHIFT - CLUTCH, REVERSE DRIVE
06 -31	TRANSMISSION ASSY, POWERSHIFT - CLUTCH, PUMP DRIVE
06 -32	TRANSMISSION ASSY, POWERSHIFT - CLUTCH, SECOND GEAR
06 -33	TRANSMISSION ASSY, POWERSHIFT - CLUTCH, OUTPUT SHAFT
06 -34	TRANSMISSION ASSY, POWERSHIFT - MOUNTING, VALVE
06 -35	TRANSMISSION ASSY, POWERSHIFT - VALVE, CONTROL

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

06 -36	TRANSMISSION ASSY, POWERSHIFT - PLATE, DRIVE
06 -37	WHEELS, REAR - TIRES
06 -38	AXLE, REAR DRIVE - MOUNTING
06 -39	AXLE, REAR - DIFFERENTIAL LOCK
06 -40	AXLE, REAR DRIVE - HOUSING
06 -41	AXLE, REAR DRIVE - DIFFERENTIAL (CLOCKWISE INPUT, MODELS WITHOUT POWERSHIFT)
06 -42	AXLE, REAR DRIVE - DIFFERENTIAL (COUNTER CLOCKWISE INPUT, MODELS WITH POWERSHIFT)
06 -43	AXLE, REAR DRIVE - RING AND PINION
06 -44	AXLE, REAR DRIVE - DIFFERENTIAL LOCK (CLOCKWISE INPUT, MODELS WITHOUT POWERSHIFT)
06 -45	AXLE, REAR DRIVE - DIFFERENTIAL LOCK (COUNTER CLOCKWISE INPUT, MODELS WITH POWERSHIFT)
06 -46	AXLE, REAR DRIVE - PLANETARY
06 -47	DRIVE SHAFT, REAR AXLE
07 -01	AXLE, REAR DRIVE - BRAKE, DIFFERENTIAL
07 -02	AXLE, REAR DRIVE - BRAKE, PARKING
07 -03	BRAKE - PEDALS
07 -04	HYDRAULICS - BRAKE MASTER CYLINDER
07 -05	CYLINDER ASSY - BRAKE MASTER
07 -06	CONTROLS - BRAKE, PARKING
08 -01	HYDRAULICS - PUMP, FILTER AND LOADER VALVE
08 -02	HYDRAULICS - PUMP AND LOADER VALVE TO BACKHOE VALVE
08 -03	HYDRAULICS - COOLER, RETURN LINES AND FILTER
08 -04	HYDRAULICS - CYLINDER, LOADER LIFT
08 -05	HYDRAULICS - CYLINDER, LOADER BUCKET
08 -06	HYDRAULICS - CYLINDER, LOADER CLAM
08 -07	HYDRAULICS - CYLINDER, LOADER CLAM
08 -08	HYDRAULICS - CYLINDER, BACKHOE STABILIZER
08 -09	HYDRAULICS - CYLINDER, BACKHOE SWING
08 -10	HYDRAULICS - CYLINDER, BACKHOE BOOM
08 -11	HYDRAULICS - CYLINDER, BACKHOE DIPPER
08 -12	HYDRAULICS - CYLINDER, BACKHOE BUCKET (MODELS WITHOUT EXTENDABLE DIPPER)
08 -13	HYDRAULICS - CYLINDER, BACKHOE BUCKET (MODELS WITH EXTENDABLE DIPPER)
08 -14	HYDRAULICS - CYLINDER, BACKHOE EXTENDABLE DIPPER
08 -15	HYDRAULICS - HAND HELD AUXILIARY (MODELS WITH OR WITHOUT EXTENDABLE DIPPER)
08 -16	HYDRAULICS - HAND HELD AUXILIARY (MODELS WITH 31 GALLON FUEL TANK)
08 -17	HYDRAULICS - HAND HELD AUXILIARY (MODELS WITH 40 GALLON FUEL TANK)
08 -18	HYDRAULICS - HAND HELD AUXILIARY (MODELS WITH 31 OR 40 GALLON FUEL TANK)
08 -19	HYDRAULICS - BACKHOE AUXILIARY
08 -20	HYDRAULICS - BACKHOE AUXILIARY
08 -20A	HYDRAULICS - BACKHOE BOOM LOCK AND ELECTRICAL CIRCUIT
08 -21	HYDRAULICS - RIDE CONTROL (297977A4 SOLENOID VALVE)
08 -21A	HYDRAULICS - RIDE CONTROL (86983598 SOLENOID VALVE)
08 -22	HYDRAULICS - COUPLER, LOADER TOOL QUICK
08 -23	HYDRAULICS - COUPLER, LOADER TOOL QUICK

Order the manual at mid-west-tech.com >