75XT
Skid Steer

ASN JAF0318922(NA)
JAF0352169(EU)

Parts Catalog

7-8210NA

CASE
CONSTRUCTION

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02 -01	RADIATOR - COOLANT RECOVERY SYSTEM
02 -02	FAN - FAN BELT
02 -03	EXHAUST SYSTEM
02 -04	AIR CLEANER - ENGINE
02 -05	COLD START - THERMOSTART
02 -06	ENGINE - MOUNTING
02 -07	WATER PUMP SYSTEM
02 -08	FRONT GEAR COVER
02 -09	MANIFOLDS - EXHAUST AND INTAKE
02 -10	FILTER AND COOLER - OIL
02 -11	OIL PUMP, PAN - HEATER
02 -12	CYLINDER HEAD COVER - THERMOSTAT AND HOUSING
02 -13	CYLINDER HEAD - VALVE MECHANISM
02 -14	CAMSHAFT
02 -15	CYLINDER BLOCK
02 -16	CRANKSHAFT
02 -17	FLYWHEEL AND HOUSING
02 -18	PISTONS - CONNECTING RODS
02 -19	GASKET KIT, VALVE GRIND
02 -20	GASKET KIT, CYLINDER BLOCK
02 -21	GASKET KIT, BASIC SERVICE ENGINE
03 -01	FUEL LINES
03 -02	CONTROLS - THROTTLE (NORTH AMERICA)
03 -03	CONTROLS - THROTTLE (EUROPE)
03 -04	FUEL INJECTION SYSTEM
03 -05	FUEL INJECTION - PUMP AND DRIVE
03 -06	FUEL INJECTION - NOZZLE
04 -01	STARTER ASSY
04 -02	ALTERNATOR ASSY
04 -03	MOUNTING - STARTER AND ALTERNATOR
04 -04	BATTERY - CABLES
04 -05	DISCONNECT SWITCH
04 -06	HARNESS, FRONT - CHASSIS
04 -07	HARNESS, REAR - CHASSIS
04 -08	HARNESS - CHASSIS OPTIONS
04 -09	SWITCH MOUNTING - CHASSIS OPTIONS
04 -10	HARNESS - TURN SIGNAL, FLASHER AND LICENSE PLATE LAMP
04 -11	SWITCH MOUNTING - LOCK, LOADER CONTROL
04 -12	HARNESS - CAB
04 -13	HARNESS - SEAT BAR
04 -14	K HARNESS - DOOR, FRONT
04 -15	HARNESS, FRONT - AUXILIARY
04 -16	WIPER, WINDSHIELD
04 -17	CONTROLS, RIGHT HAND - HANDLE
04 -18	CONTROLS, LEFT HAND - HANDLE
04 -19	LAMP ASSY - BEACON, ROTATING
04 -20	HORN - MOUNTING
04 -21	MOUNTING - LAMP, LICENSE PLATE
04 -22	LAMP ASSY - LICENSE PLATE
04 -23	MOUNTING - LAMP ASSY, COMBINATION
04 -24	MOUNTING - LAMP ASSY, COMBINATION

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

04 -25	MOUNTING - LAMPS, ROAD
04 -26	ENGINE - SHUTDOWN, AUTOMATIC
06 -01	HYDROSTATICS - PUMP AND SUPPLY LINES
06 -02	HYDROSTATICS - PUMP AND RETURN LINES
06 -03	HYDROSTATICS - AUXILIARY VALVE PLUMBING
06 -04	HYDROSTATICS - PUMP AND DRIVE MOTORS
06 -05	FILTER ASSY - MOUNTING
06 -06	PUMP, TANDEM - MOUNTING
06 -06A	PUMP, GEAR - MOUNTING
06 -07	PUMP, TANDEM
06 -08	PUMP, TANDEM
06 -09	PUMP, TANDEM
06 -10	PUMP, TANDEM
06 -10A	PUMP, TANDEM
06 -10B	PUMP, TANDEM
06 -11	PUMP, GEAR
06 -12	MOTOR ASSY
06 -13	DRIVE LINE
06 -14	AXLE ASSY
06 -15	WHEELS
06 -16	TRACK - STEEL (NORTH AMERICA)
07 -01	BRAKE SYSTEM - HYDRAULIC
07 -02	BRAKE - HYDRAULIC
07 -03	BRAKE RELEASE - MANUAL
07 -04	PUMP - BRAKE
08 -01	HYDRAULICS - LOADER LIFT
08 -02	HYDRAULICS - LOADER BUCKET
08 -02A	HYDRAULICS - SELF-LEVELING
08 -03	HYDRAULICS - AUXILIARY SYSTEM
08 -04	HYDRAULICS - RIDE CONTROL
08 -05	HYDRAULICS - COUPLER SYSTEM
08 -06	HYDRAULICS - COUPLER SYSTEM
08 -07	VALVE, CONTROL - MOUNTING
08 -08	VALVE ASSY, CONTROL - LOADER
08 -09	VALVE ASSY, CONTROL - SPOOLS AND DETENTS
08 -09A	VALVE ASSY, CONTROL - SELF-LEVELING, DUAL
08 -09B	VALVE ASSY, CONTROL - SPOOLS AND DETENTS, SELF-LEVELING, DUAL
08 -10	AUXILIARY VALVE AND MOUNTING
08 -11	CYLINDER - LOADER LIFT
08 -12	CYLINDER - LOADER BUCKET
08 -13	VALVE, SOLENOID
08 -14	COUPLERS - HYDRAULIC
08 -15	HYDRAULICS, ATTACHMENT - HIGH FLOW, GEAR
08 -16	HYDRAULICS, ATTACHMENT - HIGH FLOW, GEAR
08 -17	HYDRAULICS, ATTACHMENT - HIGH FLOW, GEAR
08 -18	HYDRAULICS, ATTACHMENT - HIGH FLOW, GEAR
08 -19	HYDRAULICS, ATTACHMENT - HIGH FLOW, GEAR
08 -19A	HYDRAULICS, ATTACHMENT - HIGH FLOW, GEAR
08 -20	VALVE ASSY, CONTROL - HIGH FLOW
08 -21	HYDRAULIC SYSTEM - BACKHOE SUPPLY AND RETURN (NORTH AMERICA)
08 -22	HYDRAULIC SYSTEM - BACKHOE SWING CYLINDER (NORTH AMERICA)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

08 -23	HYDRAULIC SYSTEM - BACKHOE STABILIZER CYLINDER (NORTH AMERICA)
08 -24	HYDRAULIC SYSTEM - BACKHOE BOOM CYLINDER (NORTH AMERICA)
08 -25	HYDRAULIC SYSTEM - BACKHOE DIPPER CYLINDER (NORTH AMERICA)
08 -26	HYDRAULIC SYSTEM - BACKHOE BUCKET CYLINDER (NORTH AMERICA)
08 -27	VALVE, CONTROL - BACKHOE (NORTH AMERICA)
08 -28	VALVE, CONTROL - BACKHOE (NORTH AMERICA)
08 -29	VALVE, CONTROL - BACKHOE (NORTH AMERICA)
08 -30	CYLINDER ASSY - BACKHOE SWING (NORTH AMERICA)
08 -31	CYLINDER ASSY - BACKHOE BOOM (NORTH AMERICA)
08 -32	CYLINDER ASSY - BACKHOE DIPPER (NORTH AMERICA)
08 -33	CYLINDER ASSY - BACKHOE BUCKET (NORTH AMERICA)
08 -34	CYLINDER ASSY - STABILIZER, FOLD DOWN (NORTH AMERICA)
08 -35	CYLINDER ASSY - STABILIZER, VERTICAL (NORTH AMERICA)
09 -01	FRAME - LOADER LIFT
09 -02	SUPPORT - LOADER FRAME
09 -03	ARM, LOADER H-FRAME
09 -04	COUPLER, MECHANICAL
09 -05	COUPLER, HYDRAULIC
09 -06	BUCKETS, LOADER - 1860 MM (73 IN) WIDE BUCKET
09 -07	BUCKETS, LOADER - 2083 MM (82 IN) WIDE BUCKET
09 -08	PALLET FORK
09 -09	CHASSIS
09 -10	PLATES, FLOOR
09 -11	CONSOLE, CONTROL
09 -12	CONTROLS - LOADER AND GROUND DRIVE
09 -13	LINKAGE - LOADER AND GROUND DRIVE
09 -14	LINKAGE - AUXILIARY SYSTEM
09 -15	HOOD - WITHOUT SOUNDPROOFING (NORTH AMERICA)
09 -16	HOOD - WITH SOUNDPROOFING (EUROPE)
09 -17	DOOR, REAR (NORTH AMERICA)
09 -18	DOOR, REAR - WITH SOUNDPROOFING (EUROPE)
09 -19	SOUNDPROOFING - PANELS (EUROPE)
09 -20	COUNTERWEIGHTS - DRAWBAR
09 -21	SEAT, MOUNTING - NON-SUSPENSION
09 -22	SEAT, MOUNTING - SUSPENSION
09 -23	SEAT - SUSPENSION
09 -24	SEAT - SUSPENSION
09 -25	SEAT - SUSPENSION
09 -26	CANOPY, ROPS - FRAME AND SEAT BAR
09 -27	CANOPY, ROPS - FRAME AND SEAT BAR
09 -28	CANOPY, ROPS - LIFT HOOK
09 -29	CANOPY, ROPS - REAR LATCH AND PIVOT
09 -30	CANOPY, ROPS - HEAT SHIELD
09 -31	CANOPY, ROPS - HEADLINER
09 -32	DOOR, FRONT - WINDSHIELD
09 -33	DOOR, FRONT - MOUNTING, FRAME
09 -34	DOOR, FRONT - LATCH
09 -35	WINDOWS - SIDE AND TOP
09 -35A	MOUNTING MIRROR, REAR VIEW
09 -36	HEATING SYSTEM - HEATER, FLOOR
09 -37	HEATING SYSTEM - HEATER, DELUXE

Order the manual at mid-west-tech.com >