95XT
Skid Steer

ASN JAF0311357(NA)
JAF0274360(EU)

Parts Catalog

7-8240NA

CASE
CONSTRUCTION

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02 -01	RADIATOR - COOLANT RECOVERY SYSTEM
02 -02	FAN - FAN BELT
02 -03	EXHAUST SYSTEM (NORTH AMERICA)
02 -03A	EXHAUST SYSTEM (EUROPE)
02 -04	AIR CLEANER - ENGINE
02 -05	COLD START - THERMOSTART
02 -06	ENGINE - MOUNTING
02 -07	WATER PUMP SYSTEM
02 -08	FRONT GEAR COVER
02 -09	MANIFOLDS - EXHAUST AND INTAKE
02 -09A	TURBOCHARGER SYSTEM
02 -09B	TURBOCHARGER ASSY, NORTH AMERICAN MODELS WITHOUT AIR CONDITIONING
02 -09C	WASTEGATE ACTUATOR, NORTH AMERICAN MODELS WITHOUT AIR CONDITIONING
02 -09D	TURBOCHARGER ASSY, NORTH AMERICAN MODELS WITH AIR CONDITIONING AND ALL EUROPEAN MODELS
02 -10	FILTER AND COOLER - OIL
02 -11	OIL PUMP, PAN - HEATER
02 -12	CYLINDER HEAD COVER - THERMOSTAT AND HOUSING
02 -13	CYLINDER HEAD - VALVE MECHANISM
02 -14	CAMSHAFT
02 -15	CYLINDER BLOCK
02 -16	CRANKSHAFT
02 -17	FLYWHEEL AND HOUSING
02 -18	PISTONS - CONNECTING RODS
02 -19	GASKET KIT, VALVE GRIND
02 -20	GASKET KIT, CYLINDER BLOCK
02 -21	GASKET KIT, BASIC SERVICE ENGINE
03 -01	FUEL LINES
03 -02	CONTROLS - THROTTLE (NORTH AMERICA)
03 -03	CONTROLS - THROTTLE (EUROPE)
03 -04	FUEL INJECTION SYSTEM
03 -04A	FUEL FILTER - PUMP, TRANSFER
03 -04B	WASTEGATE SYSTEM, NORTH AMERICAN MODELS WITHOUT AIR CONDITIONING
03 -05	J991960 FUEL INJECTION - PUMP AND DRIVE
03 -05A	J930148 FUEL INJECTION - PUMP AND DRIVE
03 -06	FUEL INJECTION - NOZZLE
04 -01	STARTER ASSY
04 -02	ALTERNATOR ASSY
04 -03	MOUNTING - STARTER AND ALTERNATOR
04 -04	BATTERY - CABLES
04 -05	DISCONNECT SWITCH
04 -06	HARNESS, FRONT - CHASSIS
04 -07	HARNESS, REAR - CHASSIS
04 -08	HARNESS - CHASSIS OPTIONS
04 -09	SWITCH MOUNTING - CHASSIS OPTIONS
04 -10	HARNESS - TURN SIGNAL, FLASHER AND LICENSE PLATE LAMP
04 -11	SWITCH MOUNTING - LOCK, LOADER CONTROL
04 -12	HARNESS - CAB
04 -13	HARNESS - SEAT BAR
04 -14	K HARNESS - DOOR, FRONT
04 -15	HARNESS, FRONT - AUXILIARY

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

04 -16	WIPER, WINDSHIELD
04 -17	CONTROLS, RIGHT HAND - HANDLE
04 -18	CONTROLS, LEFT HAND - HANDLE
04 -19	LAMP ASSY - BEACON, ROTATING
04 -20	HORN - MOUNTING
04 -21	MOUNTING - LAMP, LICENSE PLATE
04 -22	LAMP ASSY - LICENSE PLATE
04 -23	MOUNTING - LAMP ASSY, COMBINATION
04 -24	MOUNTING - LAMP ASSY, COMBINATION
04 -25	MOUNTING - LAMPS, ROAD
04 -26	ENGINE - SHUTDOWN, AUTOMATIC
06 -01	HYDROSTATICS - PUMP, SUPPLY AND RETURN
06 -01A	HYDROSTATICS - PUMP, SUPPLY AND RETURN
06 -02	HYDROSTATICS - CASE DRAIN
06 -03	HYDROSTATICS - AUXILIARY VALVE PLUMBING
06 -04	HYDROSTATICS - PUMP AND DRIVE MOTORS
06 -04A	HYDROSTATICS - SOLENOID
06 -05	FILTER ASSY - MOUNTING
06 -06	PUMP, TANDEM - MOUNTING
06 -07	PUMP, TANDEM
06 -08	PUMP, TANDEM
06 -09	PUMP, TANDEM
06 -10	PUMP, TANDEM
06 -11	PUMP, GEAR
06 -12	MOTOR ASSY
06 -12A	MOTOR ASSY
06 -12B	GEAR BOX - MOUNTING
06 -13	DRIVE LINE
06 -14	AXLE ASSY
06 -15	WHEELS
06 -16	TRACK - STEEL (NORTH AMERICA)
06 -16A	WHEELS - TRACK, RUBBER
07 -01	BRAKE
07 -02	HYDRAULIC CIRCUIT, BRAKE
07 -03	BRAKE RELEASE - MANUAL
07 -04	PUMP - BRAKE
08 -01	HYDRAULICS - LOADER LIFT
08 -02	HYDRAULICS - LOADER BUCKET
08 -02A	HYDRAULICS - SELF-LEVELING
08 -03	HYDRAULICS - AUXILIARY SYSTEM
08 -04	HYDRAULICS - RIDE CONTROL
08 -05	HYDRAULICS - COUPLER SYSTEM
08 -06	HYDRAULICS - COUPLER SYSTEM
08 -07	VALVE, CONTROL - MOUNTING
08 -08	VALVE ASSY, CONTROL - LOADER
08 -09	VALVE ASSY, CONTROL - SPOOLS AND DETENTS
08 -09A	VALVE ASSY, CONTROL - SELF-LEVELING, DUAL
08 -09B	VALVE ASSY, CONTROL - SPOOLS AND DETENTS, SELF-LEVELING, DUAL
08 -10	AUXILIARY VALVE AND MOUNTING
08 -11	CYLINDER - LOADER LIFT
08 -12	CYLINDER - LOADER BUCKET

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

08 -13	VALVE, SOLENOID
08 -14	COUPLERS - HYDRAULIC
08 -14A	HYDRAULICS, ATTACHMENT - HIGH FLOW, PISTON
08 -14B	HYDRAULICS, ATTACHMENT - HIGH FLOW, PISTON
08 -14C	HYDRAULICS, ATTACHMENT - HIGH FLOW, PISTON
08 -14D	HYDRAULICS, ATTACHMENT - HIGH FLOW, PISTON
08 -14E	HYDRAULICS, ATTACHMENT - HIGH FLOW, PISTON
08 -14F	PUMP, PISTON
08 -14G	PUMP, PISTON
08 -14H	PUMP, PISTON
08 -14I	FILTER ASSY, OIL
08 -15	HYDRAULICS, ATTACHMENT - HIGH FLOW, GEAR
08 -16	HYDRAULICS, ATTACHMENT - HIGH FLOW, GEAR
08 -17	HYDRAULICS, ATTACHMENT - HIGH FLOW, GEAR
08 -18	HYDRAULICS, ATTACHMENT - HIGH FLOW, GEAR
08 -19	HYDRAULICS, ATTACHMENT - HIGH FLOW, GEAR
08 -20	VALVE ASSY, CONTROL - HIGH FLOW
08 -21	HYDRAULIC SYSTEM - BACKHOE SUPPLY AND RETURN (NORTH AMERICA)
08 -22	HYDRAULIC SYSTEM - BACKHOE SWING CYLINDER (NORTH AMERICA)
08 -23	HYDRAULIC SYSTEM - BACKHOE STABILIZER CYLINDER (NORTH AMERICA)
08 -24	HYDRAULIC SYSTEM - BACKHOE BOOM CYLINDER (NORTH AMERICA)
08 -25	HYDRAULIC SYSTEM - BACKHOE DIPPER CYLINDER (NORTH AMERICA)
08 -26	HYDRAULIC SYSTEM - BACKHOE BUCKET CYLINDER (NORTH AMERICA)
08 -26A	HYDRAULIC SYSTEM - TRENCHER DRIVE (NORTH AMERICA)
08 -26B	HYDRAULIC SYSTEM - TRENCHER BOOM LIFT (NORTH AMERICA)
08 -27	VALVE, CONTROL - BACKHOE (NORTH AMERICA)
08 -28	VALVE, CONTROL - BACKHOE (NORTH AMERICA)
08 -29	VALVE, CONTROL - BACKHOE (NORTH AMERICA)
08 -29A	VALVE, LOCK (NORTH AMERICA)
08 -30	CYLINDER ASSY - BACKHOE SWING (NORTH AMERICA)
08 -31	CYLINDER ASSY - BACKHOE BOOM (NORTH AMERICA)
08 -32	CYLINDER ASSY - BACKHOE DIPPER (NORTH AMERICA)
08 -33	CYLINDER ASSY - BACKHOE BUCKET (NORTH AMERICA)
08 -34	CYLINDER ASSY - STABILIZER, FOLD DOWN (NORTH AMERICA)
08 -35	CYLINDER ASSY - STABILIZER, VERTICAL (NORTH AMERICA)
08 -35A	CYLINDER ASSY - TRENCHER BOOM LIFT (NORTH AMERICA)
08 -35B	TRENCHER - MOTOR, DRIVE (NORTH AMERICA)
09 -01	FRAME - LOADER LIFT
09 -02	SUPPORT - LOADER FRAME
09 -03	ARM, LOADER H-FRAME
09 -04	COUPLER, MECHANICAL
09 -05	COUPLER, HYDRAULIC
09 -06	BUCKETS, LOADER - 1860 MM (73 IN) WIDE BUCKET
09 -07	BUCKETS, LOADER - 2083 MM (82 IN) WIDE BUCKET
09 -08	PALLET FORK
09 -09	CHASSIS
09 -10	PLATES, FLOOR
09 -11	CONSOLE, CONTROL
09 -12	CONTROLS - LOADER AND GROUND DRIVE
09 -13	LINKAGE - LOADER AND GROUND DRIVE
09 -14	LINKAGE - AUXILIARY SYSTEM

Order the manual at mid-west-tech.com >

HYDRAULICS - AUXILIARY SYSTEM

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		417369A1		1	VALVE Control 1 spool Auxiliary Component Parts Not Serviced Separately See Figure 08 -10
2		218-5062		2	CONNECTOR 7/8 fl x Or Incl. 3
3		237-6010		1	O-RING 3/4 ID x 3/32
4		426984A1		1	TUBE ASSY. Auxiliary Valve
5		426982A1		1	TUBE ASSY. Auxiliary Valve
6		103-3398		4	CIRCLIP No. X 98
7		139390A3		2	HOSE 3200 mm (126 in)
8		253476A1		1	BAR
9		256688A1		1	CLAMP BRACKET
10		P24576		1	SPACER
11		814-10040		1	CAPSCREW M10 x 40
12		895-11010		1	WASHER 11 x 20 x 2 mm
13		614-10025		2	SCREW M10 x 25
14		895-11010		2	WASHER 11 x 20 x 2 mm
15		832-41410		2	NUT M10
16		197624A2		1	BRACKET Models With Hydraulic Coupler See Figure 08 -05, REF 6
17		614-10025		1	SCREW M10 x 25
18		895-11010		1	WASHER 11 x 20 x 2 mm
19		614-10020		1	CAPSCREW M10 x 20
20		895-11010		1	WASHER 11 x 20 x 2 mm
21		393397A1		1	COUPLING Male Components Not Serviced Separately
22		218-1256		2	NUT, LOCK 1-1/16
23		237-6010		2	O-RING 3/4 ID x 3/32
24		393396A1		1	COUPLING Female

MidWestTech | Case 95XT Skid Steer Parts Catalog | Publication 7-8240na Order the manual at mid-west-tech.com >

PUMP, PISTON

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
					CYLINDER BLOCK AND SHAFT
		237637A3		1	PUMP, HYDRAULIC
					Incl. 1 - 27
					Incl. 08 -14F - 08 -14G
1		105721A1		1	COVER
2		413-616		3	BOLT 3/8 x 1
3		NSS		1	NOT SERVICED SEPARAT
					Order 244908A1
4		NSS		1	NOT SERVICED SEPARAT
					Order 244908A1
5		105717A1		1	COVER
6		181680A1		1	SPLIT PIN/SAFETY PIN
7		105719A1		1	ROTOR ASSY.
8		126-169		1	KEY,BUCKET TOOTHRT 3/32 x 3/8
9		N13994		1	SPACER
10		138-217		1	PIN, ROLL 3/16 x 7/16
11		NSS		1	NOT SERVICED SEPARAT
					Order 244908A1
12		1277297C1		1	BEARING
13		128929A1		1	PLATE, LARGE Inner
		115952A2		1	CYLINDER BLOCK
					Incl. 14 - 23
14		NSS		1	NOT SERVICED SEPARAT
15		115950A1		1	DISC
16		115948A1		1	SPRING
17		115946A1		1	DISC
18		115944A2		1	CYLINDER BLOCK
19		110873A1		3	PIN, LARGE
20		115943A1		1	SLEEVE
21		115942A1		1	GUIDE
22		NSS		1	NOT SERVICED SEPARAT
23		NSS		7	NOT SERVICED SEPARAT
		178632A1		1	COVER
					Incl. 24 - 26
24		38-11612		1	SPLIT PIN/SAFETY PIN 1/4 x 3/4
25		N13254		1	PIN

MidWestTech | Case 95XT Skid Steer Parts Catalog | Publication 7-8240na Order the manual at mid-west-tech.com >

BUCKETS, LOADER - 1860 MM (73 IN) WIDE BUCKET

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		192538A2		1	BUCKET 2083 mm (82 In) Machinery Item Incl. 2, 3
2		183948A2		1	EDGE, CUTTING Welded On
3		245109A2		2	EDGE, CUTTING Side Welded On
4		857-12030		4	SCREW M12 x 30; 10.9 LIGHT MATERIAL
5		(190079A1)		1	BUCKET 2083 mm (82 In) Machinery Item Order From WholeGoods Incl. 6, 7
6		183948A2		1	EDGE, CUTTING Welded On
7		H438935		2	EDGE, CUTTING Side Welded On EXTENSION
8		192972A2		1	RISER Used With 192538A2
9		811-12035		2	SCREW 12 x 35 mm
10		896-15012		2	WASHER 13,5 x 28 x 4 mm
11		829-1412		2	NUT M12; 10 BOLT-ON CUTTING EDGE
12		299336A1		1	EDGE, CUTTING 2083 mm (82 In)
13		420-21036		13	BOLT 5/8 x 2-1/4; 8
14		329-1010		13	NUT 5/8; 8

MidWestTech | Case 95XT Skid Steer Parts Catalog | Publication 7-8240na Order the manual at mid-west-tech.com >