821C
Wheel Loader

Parts Catalog

ASN JEE0155001

7-8581 NA

Issued 01-2003
Revised 05-2005

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-01	RADIATOR MOUNTING - COOLER, CHARGE AIR
02-02	MOUNTING, ENGINE
02-03	FAN - MOUNTING
02-04	COOLANT RECOVERY SYSTEM
02-05	AIR CLEANER - AIR INTAKE PARTS
02-06	AIR CLEANER ASSY
02-07	MUFFLER - EXHAUST SYSTEM
02-08	WATER PUMP SYSTEM
02-09	FRONT GEAR COVER
02-10	TURBOCHARGER SYSTEM - MANIFOLDS
02-11	TURBOCHARGER ASSY
02-12	WASTEGATE ACTUATOR
02-13	FILTER AND COOLER - OIL
02-14	OIL PUMP, PAN - HEATER
02-15	CYLINDER HEAD - COVER
02-16	THERMOSTAT - FILTER, WATER
02-17	CRANKCASE, BREATHER - ALTERNATOR MOUNTING
02-18	CYLINDER HEAD - VALVE MECHANISM
02-19	CAMSHAFT
02-20	CYLINDER BLOCK
02-21	CRANKSHAFT
02-22	FLYWHEEL AND HOUSING
02-23	PISTONS - CONNECTING RODS
02-24	GASKET KIT
02-24	GASKET KIT
02-25	GASKET KIT
03-01	CONTROLS - THROTTLE, FOOT
03-01A	PEDAL ASSY - THROTTLE, FOOT
03-02	FUEL TANK FILLER - SENDER
03-03	FUEL LINES - FILTER, IN-LINE FUEL
03-04	COOLER - FUEL
03-05	FUEL INJECTION SYSTEM
03-06	ANEROID AND WASTEGATE SYSTEM
03-07	FUEL FILTER - PUMP, FUEL TRANSFER
03-08	FUEL INJECTION - PUMP AND DRIVE
03-09	FUEL INJECTION NOZZLE
04-01	ALTERNATOR ASSY
04-02	STARTER ASSY
04-03	PANEL, CONTROL
04-04	PANEL, CONTROL
04-04A	HARNESS - COUPLER
04-05	HARNESS, FRONT - LAMPS AND SWITCHES
04-06	HARNESS - PEDESTAL
04-07	HARNESS - CANOPY ROOF
04-08	HARNESS - CAB ROOF
04-09	HARNESS - CAB, MAIN
04-10	HARNESS - CANOPY, MAIN
04-11	HARNESS - RIDE CONTROL
04-12	HARNESS, REAR
04-13	HARNESS, REAR CHASSIS
04-14	HARNESS, REAR - RELAY PANEL

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

04-15	BATTERY - CABLES
04-15A	ALTERNATOR - MOUNTING
04-16	ELECTRICAL - STEERING, AUXILIARY
04-17	MOUNTING - LAMPS, FRONT
04-17A	MOUNTING - LAMPS, FRONT - IF USED
04-17B	MOUNTING - LAMPS, FRONT
04-18	LAMPS, FRONT
04-18A	LAMP ASSY - LAMP, FRONT - IF USED
04-19	LAMP - TURN SIGNAL
04-20	LAMPS - CLEARANCE, FRONT AND REAR
04-21	MOUNTING - BACKUP ALARM AND REAR LAMP
04-22	MOUNTING - BACKUP ALARM
04-23	MOUNTING - LAMPS, REAR COMBINATION
04-24	LAMP ASSY, COMBINATION
04-25	LAMP, LICENSE PLATE
04-26	LAMP ASSY, FRONT AND REAR
04-27	LAMPS - TURN SIGNAL, FLASHER, STOP AND TAIL
04-28	BEACON ASSY, ROTATING - MOUNTING
04-29	BEACON ASSY, ROTATING - MOUNTING
04-30	HARNESS - CIGAR LIGHTER
04-31	CAB - WIPER, FRONT
04-32	CAB - WIPER, REAR
04-33	COLD START SYSTEM
04-34	RADIO - MOUNTING
04-35	RADIO - MOUNTING
04-36	CONVERTER, POWER OUTLET - MOUNTING
05-01	STEERING WHEEL AND COLUMN
05-02	VALVE ASSY - STEERING CONTROL
05-03	HYDRAULICS - STEERING
05-04	HYDRAULICS - STEERING
05-05	HYDRAULICS - STEERING
05-06	HYDRAULICS - STEERING, AUXILIARY
05-07	CYLINDER ASSY - STEERING
06-01	HYDRAULICS - TRANSMISSION
06-02	MOUNTING - TRANSMISSION
06-03	TRANSMISSION FILL TUBE - GAUGE, SIGHT
06-04	TRANSMISSION - CONVERTER, COVER AND INPUT SHAFT
06-05	TRANSMISSION ASSY - HOUSING
06-06	TRANSMISSION ASSY - HOUSING TUBES
06-07	TRANSMISSION - CLUTCH ASSY, FIRST
06-08	TRANSMISSION - CLUTCH ASSY, SECOND
06-09	TRANSMISSION - CLUTCH ASSY, THIRD
06-10	TRANSMISSION - CLUTCH ASSY, FOURTH
06-11	TRANSMISSION - CLUTCH ASSY, FORWARD
06-12	TRANSMISSION - CLUTCH ASSY, REVERSE
06-13	TRANSMISSION - SHAFT, OUTPUT
06-14	TRANSMISSION - POWER TAKE OFF
06-15	TRANSMISSION - VALVE PLATES
06-16	TRANSMISSION - VALVE, CONTROL
06-16A	TRANSMISSION - VALVE, CONTROL
06-16B	TRANSMISSION - VALVE, REGULATOR AND OIL PUMP

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

06-16C	TRANSMISSION - SENSOR, SPEED AND PUMP COVER
06-17	TRANSMISSION - FILTER, OIL AND FILLER COVER
06-18	AXLE - MOUNTING (FRONT & REAR)
06-19	AXLE, FRONT - HOUSING
06-20	AXLE, FRONT - HUB, DISC BRAKES
06-20A	AXLE, FRONT - HUB, PLANETARY
06-21	AXLE, FRONT - DIFFERENTIAL CARRIER
06-21A	AXLE, FRONT - DIFFERENTIAL
06-22	AXLE, REAR - HOUSING
06-23	AXLE, REAR - DIFFERENTIAL CARRIER
06-23A	AXLE, REAR - DIFFERENTIAL
06-24	AXLE, REAR - HUB, DISC BRAKES
06-24A	AXLE, REAR - HUB, PLANETARY
06-25	DRIVE SHAFT, FRONT - BEARING, SUPPORT AND LUBE LINE
06-26	DRIVE SHAFT, CENTER AND REAR
06-27	WHEELS
07-01	BRAKE, PARKING
07-02	BRAKE - PEDALS
07-03	HYDRAULICS - BRAKE, MAIN
07-04	HYDRAULICS - BRAKE, MAIN
07-05	HYDRAULICS - BRAKE, MAIN
07-06	HYDRAULICS - BRAKE, MAIN
07-07	HYDRAULICS - BRAKE, MAIN
07-08	HYDRAULICS - BRAKE, MAIN
07-09	VALVE ASSY - BRAKE
07-10	ACCUMULATOR - BRAKE
08-01	RESERVOIR
08-02	HYDRAULICS - OIL COOLER AND LINES
08-03	HYDRAULICS - VALVE, PRIORITY AND UNLOADING
08-04	HYDRAULICS - RESERVOIR TO HYDRAULIC PUMP
08-05	HYDRAULICS - PRIORITY VALVE
08-06	HYDRAULICS - VALVE, BYPASS TO FILTER
08-06A	HYDRAULICS - FILTER TO RESERVOIR
08-07	HYDRAULICS - LOADER LIFT
08-08	HYDRAULICS - LOADER BUCKET
08-09	HYDRAULICS - LOADER AUXILIARY
08-10	HYDRAULICS - FAN DRIVE
08-10A	HYDRAULICS - COUPLER LOCKING
08-10B	HYDRAULICS - COUPLER
08-11	PUMP ASSY
08-11A	VALVE ASSY - FLOW CONTROL
08-11B	VALVE, UNLOADING
08-11C	VALVE ASSY - SOLENOID, COUPLER LOCKING
08-12	VALVE ASSY - LOADER CONTROL, TWO SPOOL
08-13	VALVE ASSY - LOADER CONTROL, THREE SPOOL
08-14	VALVE ASSY - LOADER CONTROL, FOUR SPOOL
08-15	VALVE SECTION - LOADER LIFT
08-16	VALVE SECTION - LOADER BUCKET TILT
08-17	VALVE SECTION - LOADER AUXILIARY
08-18	VALVE ASSY - RELIEF, CIRCUIT
08-19	CYLINDER ASSY - LOADER LIFT

Order the manual at mid-west-tech.com >

PANEL, CONTROL

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION WITH CANOPY
		REF			INSTRUCTION NORTH AMERICA ONLY
1		197377A2		1	PANEL Control
2		283426A1		1	DECAL Canopy Switches
3		239225A1		4	SCREW M4 x 12
4		REF		1	INSTRUCTION HARNESS Cab Main; SEE FIG 04-09
5		374421A4		1	SWITCH Declutch
6		374422A2		1	SWITCH Detent
7		374427A2		1	SWITCH Return To Travel
8		374431A2		1	SWITCH Trans, Auto
9		126844A1		7	PLUG Switch Opening
10		1994716C1		1	SWITCH Lamp
11		495-11053		2	WASHER 17/32 x 1-1/16 x 3/32
12		1994720C1		1	KNOB Control
13		400834A1		1	SWITCH Transmission Enable

MidWestTech | Case 821C Wheel Loader Parts Catalog | Publication 7-8581na Order the manual at mid-west-tech.com >

AXLE, FRONT - DIFFERENTIAL

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		293102A2		1	AXLE Front, With Limited Slip; Incl. Ref 1 - 13; Also Includes Figures 06-19 - 06-21A
		87313934		1	AXLE, FRONT Front, With Limited Slip; Incl. Ref 1 - 13; Also Includes Figures 06-19 - 06-21A; Oil Filled; Components Same As 293102A2
		384429A1		1	DIFFERENTIAL Includes 384473A1 Limited Slip Differential, Ref 1 - 13; Also Includes Figure 06-21
1		384473A1		1	AXLE, DIFF. Limited Slip Differential; Incl. Ref 2 - 13
2		384474A1		1	HOUSING
3		242155A1		4	DISC, CLUTCH 2,9 mm; Outer
3		242156A1		4	DISC, CLUTCH 3,1 mm; Outer
3		242157A1		4	DISC, CLUTCH 2,7 mm; Outer
3		242158A1		4	DISC, CLUTCH 3,3 mm; Outer
4		242159A1		4	DISC, CLUTCH Intermediate; Inner Clutch
5		8605362		2	RING Pressure
6		242160A1		2	PINION 16T; Side
7		120017A1		2	WASHER Outer
8		120018A1		4	PINION
9		120019A1		2	WASHER Inner
10		120020A1		2	PIN, LARGE
11		184716A1		20	SCREW
12		385426A1		1	COVER
13		193152A1		2	BOLT

MidWestTech | Case 821C Wheel Loader Parts Catalog | Publication 7-8581na Order the manual at mid-west-tech.com >

SEAT ASSY, AIR SUSPENSION

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		399259A1		1	SEAT ASSY. Cloth Air Suspension Incl. 1 - 27
1		406866A1		1	CUSHION ASSY. See Figure 09-26, REF 1, 2
2		406867A1		1	CUSHION, SEAT
2		(87344451)		1	Cushion, Seat; Cloth; Replaces 406867A1 See Figure 09-26, REF 3, 4
3		345764A1		1	BACKREST Backrest See Figure 09-26, REF 5-7
4		345727A1		1	BACKREST
5		398152A1		1	ARMREST Right Hand
6		398151A1		1	ARMREST Left Hand
7		398149A1		1	COVER
8		345783A1		1	RAIL ASSY. Seat Slide Rails See Figure 09-26, REF 45
9		345767A1		1	SUPPORT Lumbar Support Not Illustrated See Figure 09-26, REF 31-40
10		345747A1		1	FRAME Not Illustrated See Figure 09-26, REF 41-41B
11		345785A1		1	BELT Tether Belt Not Illustrated See Figure 09-26, REF 44
12		345778A1		1	SET OF PARTS Hardware Backrest Adjustment Not Illustrated

MidWestTech | Case 821C Wheel Loader Parts Catalog | Publication 7-8581na Order the manual at mid-west-tech.com >