CX25
Compact Excavator

Parts Catalog

Bur 7-8761NA

CASE

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02 -01	00	ENGINE, MOUNTING
02 -02	00	ENGINE ASSY
02 -03	00	ENGINE, CONTROL ASSY WITH DECELERATION
02 -04	00	ENGINE, CONTROL ASSY WITHOUT DECELERATION
02 -05	00	AIR CLEANER ASSY
02 -06	00	MUFFLER ASSY
02 -07	00	RADIATOR MOUNTING
02 -08	00	RADIATOR
02 -09	00	WATER PUMP SYSTEM
02 -10	00	HOUSING, GEAR
02 -11	00	MANIFOLD - INTAKE
02 -12	00	MANIFOLD - EXHAUST
02 -13	00	OIL PUMP
02 -14	00	CYLINDER HEAD AND COVER
02 -15	00	CAMSHAFT AND DRIVING GEAR
02 -16	00	CYLINDER BLOCK
02 -17	00	CRANKSHAFT AND PISTON
02 -18	00	FLYWHEEL HOUSING AND OIL PAN
02 -19	00	ENGINE FILTERS
02 -20	00	GASKET KIT
03 -01	00	FUEL TANK
03 -02	00	FUEL LINES
03 -03	00	FUEL LINES
03 -04	00	WATER SEPARATOR ASSY
03 -05	00	FUEL FILTER
03 -06	00	FUEL INJECTION PUMP
03 -07	00	GOVERNOR, FUEL INJECTION PUMP
03 -08	00	FUEL INJECTION VALVE
04 -01	00	STARTER MOTOR
04 -02	00	ALTERNATOR
04 -03	00	RELAY BOX ASSY - CANOPY
04 -04	00	RELAY BOX ASSY - CAB
04 -05	00	RELAY ASSY - CANOPY
04 -06	00	RELAY ASSY - CAB
04 -07	00	HARNESS, MAIN - CHASSIS, UPPERSTRUCTURE - CANOPY
04 -08	00	HARNESS, MAIN - CHASSIS, UPPERSTRUCTURE - CAB
04 -09	00	HARNESS ASSY - ENGINE
04 -10	00	BATTERY - CABLES
04 -11	00	BATTERY MOUNTING
04 -12	00	LAMP ASSY - BOOM
04 -13	00	LAMP MOUNTING - BOOM
04 -14	00	RADIO MOUNTING
04 -15	00	ALARM ASSY
05 -01	00	UNDERCARRIAGE
05 -02	00	TRACK, RUBBER
05 -03	00	SHOE, TRACK
05 -04	00	TRACK - IDLER
05 -05	00	TRACK - IDLER ASSY
05 -06	00	TRACK - ADJUSTER
05 -07	00	TRACK - ROLLER ASSY
06 -01	00	POWER TAKE OFF ASSY

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

06 -02	00	MOTOR - TRACK DRIVE
06 -03	00	MOTOR - TRACK DRIVE UPPER SECTION
08 -01	00	HYDRAULIC RESERVOIR ASSY
08 -02	00	HYDRAULIC LINES - HYDRAULIC PUMP
08 -03	00	HYDRAULIC LINES - SWING CYLINDER
08 -04	00	HYDRAULIC LINES - UPPER
08 -05	00	HYDRAULIC LINES - UPPER (NIBBLER & BREAKER)
08 -06	00	HYDRAULIC LINES - RETURN (NIBBLER & BREAKER)
08 -07	00	HYDRAULIC LINES - RETURN (BOOM LOCK)
08 -08	00	HYDRAULICS - PILOT CONTROL LINES, REMOTE CONTROL
08 -09	00	HYRDAULICS - PILOT CONTROL LINES, MAIN
08 -10	00	HYDRAULICS - PILOT CONTROL LINES, TRAVEL
08 -11	00	HYDRAULICS - PILOT CONTROL LINES, SWING
08 -11A	00	HYDRAULICS - PILOT CONTROL LINES, SWING
08 -12	00	HYDRAULICS - PILOT CONTROL LINES, TRAVEL ALARM
08 -13	00	HYDRAULICS - PILOT CONTROL LINES, SWING - TRAVEL ALARM
08 -13A	00	HYDRAULICS - PILOT CONTROL LINES, SWING - TRAVEL ALARM
08 -14	00	HYDRAULIC LINES - VALVE, SOLENOID - SWING
08 -15	00	HYDRAULIC LINES - LOWER
08 -16	00	HYDRAULIC LINES - BOOM
08 -17	00	HYDRAULIC LINES - BOOM (NIBBLER & BREAKER)
08 -18	00	HYDRAULIC LINES - ARM
08 -19	00	PUMP ASSY
08 -20	00	PUMP - SHAFT
08 -21	00	PUMP - BLOCK
08 -22	00	PUMP - PISTON
08 -23	00	PUMP - COVER
08 -24	00	PUMP - SPRING
08 -25	00	PUMP - GEAR
08 -26	00	PUMP - HOUSING
08 -27	00	PUMP
08 -28	00	MOUNTING - SWING MOTOR
08 -29	00	MOTOR ASSY, SWING (PV15V00014F1)
08 -30	00	MOTOR ASSY, SWING (PV15V00017F1)
08 -31	00	HYDRAULICS - JOINT, SWIVEL CENTER
08 -32	00	VALVE MOUNTING
08 -33	00	VALVE ASSY - CONTROL
08 -34	00	VALVE ASSY - DOZER BLADE
08 -35	00	VALVE ASSY - SWING
08 -36	00	VALVE ASSY - SUPPLY
08 -37	00	SERVICE VALVE
08 -38	00	VALVE ASSY - BOOM SWING
08 -39	00	VALVE ASSY - ARM
08 -40	00	VALVE ASSY - TRAVEL CONTROL RIGHT HAND (CX31 A
08 -41	00	VALVE ASSY - STRAIGHT TRAVEL
08 -42	00	VALVE ASSY - TRAVEL CONTROL LEFT HAND
08 -43	00	VALVE ASSY - BOOM
08 -44	00	VALVE ASSY - BOOM, OVERLOAD
08 -45	00	VALVE ASSY - BUCKET
08 -46	00	VALVE ASSY - PRESSURE RELIEF (PM22V00005F1)
08 -47	00	VALVE ASSY - PRESSURE RELIEF (PM22V00006F1)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

08 -48	00	VALVE ASSY - BLEEDER
08 -49	00	VALVE ASSY - PILOT (PA30V00002F1)
08 -50	00	VALVE ASSY - PILOT (PA30V00002F2)
08 -51	00	VALVE ASSY - PILOT (PA30V00003F3)
08 -52	00	VALVE ASSY - PILOT, TRAVEL
08 -53	00	VALVE ASSY - SOLENOID, TRAVEL ALARM
08 -54	00	VALVE, SOLENOID - TRAVEL ALARM
08 -55	00	VALVE ASSY - SOLENOID, PRESSURE RELIEF
08 -56	00	VALVE ASSY - STOP
08 -57	00	VALVE ASSY - SHUTTLE
08 -58	00	VALVE ASSY, SELECTOR - PILOT
08 -59	00	VALVE ASSY (PH50T00001F1)
08 -60	00	CYLINDER ASSY, BOOM - CANOPY
08 -61	00	CYLINDER ASSY, BOOM - CAB
08 -62	00	CYLINDER ASSY, ARM
08 -63	00	CYLINDER ASSY, BUCKET
08 -64	00	CYLINDER, DOZER BLADE
08 -65	00	CYLINDER, SWING
08 -66	00	HYDRAULIC TANK - FILTERS
08 -67	00	MOUNTING - BOOM AND ARM CYLINDERS
09 -01	00	TURNTABLE BEARING
09 -02	00	TURNTABLE - ACCESS COVERS
09 -03	00	COUNTERWEIGHT
09 -04	00	COUNTERWEIGHT - GAIN
09 -05	00	BRACKET ASSY - SWING, CAB
09 -06	00	BRACKET ASSY - SWING, CANOPY
09 -07	00	COVER - SUPPORTS, CANOPY
09 -08	00	COVER - SUPPORTS, CAB
09 -09	00	COVER - PANELS, CANOPY
09 -10	00	COVER - PANELS, CAB
09 -11	00	COVER AND LOCK ASSY
09 -12	00	PLATES, FLOOR - CANOPY
09 -13	00	PLATES, FLOOR - CAB
09 -14	00	MAT, FLOOR - HAND CONTROL (OPTIONAL)
09 -15	00	CANOPY
09 -16	00	CAB - GLASS
09 -17	00	CAB - WINDOW, FRONT
09 -18	00	CAB DOOR
09 -19	00	CAB - ELECTRICAL, CONNECTIONS
09 -20	00	CAB MOUNTING
09 -21	00	CAB HEAD GUARD
09 -22	00	SEAT MOUNTING AND SEAT BELT
09 -23	00	CONTROLS - OPERATORS COMPARTMENT
09 -24	00	CONTROLS - OPERATORS COMPARTMENT (A)
09 -25	00	STAND CONTROL - CANOPY
09 -26	00	STAND CONTROL - CAB
09 -27	00	CONTROL BOX ASSY - LEFT HAND
09 -28	00	CONTROL BOX ASSY - RIGHT HAND
09 -29	00	LEVER ASSY - CANOPY
09 -30	00	LEVER ASSY - CAB
09 -31	00	CONTROL PEDAL AND LEVER ASSY

Order the manual at mid-west-tech.com >