CX47
Compact Excavator

Parts Catalog

7-8781NA

MidWestTech | Case CX47 Compact Excavator Parts Catalog | Publication 7-8781

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-01	00	ENGINE, MOUNTING
02-02	00	ENGINE ASSY
02-03	00	ENGINE, CONTROL ASSY WITH DECELERATION
02-04	00	ENGINE, CONTROL ASSY WITHOUT DECELERATION
02-05	00	AIR CLEANER ASSY - CANOPY
02-06	00	AIR CLEANER ASSY - CAB
02-07	00	AIR CLEANER - ELEMENT
02-08	00	MUFFLER ASSY
02-09	00	RADIATOR MOUNTING
02-10	00	RADIATOR
02-11	00	WATER PUMP SYSTEM
02-12	00	HOUSING, GEAR
02-13	00	MANIFOLD - INTAKE
02-14	00	MANIFOLD - EXHAUST
02-15	00	OIL PUMP
02-16	00	CYLINDER HEAD AND COVER
02-17	00	CAMSHAFT AND DRIVING GEAR
02-18	00	CYLINDER BLOCK
02-19	00	CRANKSHAFT AND PISTON
02-20	00	FLYWHEEL HOUSING AND OIL PAN
02-21	00	ENGINE FILTERS
02-22	00	GASKET KIT
03-01	00	FUEL TANK
03-02	00	FUEL LINES
03-03	00	WATER SEPARATOR ASSY
03-04	00	FUEL FILTER
03-05	00	FUEL INJECTION PUMP
03-06	00	GOVERNOR, FUEL INJECTION PUMP
03-07	00	FUEL INJECTION VALVE
04-01	00	STARTER MOTOR
04-02	00	ALTERNATOR
04-03	00	RELAY BOX ASSY - CANOPY
04-05	00	RELAY ASSY - CANOPY
04-06	00	RELAY ASSY - CAB
04-07	00	HARNESS, MAIN - CHASSIS, UPPERSTRUCTURE - CANOPY
04-08	00	HARNESS, MAIN - CHASSIS, UPPERSTRUCTURE - CAB
04-09	00	HARNESS ASSY - ENGINE
04-10	00	BATTERY - CABLES
04-11	00	BATTERY MOUNTING
04-12	00	LAMP ASSY - BOOM
04-13	00	LAMP MOUNTING - BOOM
04-14	00	RADIO MOUNTING
04-15	00	ALARM ASSY
04-16	00	HORN - MOUNTING
05-01	00	UNDERCARRIAGE
05-02	00	UNDERCARRIAGE - TRACK, RUBBER
05-03	00	TRACK, RUBBER
05-04	00	SHOE, TRACK
05-05	00	TRACK - IDLER
05-06	00	TRACK - IDLER ASSY
05-07	00	TRACK - ADJUSTER

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

05-08	00	TRACK - ROLLER ASSY
05-09	00	TRACK - ROLLER, UPPER
06-01	00	POWER TAKE OFF ASSY - CANOPY
06-02	00	POWER TAKE OFF ASSY - CAB
06-03	00	MOTOR - TRACK DRIVE
06-04	00	MOTOR - TRACK DRIVE UPPER SECTION
08-01	00	HYDRAULIC RESERVOIR ASSY
08-02	00	HYDRAULIC LINES - HYDRAULIC PUMP
08-03	00	HYDRAULIC LINES - HYDRAULIC PUMP - CAB
08-04	00	HYDRAULIC LINES - UPPER
08-05	00	HYDRAULIC LINES - UPPER (NIBBLER & BREAKER)
08-06	00	HYDRAULIC LINES - RETURN (NIBBLER & BREAKER)
08-07	00	HYDRAULICS - PILOT CONTROL LINES, REMOTE CONTROL
08-08	00	HYRDAULICS - PILOT CONTROL LINES, MAIN
08-09	00	HYDRAULICS - PILOT CONTROL LINES, HAND CONTROL
08-10	00	HYDRAULICS - PILOT CONTROL LINES, TRAVEL
08-11	00	HYDRAULICS - PILOT CONTROL LINES, SWING
08-11A	00	HYDRAULICS - PILOT CONTROL LINES, SWING
08-12	00	HYDRAULIC LINES - VALVE, SOLENOID
08-13	00	HYDRAULIC LINES - LOWER
08-14	00	HYDRAULIC LINES - BOOM
08-15	00	HYDRAULIC LINES - BOOM (NIBBLER & BREAKER)
08-16	00	HYDRAULIC LINES - ARM
08-17	00	PUMP ASSY (PY10V00009F1)
08-18	00	PUMP ASSY (PY10V00010F1)
08-19	00	PUMP - SHAFT
08-20	00	PUMP - BLOCK
08-21	00	ROTARY ASSY
08-22	00	PUMP - COVER
08-23	00	PUMP - SPRING
08-24	00	PUMP - PISTON
08-25	00	PUMP - GEAR
08-26	00	PUMP
08-27	00	PUMP - SILENCER ASSY
08-28	00	MOUNTING - SWING MOTOR
08-29	00	MOTOR ASSY, SWING (PY15V00007F1)
08-30	00	MOTOR ASSY, SWING (PY15V00010F1)
08-31	00	REDUCTION - MOTOR, SWING
08-32	00	HYDRAULICS - JOINT, SWIVEL CENTER
08-33	00	VALVE MOUNTING
08-34	00	VALVE ASSY - CONTROL
08-35	00	VALVE ASSY - DOZER BLADE
08-36	00	VALVE ASSY - SWING
08-37	00	VALVE ASSY - SUPPLY
08-38	00	SERVICE VALVE
08-39	00	VALVE ASSY - BOOM, SWING
08-40	00	VALVE ASSY - BOOM, OVERLOAD
08-41	00	VALVE ASSY - ARM
08-42	00	VALVE ASSY - TRAVEL CONTROL RIGHT HAND
08-43	00	VALVE ASSY - STRAIGHT TRAVEL
08-44	00	VALVE ASSY - TRAVEL CONTROL LEFT HAND

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

08-45	00	VALVE ASSY - BUCKET
08-46	00	VALVE ASSY - PRESSURE RELIEF (PH22V00003F1)
08-47	00	VALVE ASSY - PRESSURE RELIEF (PH22V00008F1)
08-48	00	VALVE ASSY - PRESSURE RELIEF (PM22V00005F1)
08-49	00	VALVE ASSY - PILOT (PA30V00002F1)
08-50	00	VALVE ASSY - PILOT (PA30V00002F2)
08-51	00	VALVE ASSY - PILOT (PA30V00003F3)
08-52	00	VALVE ASSY - PILOT, TRAVEL
08-53	00	VALVE ASSY - SOLENOID, (PH35V00001F2)
08-54	00	VALVE ASSY - SOLENOID, TRAVEL ALARM
08-55	00	VALVE ASSY - SOLENOID, PRESSURE RELIEF
08-56	00	VALVE ASSY - SOLENOID (PY35V00005F1)
08-57	00	VALVE ASSY - SOLENOID (PE35V00001F1)
08-59	00	VALVE ASSY - SELECTOR
08-60	00	VALVE ASSY - REDUCTION
08-61	00	CYLINDER ASSY, BOOM
08-62	00	CYLINDER ASSY, ARM
08-63	00	CYLINDER ASSY, BUCKET
08-64	00	CYLINDER, DOZER BLADE
08-65	00	CYLINDER, SWING
08-66	00	HYDRAULIC TANK - FILTERS
09-01	00	TURNTABLE BEARING
09-02	00	TURNTABLE
09-03	00	TURNTABLE - ACCESS COVERS
09-04	00	COUNTERWEIGHT
09-05	00	BRACKET ASSY - SWING, CANOPY
09-06	00	BRACKET ASSY - SWING, CAB
09-07	00	COVER - SUPPORTS, CANOPY
09-08	00	COVER - SUPPORTS, CAB
09-09	00	COVER - PANELS, CANOPY
09-10	00	COVER - PANELS, CAB
09-11	00	COVER AND LOCK ASSY
09-12	00	PLATES, FLOOR - CANOPY
09-13	00	PLATES, FLOOR - CAB
09-14	00	MAT, FLOOR - HAND CONTROL (OPTIONAL)
09-15	00	CANOPY
09-16	00	CAB - GLASS
09-17	00	CAB - WINDOW, FRONT
09-18	00	CAB DOOR
09-19	00	CAB - ELECTRICAL, CONNECTIONS
09-20	00	CAB MOUNTING
09-21	00	CAB HEAD GUARD
09-22	00	SEAT MOUNTING AND SEAT BELT
09-23	00	CONTROLS - OPERATORS COMPARTMENT
09-24	00	CONTROLS - OPERATORS COMPARTMENT (A)
09-25	00	STAND CONTROL - CANOPY
09-26	00	STAND CONTROL - CAB
09-27	00	CONTROL BOX ASSY - LEFT HAND
09-28	00	CONTROL BOX ASSY - RIGHT HAND
09-29	00	LEVER ASSY - CANOPY
09-30	00	LEVER ASSY - CAB

Order the manual at mid-west-tech.com >