CX225SR
Excavator

Parts Catalog

7-8970NA

CASE
CONSTRUCTION

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-01	ENGINE MOUNTING - ENGINE
02-02	AIR CLEANER
02-03	EXHAUST SYSTEM - MUFFLER
02-04	RADIATOR AND CONNECTIONS
02-05	RADIATOR ASSY
02-06	DRIVE BELT GUARD - VENTILATOR
02-07	WATER PUMP SYSTEM
02-08	WATER CIRCUIT - THERMOSTAT
02-09	MANIFOLD - EXHAUST
02-10	MANIFOLD - INTAKE
02-11	TURBOCHARGER SYSTEM
02-12	TURBOCHARGER
02-13	FRONT TIMING GEAR COVER
02-14	OIL PAN
02-15	OIL PUMP
02-16	OIL COOLER
02-17	OIL FILTER
02-18	OIL CIRCUIT
02-19	CYLINDER HEAD
02-20	CAMSHAFT - VALVE MECHANISM
02-21	CYLINDER HEAD COVER
02-22	CYLINDER BLOCK
02-23	CYLINDER BLOCK - BREATHER
02-24	FLYWHEEL HOUSING
02-25	PISTONS AND CRANKSHAFT - FLYWHEEL
02-26	ALTERNATOR MOUNTING
02-27	PACKAGE, SEALS - ENGINE
03-01	FUEL TANK
03-02	FUEL LINES
03-03	WATER SEPARATOR ASSY
03-04	ENGINE SHUTOFF - SUPPORT
03-05	FUEL SYSTEM
03-06	FUEL FILTER
03-07	FUEL INJECTION PUMP AND DRIVE
03-08	FUEL INJECTION PUMP
03-09	FUEL INJECTION PUMP
03-10	FUEL INJECTION PUMP - CONTROL
03-11	FUEL INJECTION PUMP - CONTROL
03-12	FEED PUMP - FUEL INJECTION PUMP
03-13	FEED PUMP - FUEL INJECTION PUMP
03-14	FUEL INJECTION - NOZZLE
04-01	HARNESS, MAIN - CHASSIS, UPPERSTRUCTURE
04-02	HARNESS, MAIN - CLAMPS AND RETAINERS
04-03	ELECTRICAL - CAB
04-04	ELECTRICAL PARTS - MODELS WITH LOAD HOLD
04-05	TRAVEL ALARM
04-06	RADIO
04-07	CONVERTER
04-08	HORN
04-09	LAMP, WORK - CAB
04-10	LAMP, WORK - BOOM

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

04-11	WINDSHIELD WASHER
04-12	BATTERIES
04-13	ELECTRICAL ACCESSORIES - ENGINE
04-14	STARTER ASSY
04-15	ALTERNATOR ASSY
05-01	UNDERCARRIAGE
05-02	GUIDE, CHAIN
05-03	UNDERCARRIAGE COVER, LOWER
05-04	TRACK CHAINS - STEEL (P.I.N. DAC0825101 - DAC0815118)
05-05	TRACK CHAINS - STEEL (P.I.N. DAC0825119 -)
05-06	TRACK - IDLER
05-07	TRACK - ADJUSTER
05-08	TRACK - ROLLER, UPPER
05-09	TRACK - ROLLER, LOWER
06-01	TRACK DRIVE ASSY
06-02	MOTOR ASSY - GEAR ASSY, REDUCTION
06-03	MOTOR ASSY - PISTON
06-04	MOTOR ASSY - PISTON
06-05	HYDRAULICS - TRACK DRIVE
06-06	HYDRAULICS - TRAVEL
08-01	HYDRAULIC RESERVOIR
08-02	PUMP ASSY, HYDRAULIC - COUPLING
08-03	PUMP ASSY, HYDRAULIC
08-04	PUMP ASSY, HYDRAULIC - COUPLING
08-05	HYDRAULICS - PUMP SUCTION LINE
08-06	HYDRAULICS - CONTROL VALVE SUPPLY
08-07	HYDRAULICS - RESERVOIR RETURN
08-08	HYDRAULICS - BYPASS FILTER
08-09	HYDRAULICS - DRAIN LINE
08-10	HYDRAULICS - SWING
08-11	HYDRAULICS - BOOM
08-12	HYDRAULICS - BOOM, DOUBLE ACTING CIRCUIT
08-13	HYDRAULICS - BOOM CYLINDER, MODELS WITHOUT LOAD HOLD
08-14	HYDRAULICS - BOOM CYLINDER, MODELS WITH LOAD HOLD
08-15	HYDRAULICS - BOOM CYLINDER, MODELS WITH LOAD HOLD
08-16	HYDRAULICS - ARM AND BUCKET
08-17	HYDRAULICS - ARM CYLINDER, MODELS WITHOUT LOAD HOLD
08-18	HYDRAULICS - ARM CYLINDER, MODELS WITH LOAD HOLD
08-19	HYDRAULICS - ARM CYLINDER, MODELS WITH LOAD HOLD
08-20	HYDRAULICS - BUCKET, 2,40 METER (7 FT 10 IN) ARM
08-21	HYDRAULICS - BUCKET, 3,0 METER (9 FT 10 IN) ARM
08-22	PILOT CONTROL LINES, TRAVEL - MODELS WITHOUT LOAD HOLD
08-23	PILOT CONTROL LINES, ATTACHMENT - MODELS WITHOUT LOAD HOLD
08-24	PILOT CONTROL LINES, ATTACHMENT - MODELS WITHOUT LOAD HOLD
08-25	PILOT CONTROL LINES, CONTROL VALVE - MODELS WITHOUT LOAD HOLD
08-26	PILOT CONTROL LINES, TRAVEL - MODELS WITH CONTROL SELECTOR VALVE
08-27	PILOT CONTROL LINES, ATTACHMENT - MODELS WITH CONTROL SELECTOR VALVE
08-28	PILOT CONTROL LINES, ATTACHMENT - MODELS WITH CONTROL SELECTOR VALVE
08-29	PILOT CONTROL LINES, CONTROL VALVE - MODELS WITH CONTROL SELECTOR VALVE
08-30	PILOT CONTROL LINES - MODELS WITH LOAD HOLD

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

08-31	HYDRAULICS - PILOT PRESSURE, RETURN LINES
08-32	HYDRAULICS - PILOT PRESSURE, RETURN LINES
08-33	HYDRAULICS, AUXILIARY - SINGLE ACTING CIRCUIT
08-34	HYDRAULICS, AUXILIARY - SINGLE ACTING CIRCUIT
08-35	HYDRAULICS, AUXILIARY - DOUBLE ACTING CIRCUIT (PIN DAC0822101 - DAC0822106)
08-36	HYDRAULICS, AUXILIARY - DOUBLE ACTING CIRCUIT (PIN DAC0822101 - DAC0822106)
08-37	HYDRAULICS, AUXILIARY - DOUBLE ACTING CIRCUIT (PIN DAC0822107 -)
08-38	HYDRAULICS, AUXILIARY - DOUBLE ACTING CIRCUIT (PIN DAC0822107 -)
08-39	HYDRAULICS, AUXILIARY - MULTI-PURPOSE + 3 WAY VALVE
08-40	HYDRAULICS, AUXILIARY - MULTI-PURPOSE + 3 WAY VALVE
08-41	HYDRAULICS, AUXILIARY - MULTI-PURPOSE + 3 WAY VALVE
08-42	PLUG - STANDARD
08-43	PLUG - BREAKER
08-44	PLUG - BREAKER & CRUSHER, BREAKER & HBCV
08-45	PLUG - BREAKER & CRUSHER & HBCV
08-46	OPTIONS, AUXILIARY HYDRAULICS - 2,4 M ARM
08-47	OPTIONS, AUXILIARY HYDRAULICS - 3,0 M ARM
08-48	CONTROL VALVE
08-49	MOUNTING - SWING MOTOR (KRC0214)
08-50	SWING MOTOR (KRC0214)
08-51	MOUNTING - SWING MOTOR (KRC0228)
08-52	SWING MOTOR
08-53	SWING MOTOR (KRC0228)
08-54	JOINT, SWIVEL CENTER (- P.I.N. DAC0825130)
08-55	JOINT, SWIVEL CENTER (P.I.N. DAC0825131 -)
08-56	CONTROL VALVE - SUPPORT
08-57	VALVE ASSY, CONTROL
08-58	VALVE ASSY, CONTROL
08-59	VALVE ASSY, CONTROL
08-60	VALVE ASSY, CONTROL
08-61	VALVE ASSY, CONTROL
08-62	VALVE ASSY, CONTROL
08-63	VALVE ASSY - PILOT CONTROL LINES
08-64	VALVE ASSY - HAND CONTROL
08-65	VALVE ASSY, REMOTE CONTROL
08-66	VALVE ASSY - PEDAL CONTROL
08-67	VALVE ASSY, RELIEF - FLOW CONTROL
08-68	VALVE ASSY, RELIEF - FLOW CONTROL
08-69	VALVE ASSY, RELIEF - MODELS WITH LOAD HOLD
08-70	VALVE, CUSHION - PILOT CONTROL LINES
08-71	VALVE ASSY - PILOT CONTROL LINES
08-72	VALVE, SOLENOID
08-73	VALVE, SOLENOID
08-74	CYLINDER ASSY, BOOM, RIGHT HAND - MODELS WITHOUT LOAD HOLD
08-75	CYLINDER ASSY, BOOM, LEFT HAND - MODELS WITHOUT LOAD HOLD
08-76	CYLINDER ASSY, BOOM - MODELS WITH LOAD HOLD
08-77	CYLINDER ASSY, ARM - MODELS WITHOUT LOAD HOLD
08-78	CYLINDER ASSY, ARM - MODELS WITH LOAD HOLD
08-79	CYLINDER ASSY - BUCKET

Order the manual at mid-west-tech.com >