PARTS CATALOG

LW110.B
Wheel Loader

Revision Date: 08/2004

7-9071NA

MidWestTech | New Holland LW110.B Wheel Loader Parts Catalog | Publication 7_9071

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02 -01	MOUNTING, ENGINE
02 -02	RADIATOR - MOUNTING
02 -03	FAN - FAN BELT
02 -04	COOLANT RECOVERY SYSTEM
02 -05	COOLING SYSTEM
02 -06	COOLING SYSTEM - MOTOR, DRIVE (MOUNTING)
02 -07	COOLING SYSTEM - MOTOR, DRIVE (STANDARD FAN DRIVE)
02 -08	COOLING SYSTEM - MOTOR, DRIVE (REVERSIBLE FAN DRIVE)
02 -09	VALVE ASSY - COOLING SYSTEM
02 -10	AIR CLEANER - AIR INTAKE PARTS
02 -10A	AIR CLEANER ASSY
02 -11	MUFFLER - EXHAUST SYSTEM
02 -12	MUFFLER - EXHAUST SYSTEM - IF USED
02 -13	MUFFLER - EXHAUST SYSTEM - STANDARD/ASPIRATOR SPARK ARRESTER
02 -13A	MUFFLER - SPARK ARRESTER/ASPIRATOR
02 -14	ENGINE
02 -15	ENGINE, OIL
02 -16	OIL PUMP - ENGINE
02 -17	OIL FILTERS - ENGINE
02 -18	OIL FILTER AND COOLER
02 -19	OIL PUMP, PAN
02 -20	OIL PUMP, PAN - DRAIN LINE
02 -21	BREATHER - ENGINE
02 -22	TURBOCHARGER SYSTEM
02 -23	TURBOCHARGER
02 -24	WATER PUMP
02 -25	WATER PUMP - CONTROL
02 -26	CYLINDER BLOCK
02 -27	CYLINDER BLOCK - PLUG ASSY
02 -28	CYLINDER BLOCK
02 -29	FLYWHEEL HOUSING
02 -30	GEAR COVER - REAR HOUSING
02 -31	FRONT GEAR COVER
02 -31A	FRONT GEAR COVER - PLATE
02 -32	CYLINDER HEAD - COVERS
02 -33	CYLINDER HEAD - VALVE MECHANISM
02 -34	CYLINDER HEAD
02 -35	MANIFOLD - INTAKE
02 -36	MANIFOLD - EXHAUST
02 -37	CAMSHAFT
02 -38	CRANKSHAFT
02 -39	CRANKSHAFT - PULLEY
02 -40	FLYWHEEL - ENGINE
02 -41	CONNECTING ROD
02 -42	PISTONS - CONNECTING ROD
02 -43	COOLING SYSTEM - ENGINE
02 -44	THERMOSTAT - ENGINE COOLING SYSTEM
02 -45	ENGINE - LIFT HOOK
02 -46	ENGINE - BLOCK HEATER
03 -01	CONTROLS - THROTTLE, FOOT
03 -02	PEDAL ASSY - THROTTLE, FOOT
03 -03	FUEL LINES - FILTER, IN-LINE FUEL

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03 -04	FUEL TANK FILLER - SENDER
03 -05	FUEL PUMP
03 -06	FUEL INJECTION PUMP
03 -07	FUEL INJECTION SYSTEM - PUMP MOUNTING
03 -08	FUEL INJECTION SYSTEM - FUEL, SUPPLY
03 -09	FUEL INJECTION SYSTEM - DRAIN LINE
03 -10	FUEL INJECTION SYSTEM
03 -11	FUEL INJECTION SYSTEM - INJECTOR
03 -12	FUEL INJECTION SYSTEM - TURBOCHARGER, PIPES AND CONNECTIONS
03 -13	FUEL FILTER
04 -01	STARTER
04 -02	ALTERNATOR
04 -02A	ALTERNATOR - IF USED
04 -03	ALTERNATOR
04 -04	PANEL, CONTROL
04 -05	PANEL, CONTROL
04 -06	INSTRUMENT CLUSTER
04 -07	HARNESS, FRONT - IF USED
04 -07A	HARNESS, FRONT - IF USED
04 -07B	HARNESS, RTD - TC - IF USED
04 -08	CONTROLS, CAB
04 -09	HARNESS - CAB, MAIN
04 -10	HARNESS - CAB, MAIN
04 -11	HARNESS - TRANSMISSION
04 -12	HARNESS - GRID HEATER
04 -13	HARNESS, REAR CHASSIS - IF USED
04 -13A	HARNESS, REAR CHASSIS - IF USED
04 -14	HARNESS, REAR - RELAY PANEL
04 -15	ELECTRICAL - STEERING, AUXILIARY
04 -16	AUXILIARY STEERING AND RIDE CONTROL RELAY
04 -17	BATTERY - CABLES - IF USED
04 -17A	BATTERY - CABLES - IF USED
04 -18	MOUNTING - LAMP, FRONT
04 -19	LAMP ASSY - LAMP, FRONT
04 -20	DOUBLE-SIZE ROTATING LAMP
04 -21	LAMP ASSY - LAMPS, REAR COMBINATION
04 -22	WINDSHIELD WIPER, FRONT
04 -23	CAB - WIPER, REAR
04 -24	RADIO
04 -25	CONVERTER, POWER OUTLET - MOUNTING
05 -01	STEERING COLUMN
05 -01A	STEERING COLUMN -
05 -02	VALVE ASSY - STEERING CONTROL
05 -03	HYDRAULICS - STEERING
05 -04	HYDRAULICS - STEERING
05 -05	HYDRAULICS - STEERING
05 -06	HYDRAULICS - STEERING
05 -07	HYDRAULICS - STEERING, AUXILIARY
05 -08	PRIORITY VALVE - STEERING, AUXILIARY
05 -09	PUMP - STEERING, AUXILIARY
05 -10	CYLINDER ASSY - STEERING
06 -01	HYDRAULICS - TRANSMISSION

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

06 -02	MOUNTING - TRANSMISSION
06 -03	TRANSMISSION FILL TUBE - GAUGE, SIGHT
06 -04	TRANSMISSION - CONVERTER, COVER AND INPUT SHAFT
06 -05	TRANSMISSION ASSY - INPUT SHAFT
06 -06	TRANSMISSION ASSY - HOUSING
06 -07	TRANSMISSION ASSY - HOUSING TUBES
06 -08	TRANSMISSION - CLUTCH ASSY, FIRST
06 -09	TRANSMISSION - CLUTCH ASSY, SECOND
06 -10	TRANSMISSION - CLUTCH ASSY, THIRD
06 -11	TRANSMISSION - CLUTCH ASSY, FOURTH
06 -12	TRANSMISSION - CLUTCH ASSY, FORWARD
06 -13	TRANSMISSION - CLUTCH ASSY, REVERSE
06 -14	TRANSMISSION - SHAFT, OUTPUT
06 -15	TRANSMISSION - POWER TAKE OFF
06 -16	TRANSMISSION - VALVE PLATES
06 -17	TRANSMISSION - VALVE, CONTROL
06 -18	TRANSMISSION - VALVE, CONTROL
06 -19	TRANSMISSION - VALVE, REGULATOR AND OIL PUMP
06 -20	TRANSMISSION - SENSOR, SPEED AND PUMP COVER
06 -21	TRANSMISSION - FILTER, OIL AND FILLER COVER
06 -22	AXLE, FRONT - MOUNTING
06 -23	AXLE, FRONT - HOUSING
06 -23A	AXLE, FRONT - BRAKE
06 -23B	AXLE, FRONT - BRAKE
06 -24	AXLE, FRONT - DIFFERENTIAL CARRIER
06 -25	AXLE, FRONT - DIFFERENTIAL
06 -26	AXLE, FRONT - HUB, DISC BRAKES
06 -27	AXLE, FRONT - HUB, PLANETARY
06 -28	AXLE, REAR - MOUNTING
06 -29	AXLE, REAR - HOUSING
06 -30	AXLE, REAR - DIFFERENTIAL CARRIER
06 -31	AXLE, REAR - DIFFERENTIAL
06 -32	AXLE, REAR - HUB, DISC BRAKES
06 -33	AXLE, REAR - HUB, PLANETARY
06 -34	AXLE, REAR
06 -35	DRIVE SHAFT
06 -35A	DRIVE SHAFT - ENGINE
06 -36	DRIVE SHAFT, FRONT - BEARING, SUPPORT AND LUBE LINE
06 -37	DRIVE SHAFT - CENTER AND REAR
06 -38	WHEELS
07 -01	BRAKE, PARKING
07 -02	HYDRAULICS - BRAKE, MAIN
07 -03	HYDRAULICS - BRAKE, MAIN
07 -04	HYDRAULICS - BRAKE, MAIN
07 -05	ACCUMULATOR - BRAKE
07 -06	HYDRAULICS - BRAKE, MAIN
07 -07	VALVE ASSY - BRAKE
08 -01	RESERVOIR
08 -02	HYDRAULICS - RESERVOIR TO HYDRAULIC PUMP
08 -02A	HYDRAULICS - COOLER WITHOUT BYPASS
08 -02B	HYDRAULICS - BYPASS
08 -03	HYDRAULICS - FILTER, OIL

Order the manual at mid-west-tech.com >

COOLING SYSTEM - MOTOR, DRIVE (MOUNTING)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		(400337A1)		1	Fan Drive; Standard or Reversible; Incl. Ref 2, 3; With M12 Drain Port On Top; No Longer Available, Order 87426773 Motor, Ref 7; Also Order 700-378 Elbow and 87427292 Hose On Figure 07-05
2		8604520		1	SEAL Shaft Fan Pump; Not Illustrated
3		(8604978)		1	Seal; Not Illustrated
4		627-10035		2	SCREW M10 x 35; 10.9
5		895-11010		4	WASHER 11 x 20 x 2 mm
6		832-10410		2	NUT M10
7		87426773		1	MOTOR, HYDRAULIC Fan Drive; Standard or Reversible; Includes 87426795 Seal Kit; With M14 Drain Port On Side
		(87426795)		1	Seal; Not Illustrated

MidWestTech | New Holland LW110.B Wheel Loader Parts Catalog | Publication 7_9071 Order the manual at mid-west-tech.com >

HYDRAULICS - LOADER BUCKET - RIGHT SIDE (TC LOADER) - IF USED

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION LOADER BUCKET; XT LOADER
		REF			INSTRUCTION USED WITH OR WITHOUT RSM2-16 RIDE CONTROL OPTION
1		{87452747}		2	Mounting
2		379374A1		2	BLOCK Mounting
3		827-10070		4	SCREW M10 x 70; 10.9
4		827-10090		4	SCREW M10 x 90; 10.9
5		627-10020		2	SCREW M10 x 20; 10.9
6		{87447893}		1	XT Tilt Tubes Right Hand
7		700-104		2	FITTING 1-3/16 fc sl x 27 Or; Incl. 7A, 7B
7A		637-64236		1	O-RING 23,6 ID x 2,9; Boss Seal
7B		238-6018		1	O-RING 3/4 ID x 1/16; Face Seal
8		700-307		2	ELBOW 1-3/16 fc sl x 27 Or; Incl. 8A, 8B
8A		637-64236		1	O-RING 23,6 ID x 2,9; Boss Seal
8B		238-6018		1	O-RING 3/4 ID x 1/16; Face Seal
9		{87302137}		2	ELBOW ORFS, 45deg; BHD 20mm Or 3/4 in; Incl. 9A
9A		238-6018		1	O-RING 3/4 ID x 1/16; Face Seal
10		{87304893}		1	XT Tilt Base; 2175mm (85-5/8 in)
11		{87304892}		1	XT Tilt Rod; 2255mm (88-3/4 in)
12		{701-1249}		2	
12A		238-6018		1	O-RING 3/4 ID x 1/16; Face Seal
13		832-10410		4	NUT M10
14		238-6018		1	O-RING 3/4 ID x 1/16; Face Seal
15		{8500858}		2	Clamp Cover
16		367658A1		2	PLATE Clamp Cover
17		701-427		2	TEE 1-3/16 fc sl; Incl. 25
17A		238-6018		3	O-RING 3/4 ID x 1/16; Face Seal
18		{87447928}		1	XT Tilt Base Left
19		{87447920}		1	XT Tilt Head Right
20		{404363A1}		1	XT Tilt Rod
21		{87447922}		1	XT Tilt Rod Right
22		{87448138}		1	XT Tilt Rod Right
23		895-11010		8	WASHER 11 x 20 x 2 mm
24		895-15010		1	WASHER 11 x 24 x 2 mm
25		{404353A1}		1	XT Tilt Head

MidWestTech | New Holland LW110.B Wheel Loader Parts Catalog | Publication 7_9071 Order the manual at mid-west-tech.com >

FRAME-LOADER LIFT AND LINKAGE (TC)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION XT LOADER LIFT ARM
1		{87452244}		1	Loader Lift; Incl. 1A-1E
1A		358624A2		2	BUSHING Lift Arm
1B		{87446999}		2	Lift Arm
1C		{369435A2}		2	Lift Arm
1 D		{369432A2}		2	Dump Link
1E		{8500303}		4	Anchor Link
2		{87452240}		2	Dump; Incl. 2A, 2B
2A		{379191A2}		1	Lift Arm
2B		{369432A2}		2	Dump Link
3		{87447627}		2	Anchor; 3A, 3B
3A		{369433A2}		1	Anchor
3B		{8500303}		1	Anchor
4		D95146		12	WIPER Rod 63.5
5		D95147		16	WIPER Rod 69.8
6		D95145		12	WIPER Rod 57.125
7		{87447635}		4	Guide
8		{87447632}		2	Bellcrank; Right Hand
9		{87447629}		2	Bellcrank; Left Hand
10		{87446958}		2	114 ID x 819.9 mm strk; Bucket Tilt; See Figure 08-
11		{87405367}		2	114.3 ID x 787.6 mm strk; Lift; See Figure 08-
12		{361133A2}		2	
13		{361128A1}		2	
14		{368744A2}		2	Bellcrank Pivot
15		{369238A2}		4	Guide Link
16		L125100		14	SPACER
17		496-81025		14	WASHER 21/32 x 2-1/2 x 3/16
18		627-16050		12	SCREW M16 x 50; 10.9
19		627-16040		6	SCREW 16 x 40; 10.9
20		219-1		18	NIPPLE, LUBE 1/8 PT x 21/32
21		365356A1		X	WASHER 71.3 ID; 3.5 Thick
22		375516A1		X	WASHER 71.3 ID; 1.6 Thick
23		375517A1		X	WASHER 71.3 ID; 2.5 Thick
24		{87446996}		4	Lift Arm
25		{368775A1}		2	Bellcrank; Cylinder Side
26		{368776A1}		2	Bellcrank; Anchor Side
27		{368836A2}		2	Tilt Cylinder

MidWestTech | New Holland LW110.B Wheel Loader Parts Catalog | Publication 7_9071 Order the manual at mid-west-tech.com >