PARTS CATALOG

LW170.B
WHEEL LOADER

Issued 01-2004
Revised 08-2004
Revised 05-2005

7-9092 NA

NEW HOLLAND
CONSTRUCTION

MidWestTech | New Holland LW170.B Wheel Loader Parts Catalog | Publication 7-9092

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02 -01	ENGINE MOUNTING
02 -02	RADIATOR - MOUNTING
02 -02A	RADIATOR - MOUNTING - IF USED
02 -03	FAN - FAN BELT
02 -04	COOLANT RECOVERY SYSTEM
02 -06	COOLING SYSTEM - MOTOR, DRIVE
02 -07	MUFFLER - EXHAUST AND INTAKE
02 -08	AIR CLEANER - AIR INTAKE PARTS
02 -09	AIR CLEANER ASSY
02 -10	MUFFLER - EXHAUST AND INTAKE
02 -11	MUFFLER - SPARK ARRESTER
02 -12	ENGINE
02 -13	OIL FILL, ENGINE
02 -14	OIL PUMP - ENGINE
02 -15	OIL FILTERS - ENGINE
02 -16	OIL FILTER AND COOLER
02 -17	OIL PAN
02 -18	OIL PAN DRAIN LINE AND COVER
02 -19	BREATHER - ENGINE
02 -20	TURBOCHARGER SYSTEM
02 -21	TURBOCHARGER
02 -22	WATER PUMP
02 -23	WATER PUMP - CONTROL
02 -24	CYLINDER BLOCK
02 -25	CYLINDER BLOCK - PLUG ASSY
02 -26	CYLINDER BLOCK
02 -27	FLYWHEEL HOUSING
02 -28	GEAR COVER - REAR HOUSING
02 -29	FRONT GEAR COVER
02 -29A	GEAR COVER - PLATE
02 -30	CYLINDER HEAD - COVERS
02 -31	CYLINDER HEAD - VALVE MECHANISM
02 -32	CYLINDER HEAD
02 -33	MANIFOLD - INTAKE
02 -34	MANIFOLD - EXHAUST
02 -35	CAMSHAFT
02 -36	CRANKSHAFT
02 -37	CRANKSHAFT - PULLEY
02 -38	FLYWHEEL - ENGINE
02 -39	CONNECTING ROD
02 -40	PISTONS
02 -41	COOLING SYSTEM - ENGINE
02 -42	THERMOSTAT - ENGINE COOLING SYSTEM
02 -43	TURBOCHARGER ASSY
02 -44	ENGINE - LIFT HOOK
02 -45	ENGINE - BLOCK HEATER
03 -01	CONTROLS - THROTTLE, FOOT
03 -02	FUEL LINES
03 -03	FUEL TANK
03 -04	FUEL INJECTION PUMP
03 -05	FUEL INJECTOR - INJECTOR

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03 -06	FUEL INJECTION SYSTEM - FUEL, SUPPLY
03 -07	FUEL INJECTION SYSTEM - MODULE, ENGINE CONTROL
03 -08	FUEL INJECTION SYSTEM
03 -09	FUEL INJECTION SYSTEM - DRAIN LINE
03 -10	FUEL FILTER
04 -01	ALTERNATOR MOUNTING
04 -01A	ALTERNATOR
04 -02	STARTER
04 -03	PANEL, CONTROL
04 -04	PANEL, CONTROL
04 -05	INSTRUMENT CLUSTER
04 -06	CONTROLS, CAB
04 -07	HARNESS, ENGINE - MOUNTING
04 -08	HARNESS, RTD - TC - IF USED
04 -09	HARNESS, CAB
04 -10	HARNESS - CAB, MAIN
04 -11	HARNESS - TRANSMISSION
04 -11A	HARNESS - TRANSMISSION
04 -12	HARNESS, FRONT- IF USED
04 -12A	HARNESS, FRONT - IF USED
04 -12B	HARNESS, FRONT - IF USED
04 -13	HARNESS - AUXILIARY STEERING MODULE
04 -14	HARNESS - AIR CONDITIONING
04 -15	HARNESS, REAR CHASSIS - HARNESS, ENGINE
04 -15A	HARNESS, REAR CHASSIS - HARNESS, ENGINE - IF USED
04 -15B	HARNESS, REAR CHASSIS - HARNESS, ENGINE
04 -15C	HARNESS, REAR CHASSIS - HARNESS, ENGINE - IF USED
04 -15D	HARNESS, REAR CHASSIS - HARNESS, ENGINE - IF USED
04 -16	HARNESS, REAR CHASSIS - RELAY AND FUSE BOX
04 -16A	HARNESS, REAR CHASSIS - RELAY AND FUSE BOX - IF USED
04 -17	HARNESS REAR CHASSIS - GRID HEATER
04 -18	BATTERY - STANDARD
04 -18A	BATTERY - STANDARD - IF USED
04 -18B	BATTERY - STANDARD - IF USED
04 -19	BATTERY - HEAVY DUTY
04 -19A	BATTERY - HEAVY DUTY
04 -20	CABLES, BATTERY
04 -20A	CABLES, BATTERY - IF USED
04 -20B	CABLES, BATTERY - IF USED
04 -21	MOUNTING - LAMP, FRONT
04 -21A	MOUNTING - LAMP, REAR
04 -22	LAMP ASSY - LAMP, FRONT
04 -23	LAMP ASSY - LAMPS, REAR COMBINATION
04 -23A	LAMP ASSY - LAMPS, REAR COMBINATION - IF USED
04 -24	DOUBLE-SIZE ROTATING LAMP
04 -25	CAB - WIPER, FRONT
04 -26	CAB - WIPER, REAR
04 -27	RADIO
04 -28	CONVERTER, POWER OUTLET - MOUNTING
04 -29	AUXILIARY STEERING AND RIDE CONTROL RELAY
04 -30	LAMP - CAB

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

05 -01	STEERING COLUMN
05 -02	STEERING COLUMN
05 -03	VALVE ASSY - STEERING CONTROL
05 -03A	HYDRAULICS - STEERING - STANDARD
05 -04	HYDRAULICS - STEERING
05 -04A	HYDRAULICS, STEERING - COOLING FRAME TO PUMP
05 -04B	HYDRAULICS, STEERING - PUMP TO CONTROL VALVE
05 -04C	HYDRAULICS, STEERING - PUMP TO LOAD SENSE VALVE
05 -05	HYDRAULICS - STEERING - HYDRAULIC SYSTEM
05 -05A	HYDRAULICS, STEERING - COOLING FRAME TO PUMP
05 -06	HYDRAULICS, STEERING - PUMP TO CONTROL VALVE
05 -07	HYDRAULICS, STEERING - PUMP TO LOAD SENSE VALVE
05 -08	HYDRAULICS - STEERING
05 -09	HYDRAULICS, AUXILIARY STEERING - PUMP TO MANIFOLD
05 -10	HYDRAULICS, AUXILIARY STEERING - SOLENOID VALVE TO STG PRIORITY VALVE
05 -10A	CYLINDER ASSY - STEERING - IF USED
05 -11	HYDRAULICS, AUXILIARY STEERING - PUMP TO HYDRAULIC TANK
05 -12	PRIORITY VALVE - STEERING, AUXILIARY
05 -13	PUMP - STEERING, AUXILIARY
05 -14	CYLINDER ASSY - STEERING
05 -15	PRIORITY VALVE - STEERING, AUXILIARY
06 -01	HYDRAULICS - TRANSMISSION
06 -02	MOUNTING - TRANSMISSION
06 -03	TRANSMISSION FILL TUBE - GAUGE, SIGHT
06 -04	TRANSMISSION - CONVERTER, COVER AND INPUT SHAFT
06 -05	TRANSMISSION ASSY - HOUSING
06 -06	TRANSMISSION ASSY - HOUSING TUBES
06 -07	TRANSMISSION - CLUTCH ASSY, FIRST
06 -08	TRANSMISSION - CLUTCH ASSY, SECOND
06 -09	TRANSMISSION - CLUTCH ASSY, THIRD
06 -10	TRANSMISSION - CLUTCH ASSY, FOURTH
06 -11	TRANSMISSION - CLUTCH ASSY, FORWARD
06 -12	TRANSMISSION - CLUTCH ASSY, REVERSE
06 -13	TRANSMISSION - SHAFT, OUTPUT
06 -14	TRANSMISSION - POWER TAKE OFF
06 -15	TRANSMISSION - VALVE PLATES
06 -16	TRANSMISSION - VALVE, CONTROL
06 -17	TRANSMISSION - VALVE, CONTROL
06 -18	TRANSMISSION - VALVE, REGULATOR AND OIL PUMP
06 -19	TRANSMISSION - SENSOR, SPEED AND PUMP COVER
06 -20	TRANSMISSION - FILTER, OIL AND FILLER COVER
06 -21	AXLE, FRONT AND REAR - MOUNTING
06 -22	AXLE, FRONT - HOUSING
06 -23	AXLE, FRONT - HUB, PLANETARY
06 -24	AXLE, FRONT - HUB, DISC BRAKES
06 -25	AXLE, FRONT - DIFFERENTIAL
06 -26	AXLE, FRONT - DIFFERENTIAL CARRIER
06 -27	AXLE, REAR - HOUSING
06 -28	AXLE, REAR - HUB, PLANETARY
06 -29	AXLE, REAR - HUB, DISC BRAKES
06 -30	AXLE, REAR - DIFFERENTIAL

Order the manual at mid-west-tech.com >

HYDRAULICS - BRAKE, MAIN

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION MAIN BRAKE VALVE TO RESERVOIR AND BRAKE PUMP
1		87425585		1	VALVE, BRAKE Main; No Component Parts Available
5		87426002		1	HOSE 692 mm (27-1/4 in); Brake Valve Discharge
6		87426003		1	HOSE 704 mm (27-27/32 in); Brake Pump Discharge
7		8602673		1	HOSE, FLEXIBLE 2394 mm (94-1/4 in); Brake Pump Pressure
8		8606002		3	COLLAR, RETAINER Tube Mounting
9		76082265		5	BLOCK Tube Mounting
10		827-10120		2	SCREW M10 x 120; Replaced By 827-10060
10		827-10060		2	SCREW M10 x 60
11		367658A1		1	PLATE
13		214-1420		1	CLAMP Replaced By 353036A1
13		353036A1		1	CLAMP Constant Torque
14		8500478		4	BLOCK
15		8500555		3	PLATE
16		238-6011		2	O-RING 5/16 x 1/16
17		827-10130		1	SCREW M10 x 130; 10.9
18		895-11010		9	WASHER
19		832-10410		3	NUT
20		8500218		1	TUBE Brake Supply
21		8500220		1	TUBE Fan Supply
22		701-340		2	ELBOW 90 Deg Elbow; Incl. 23
23		238-6016		2	O-RING 5/8 ID x 1/16, Face Seal
24		8500174		1	HOSE, FLEXIBLE 1407 mm (55 - 7/16 in); Fan Supply
25		700-307		1	ELBOW 90 deg; Incl. 26, 27; If Used
26		238-6018		1	O-RING 3/4 ID x 1/16, Face Seal
27		637-64236		1	O-RING 23,8 ID x 2,9 mm, Boss Seal
25		700-166		1	CONNECTOR, HYD. 1-7/16 fc sl x 27 orb; Incl. 25A, 25B; If Used
25A		637-64236		1	O-RING 23,6 ID x 2,9; Boss Seal
25B		238-6018		1	O-RING 3/4 ID x 1/16; Face Seal
25		700-105		1	CONNECTOR, HYD. Incl. 25A, 25B; If Used
25A		238-6021		1	O-RING 15/16 ID x 1/16, Face Seal

MidWestTech | New Holland LW170.B Wheel Loader Parts Catalog | Publication 7-9092 Order the manual at mid-west-tech.com >

VALVE SECTION - BUCKET/BOOM/OPTIONAL SPOOLS (3 SPOOL VALVE) (Z-BAR/TC LOADER)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION THREE SPOOL VALVE
		87440134		1	VALVE, HYDRAULIC Three Spool; Incl. 1 - 11; Also Includes Parts On Figure 08-16A, 16D; Z-Bar and XR Loader Models; Replaces 8500494 Valve
		87450851		1	VALVE, HYDRAULIC Three Spool; Incl. 1 - 11; Also Includes Parts On Figure 08-16A, 16D; Z-Bar and XR Loader Models; Replaces 87440134 Valve
		87450854		1	VALVE, HYDRAULIC Three Spool; Incl. 1 - 11; Also Includes Parts On Figure 08-16B, 16D; XT Loader Models
1		8602890		5	COVER Component Parts Not Serviced Separately
2		8604934		1	KIT, SEALS Load Sensing Control Block; Includes (29) O-Rings, Which Are Not Serviced Separately
3		962-6016		10	SCREW Hex Socket; M6 x 16; 10.9
4		8602924		5	PISTON M12 x 1,5
5		8602917		6	SPRING
6		8602918		7	RETAINER Spring
7		8602894		1-2	SPOOL (2) Used In 87440134 Z-Bar and XR Loader Valve For Bucket and Optional Spools; (1) Used In 87450854 XT Loader Valve For Optional Spool
8		8602895		1	SPOOL Boom Spool; Used With Ref 9
8A		8602933		1	SPOOL Bucket Spool; Used In 87450854 XT Loader Valve
9		8602891		1	COVER Component Parts Not Serviced Separately
10		8604972		1	O-RING
11		8602892		2	SCREW Hex Socket; M6 x 105

MidWestTech | New Holland LW170.B Wheel Loader Parts Catalog | Publication 7-9092 Order the manual at mid-west-tech.com >

COVERS - BATTERY BOX

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		REF		1	INSTRUCTION Box, Left Hand, See Page XX
2		REF		1	INSTRUCTION Box, Right Hand, See Page XX
3		76037610		12	WASHER
4		832-10412		12	NUT M12
5		76030114		2	HANDLE
6		895-11008		4	WASHER 9 x 16 x 1,6 mm
7		832-10408		4	NUT M8
8		827-8040		4	SCREW M8 x 40

MidWestTech | New Holland LW170.B Wheel Loader Parts Catalog | Publication 7-9092 Order the manual at mid-west-tech.com >