PARTS CATALOG

EH130
CRAWLER EXCAVATOR

7-9241NA

NEW HOLLAND
CONSTRUCTION

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02 -01	00	ENGINE MOUNTING
02 -02	00	ENGINE MOUNTING BRACKETS
02 -03	00	ENGINE ASSY
02 -04	00	ENGINE CONTROL ASSY
02 -05	00	ACCELERATOR PEDAL CONTROL SPACER
02 -06	00	AIR CLEANER ASSY
02 -07	00	INNER ELEMENT AIR FILTER
02 -08	00	MUFFLER ASSY
02 -09	00	RADIATOR MOUNTING
02 -10	00	RADIATOR ASSY
02 -11	00	WATER PUMP SYSTEM
02 -12	00	THERMOSTAT AND HOUSING
02 -13	00	WATER BYPASS
02 -14	00	GEAR HOUSING
02 -15	00	MANIFOLD - INTAKE
02 -16	00	MANIFOLD - EXHAUST
02 -17	00	OIL PUMP
02 -18	00	OIL FILTER
02 -19	00	OIL COOLER
02 -20	00	OIL LINES
02 -21	00	OIL PAN AND GAUGE
02 -22	00	CYLINDER HEAD COVER
02 -23	00	CYLINDER HEAD
02 -24	00	CYLINDER BLOCK
02 -25	00	CRANKSHAFT AND PISTON
02 -26	00	CAMSHAFT
02 -27	00	AIR BREATHER
02 -28	00	TURBOCHARGER
02 -29	00	TURBOCHARGER SYSTEM
02 -30	00	GASKET KIT
02 -31	00	ELEMENT KIT
02 -32	00	ENGINE FILTERS
03 -01	00	FUEL TANK
03 -02	00	FUEL LINES (YY21P00002F1)
03 -03	00	FUEL LINES (YY21P00002F2)
03 -04	00	FUEL LINES & FILTER
03 -05	00	FUEL INJECTION SYSTEM
03 -06	00	FUEL FILTER
03 -07	00	WATER SEPARATOR
03 -08	00	INJUCTION PUMP & MISCELLANEOUS PARTS
03 -09	00	INJECTION PUMP COUPLING
03 -10	00	FEED PUMP
04 -01	00	ELECTRICAL CONTROL PARTS
04 -02	00	GENERATOR
04 -03	00	RELAY ASSY
04 -04	00	RELAY ASSY
04 -05	00	HARNESS ASSY (CAB)
04 -06	00	HARNESS ASSY, UPPERSTRUCTURE
04 -07	00	HARNESS ASSY (ENGINE)
04 -08	00	HORN MOUNTING
04 -09	00	BATTERY MOUNTING

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

04 -10	00	LAMP ASSY (YN80S00010F2)
04 -11	00	LAMP MOUNTING
04 -12	00	LIGHT ASSY (YW80S00001F1)
04 -13	00	LAMP MOUNTING - BOOM
04 -14	00	FLASHERS, SIDE
04 -15	00	SWITCH (INSTRUMENT PANEL)
05 -01	00	UNDERCARRIAGE
05 -02	00	UNDERCARRIAGE - BLOCK (COVER ASSY)
05 -03	00	TRACK - IDLER
05 -04	00	TRACK - IDLER ASSY
05 -05	00	TRACK - ADJUSTER
05 -06	00	TRACK - ROLLER ASSY
05 -07	00	TRACK - ROLLER, UPPER
05 -08	00	TRACK - SHOE (YY60D00005F1)
05 -09	00	TRACK - SHOE (YY60D00007F1-F2)
05 -10	00	STEPS - MOUNTING
06 -01	00	POWER TAKE OFF ASSY (YX30P00002F1)
06 -02	00	TRAVEL MOTOR
06 -03	00	TRAVEL MOTOR UPER SECTION
08 -01	00	HYDRAULIC TANK ASSY (YY33H00013F6)
08 -02	00	HYDRAULIC LINES - HYDRAULIC PUMP (YY30H00002F1)
08 -03	00	HYDRAULIC LINES - MAIN (YY03H00023F2)
08 -04	00	HYDRAULIC LINES - MAIN (YY03H00023F2)
08 -05	00	HYDRAULIC LINES - RETURN (YY32H00003F1)
08 -06	00	HYDRAULIC LINES - RETURN (YY32H00003F1)
08 -07	00	HYDRAULIC LINES - LOWER (YY02H00017F1)
08 -08	00	HYDRAULIC LINES - UPPER (YY03H00030F1)
08 -09	00	HYDRAULIC LINES - REMOTE CONTROL, PUMP (YY06H00021F1)
08 -10	00	HYDRAULIC LINES - REMOTE CONTROL, PUMP (YY06H00021F1)
08 -11	00	HYDRAULIC LINES - REMOTE CONTROL, VALVE (YY64H00046F1)
08 -12	00	HYDRAULIC LINES - REMOTE CONTROL, VALVE (YY64H00046F1)
08 -13	00	HYDRAULIC LINES - REMOTE CONTROL, VALVE (YY64H00046F1)
08 -14	00	HYDRAULIC LINES - REMOTE CONTROL, VALVE (YY68H00048F1)
08 -15	00	HYDRAULIC LINES - REMOTE CONTROL, MULTI (YY68H00029F1)
08 -16	00	HYDRAULIC LINES - REMOTE CONTROL, MULTI (YY68H00029F1)
08 -17	00	HYDRAULIC LINES - REMOTE CONTROL, MULTI (YY68H00029F1)
08 -18	00	HYDRAULIC LINES - REMOTE CONTROL, MULTI (YY68H00029F1)
08 -19	00	HYDRAULIC LINES - BOOM 4.6M (15FT 1IN)
08 -20	00	HYDRAULIC LINES - BOOM 4.6M (15FT 1 IN) (NIBBLER & BREAKER)
08 -21	00	HYDRAULIC LINES - ARM 2.45M (8FT)
08 -22	00	HYDRAULIC LINES - ARM 2.45M (8FT) (NIBBLER & BREAKER)
08 -23	00	HYDRAULIC LINES - ARM 2.95M (9FT 8IN)
08 -24	00	HYDRAULIC LINES - ARM 2.95M (9FT 8IN) (NIBBLER & BREAKER)
08 -25	00	PUMP
08 -26	00	PUMP ASSY
08 -27	00	PUMP - GEAR
08 -28	00	PUMP - GEAR - DOZER (YV10V00006F1)
08 -29	00	CASE ASSY, GEAR
08 -30	00	PUMP - REGULATOR
08 -31	00	MOUNTING - SWING MOTOR
08 -32	00	SWING MOTOR ASSY (YY15V00004F1)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

08 -33	00	SWING MOTOR (YX15V00004F1,F2,F3)
08 -34	00	SWING MOTOR - REDUCTION
08 -35	00	HYDRAULICS - JOINT, SWIVEL CENTER (YN55V00037F2)
08 -36	00	VALVE MOUNTING (YX64H00002F1)
08 -37	00	VALVE MOUNTING (YY64H0032F1)
08 -38	00	VALVE, PRESSURE RELIEF (YN22V00002F1 - F7)
08 -39	00	VALVE, SELECTOR (YY30V00019F1)
08 -40	00	VALVE ASSY - PILOT, TRAVEL (YX30V0004F1)
08 -41	00	VALVE ASSY - PILOT (YY30V00055F1,F2)
08 -42	00	VALVE ASSY - CONTROL (YN30V00075F1,F2) (OPTION)
08 -43	00	VALVE ASSY - CONTROL (YY30V00008F1,F2,F3)
08 -44	00	VALVE ASSY - CONTROL (YY30V00044F1)
08 -45	00	VALVE ASSY - CONTROL (YY30V00044F1)
08 -46	00	VALVE ASSY - CONTROL (YY30V00044F1)
08 -47	00	VALVE ASSY, SWING (YX30V00006F1,F2)
08 -48	00	VALVE, BYPASS (YY30V00045F1)
08 -49	00	VALVE ASSY, RELIEF (2436R1119F1 - F6)
08 -50	00	VALVE ASSY, RELIEF (LP22V00001F1 - F2)
08 -51	00	VALVE ASSY, RELIEF (YT22V00006F1 - F6)
08 -52	00	VALVE ASSY, RELIEF (YX22V00002F1)
08 -53	00	VALVE ASSY, RELIEF (YY22V00007F1 - F2)
08 -54	00	VALVE ASSY, SOLENOID (LC35V00004F1,F2)
08 -55	00	VALVE ASSY, SOLENOID (YB35V00003F1)
08 -56	00	VALVE ASSY, SOLENOID (YT35V00005F1)
08 -57	00	VALVE ASSY, SOLENOID (YT35V00012F1)
08 -58	00	VALVE ASSY, SOLENOID (YT35V00013F1)
08 -59	00	VALVE ASSY, SOLENOID (YT35V00014F1)
08 -60	00	VALVE ASSY, SOLENOID (YY35V00006F1)
08 -61	00	SECTION ASSY, INLET (YR20V00001F1)
08 -62	00	SECTION ASSY, SPOOL (YT30V00027F1)
08 -63	00	VALVE ASSY, LOCK (YX30V00009F1)
08 -64	00	CYLINDER ASSY, BOOM, RIGHT HAND
08 -65	00	CYLINDER ASSY, BOOM, LEFT HAND
08 -66	00	CYLINDER ASSY, ARM (YY01V00003F1, F2)
08 -67	00	CYLINDER ASSY, BUCKET
08 -68	00	CONNECTORS
08 -69	00	CONNECTORS
08 -70	00	CONNECTORS
09 -01	00	TURNTABLE BEARING
09 -02	00	TURNTABLE (YY52F00027F5)
09 -03	00	TURNTABLE - ACCESS COVERS
09 -04	00	COUNTERWEIGHT
09 -05	00	COUNTERWEIGHT (GUARDS)
09 -06	00	COVER - SUPPORTS
09 -07	00	BRACKET ASSY (YY21C01149F1)
09 -08	00	COVER - SUPPORTS
09 -09	00	COVER - SUPPORTS
09 -10	00	COVER - SUPPORTS
09 -11	00	COVER - SUPPORTS
09 -12	00	MOUNTING BRACKET
09 -13	00	COVER ASSY

Order the manual at mid-west-tech.com >