PARTS CATALOG

DC85
CRAWLER DOZER

7-9261 NA

NEW HOLLAND
CONSTRUCTION

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-01	ENGINE - MOUNTING
02-02	FAN - FAN BELT
02-03	RADIATOR - MOUNTING
02-04	RADIATOR ASSY
02-05	COOLANT RECOVERY SYSTEM
02-06	AIR CLEANER - MOUNTING
02-07	AIR CLEANER ASSY
02-08	MUFFLER - EXHAUST SYSTEM
02-09	ENGINE
02-10	CYLINDER BLOCK
02-11	CYLINDER BLOCK
02-12	OIL PUMP, PAN
02-13	GEAR COVER - REAR HOUSING
02-14	CYLINDER BLOCK - COVERS
02-15	FLYWHEEL HOUSING
02-16	BREATHER - ENGINE
02-17	CYLINDER HEAD
02-18	CYLINDER HEAD - COVERS
02-19	CYLINDER HEAD - VALVE MECHANISM
02-20	MANIFOLD - INTAKE
02-21	MANIFOLD - EXHAUST
02-22	CRANKSHAFT
02-23	PISTONS - CONNECTING ROD
02-24	PISTONS - CONNECTING ROD
02-25	FLYWHEEL - ENGINE
02-26	PULLEY - CRANKSHAFT
02-27	DYNAMIC BALANCER, GEARS & SHAFTS
02-28	CAMSHAFT
02-29	TURBOCHARGER
02-30	ENGINE, OIL
02-31	OIL PUMP - ENGINE
02-32	OIL FILTERS - ENGINE
02-33	PIPING - ENGINE OIL
02-34	OIL FILTER AND COOLER
02-35	WATER PUMP
02-36	COOLING SYSTEM - ENGINE
02-37	THERMOSTAT - ENGINE COOLING SYSTEM
02-38	WATER PUMP - CONTROL
02-39	FAN DRIVE
02-40	POWER TAKE-OFF
02-41	ENGINE - LIFT HOOK
03-01	CONTROLS, THROTTLE - CABLE AND HAND LEVER
03-02	CONTROLS, THROTTLE - DECELERATOR PEDAL AND CROSS SHAFT
03-03	CONTROLS, THROTTLE - LINKAGE AT ENGINE
03-04	FUEL TANK
03-05	FUEL LINES
03-06	FUEL INJECTION PUMP
03-07	FUEL INJECTION SYSTEM
03-08	FUEL INJECTION SYSTEM
03-09	FUEL INJECTION SYSTEM
03-10	FUEL FILTER
03-11	FUEL PUMP

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03-12	FUEL INJECTION SYSTEM
03-13	FUEL INJECTION SYSTEM
04-01	STARTER
04-02	ALTERNATOR ASSY (MODELS WITHOUT AIR CONDITIONING)
04-03	ALTERNATOR ASSY (MODELS WITH AIR CONDITIONING)
04-04	ALTERNATOR MOUNTING
04-05	BATTERY, SINGLE - CABLES
04-06	BATTERY, DUAL - CANOPY, ROPS
04-07	BATTERY, DUAL - CAB
04-08	HARNESS, ENGINE - FUSES AND RELAYS
04-09	HARNESS, ENGINE (RIGHT-HAND SIDE) - ALTERNATOR
04-10	HARNESS, ENGINE (LEFT-HAND SIDE AND REAR)
04-11	HARNESS, ENGINE AND REAR WIRE HARNESS
04-13	HARNESS, FRONT CONSOLE AND SWITCHES - CANOPY, ROPS
04-14	HARNESS, FRONT CONSOLE AND SWITCHES - CAB
04-15	HARNESS, CANOPY - HARNESS, MICROCONTROLLER
04-16	HARNESS, CAB - HARNESS, MICROCONTROLLER
04-17	CONSOLE, FRONT - CANOPY, ROPS
04-18	CONSOLE, FRONT - CAB
04-19	INSTRUMENT CLUSTER
04-20	HARNESS, LAMP - CANOPY, ROPS
04-21	HARNESS, LAMP - CAB
04-22	ALARM, BACKUP - HORN
04-23	GRID HEATER - CABLES
04-24	GRID HEATER - SYSTEM CONTROL
04-25	WIPER, FRONT - CAB
04-26	WIPER, REAR - CAB
05-01	FRAME, TRACK - ROLLER AND RECOIL HOUSING
05-02	FRAME, TRACK - COVERS
05-03	SPROCKET, TRACK
05-04	TRACK ADJUSTER AND IDLER - MOUNTING
05-05	TRACK ADJUSTER
05-06	TRACK IDLER
05-07	TRACK ROLLER
05-08	TRACK GUARDS
05-09	TRACK CHAIN, SEALED
05-10	TRACK CHAIN, SEALED AND LUBRICATED
06-01	MOUNTING - PUMP, HYDROSTATIC TANDEM AND DRIVESHAFT
06-02	HYDROSTATICS - PUMP, TANDEM SUPPLY AND RETURN TO FILTER
06-03	HYDROSTATICS - MOTOR, DRIVE
06-04	DIAGNOSTIC LINES
06-05	MOUNTING - FINAL DRIVE
06-06	COVERS - FINAL DRIVE
06-07	FINAL DRIVE ASSY, DROP HOUSING
06-08	FINAL DRIVE ASSY, HUB
06-09	FILTER ASSY
06-10	CONTROLS, FORWARD AND REVERSE
06-11	HYDROSTATIC MOTOR
06-12	HYDROSTATIC MOTOR
06-13	PUMP ASSY - COMBINATION
07-01	BRAKES - PEDALS AND LINKAGE
07-02	BRAKE LINES

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

07-03	BRAKE, PARKING/LOCKOUT LEVERS
08-01	RESERVOIR, HYDRAULIC - COVERS
08-02	HYDRAULICS, EQUIPMENT - RESERVOIR TO PUMP AND CONTROL VALVE
08-03	HYDRAULICS, EQUIPMENT - CONTROL VALVE TO THERMAL BYPASS VALVE AND FILTER
08-04	VALVE ASSEMBLY, THERMAL BYPASS
08-05	HYDRAULICS - LIFT CIRCUIT
08-06	HYDRAULICS - TILT AND ANGLE CIRCUITS
08-07	HYDRAULICS - TILT CIRCUIT
08-08	HYDRAULICS - ANGLE CIRCUIT
08-09	HYDRAULICS - RIPPER, VALVE TO REAR OF TRACTOR
08-10	HYDRAULICS - RIPPER, REAR OF TRACTOR TO CYLINDERS
08-11	CYLINDER ASSY - LIFT
08-12	CYLINDER ASSY - TILT
08-13	CYLINDER ASSY - ANGLE
08-14	CYLINDER ASSY - RIPPER
08-15	VALVE, CONTROL - MOUNTING
08-16	CONTROLS - LEVER AND LINKAGE, THREE SPOOL VALVE
08-17	CONTROLS - LEVER AND LINKAGE, FOURTH SPOOL
08-18	VALVE, CONTROL
08-19	VALVE ASSY, RELIEF
08-20	SECTION ASSEMBLY - LIFT
08-21	SECTION ASSEMBLY - TILT, ANGLE, AND AUXILIARY
08-22	VALVE ASSY, CHECK - VALVE ASSY, ANTI-CAVITATION
08-23	VALVE ASSY, RELIEF
09-01	FRAME, LIFT - CYLINDERS, MOUNTING
09-02	DOZER BLADE - MOUNTING
09-03	BLADE, DOZER - EDGES, CUTTING
09-04	SHIELDS, DOZER HYDRAULICS
09-05	RIPPER
09-06	COUNTERWEIGHT, FRONT - HOOK, TOWING
09-07	DRAWBAR - HOOK, TOWING
09-08	FRAME, MAIN
09-09	UPPER MAIN FRAME, MOUNTING - HYDRAULIC AND FUEL TANK SEAT
09-10	DOOR, REAR - TANK, HYDRAULIC OIL
09-11	DOORS, REAR
09-12	HOOD AND SIDE PANELS
09-13	GUARD, RADIATOR BRUSH SCREEN - GRILLE, HOOD
09-14	SEAT ASSY, MECHANICAL SUSPENSION - MOUNTING
09-15	SEAT ASSY, MECHANICAL SUSPENSION
09-16	SEAT ASSY, AIR SUSPENSION - MOUNTING
09-17	SEAT ASSY, AIR SUSPENSION
09-18	CANOPY, ROPS - FRAME, MOUNTING AND GRAB HANDLES
09-19	CANOPY, ROPS - HEADLINER, FLOORMAT AND MIRROR
09-20	CANOPY, ROPS - ARMRESTS, TOOLBOX AND COVERS
09-21	CANOPY, ROPS - CONSOLES, SIDE
09-22	CANOPY, ROPS - SCREENS
09-23	CAB OR CANOPY - GUARD, BRUSH
09-24	CAB OR CANOPY - TILT COMPONENTS
09-25	CAB OR CANOPY - LAMP MOUNTING
09-26	CAB - FRAME AND MOUNTING
09-27	CAB - DOORS

Order the manual at mid-west-tech.com >

MUFFLER - EXHAUST SYSTEM

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		87438478		1	PIPE, EXHAUST SYSTEM
2		R27699		1	CLAMP
3		614-10090		1	BOLT M10 x 90
4		896-15010		2	WASHER 11 x 24 x 2 mm
5		892-11010		1	WASHER, LOCK 10 mm
6		829-1410		1	NUT M10
7		87311625		1	MUFFLER Muffler; Includes Clamp; Replaces 87433764
9		{J910992}		1	Exhaust Outlet Elbow; Replaces 87416402 Elbow Used On Some Models
10		217-506		1	PLUG 1/4 PT
11		A170467		1	CLAMP Includes Hardware
12		87446365		1	BRACKET, SUPPORTING Muffler Support; No Longer Available, Order 87324593 Bracket, Ref 12A
12A		87324593		1	BRACKET, SUPPORTING Muffler Support
13		614-10035		2	BOLT M10 x 35; 8,8
14		896-15010		4	WASHER 11 x 24 x 2 mm
15		832-10410		2-3	NUT M10
16		814-12045		1	SCREW M12 x 45
17		896-15012		2	WASHER 13.5 x 28 x 4 mm
18		832-10412		1	NUT M12
20		87435848		1	BRACKET, SUPPORTING If Used
21		614-8025		2	BOLT M8 x 25; Used With Ref 20 Bracket
21A		627-8030		3-4	SCREW M10 x 30; Used With Ref 32 Bracket
22		895-15008		2-3	WASHER 9 x 20 x 1,6 mm
23		892-11008		2-3	WASHER M8
24		614-10025		2	BOLT M10 x 25; Used With Ref 20 Bracket
24A		614-10030		2	BOLT M10 x 30; Used With Ref 32 Bracket
25		892-11010		2	WASHER, LOCK M10
26		896-15010		2-6	WASHER 11 x 24 x 3 mm
27		87450952		1	BRACKET, SUPPORTING Hose Support; Two Holes; No Longer Available, Order 87324592 Bracket, Ref 27A
27A		87324592		1	BRACKET, SUPPORTING Hose Support; Three Holes
28		614-8040		2	BOLT M8 x 40; Replaces 614-8030 M8 x 30 Bolt Used On Some Models

MidWestTech | New Holland DC85 Crawler Dozer Parts Catalog | Publication 7-9261 Order the manual at mid-west-tech.com >

BRAKES - PEDALS AND LINKAGE

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		76046806		1	SUPPORT Incl. Ref 2
2		79048068		2	BEARING ASSY
3		47109434		4	SCREW M10 x 20
4		79089497		1	PEDAL Brake
5		79103841		1	HUB Incl. Ref 6, 7
6		79087266		1	PIN
7		79087112		1	BUSHING
8		569475		3	SCREW M10; Use With Loctite 243
		345-199		X	ADHESIVE Loctite 243, 1 ml
9		514-720		1	SCREW M10 x 50
10		825-11410		1	NUT M10
11		79103849		1	PIN Shaft
12		829-1408		1	NUT M8
13		411095A1		1	SENSOR Rod
14		{87337479}		1	Rotary; Plugs Into Intermediate Microcontroller Harness 426946A1; Replaces 432368A1
15		864-5040		2	SCREW M5 x 40; Use With Loctite 243
		345-199		X	ADHESIVE Loctite 243, 1 ml
16		895-11005		4	WASHER 5,5 x 10 x 1 mm
17		832-10405		2	NUT M5
18		435695A1		1	SPRING, TENSION
19		79102461		1	PIN
20		76046804		1	FOOT REST
21		614-10025		1	BOLT M10 x 25
22		614-10050		1	BOLT M10 x 50
23		829-1410		2	NUT M10
24		614-10030		2	BOLT M10 x 30

MidWestTech | New Holland DC85 Crawler Dozer Parts Catalog | Publication 7-9261 Order the manual at mid-west-tech.com >

CYLINDER ASSY - RIPPER

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		87436768		1	CYLINDER ASSY. 83 ID x 206 mm strk; Ripper; Right-Hand; Incl. Ref 1, 2 - 19
		87436767		1	CYLINDER ASSY. 83 ID x 206 mm strk; Ripper; Left-Hand; Incl. Ref 1A - 19
1		G100608		1	CYLINDER Tube; Right-Hand; Incl. Ref 2
1A		G100609		1	CYLINDER Tube; Left-Hand; Incl. Ref 2
2		30634		2	BUSHING
3		86642312		1	SCREW No. 8 x 3/8
4		G100617		1	ROD Incl. Ref 5
5		30634		2	BUSHING
6		G100642		1	PISTON
7		1542972C1		1	CAP CYLINDER END
		1543265C1		1	KIT, GASKET Incl. Ref 8 - 15
8		D95143		1	SEAL
9		G102425		1	BUSHING, LARGE
10		1542875C1		1	SET OF PARTS Seal Kit; Order 1543265C1 Kit
11		238-5236		1	O-RING 3-1/4 ID x 1/8
12		D38858		1	GASKET
13		G102287		1	SEAL
14		S109444		1	RING
15		S109445		2	RING
16		86982437		1	BOLT, SPECIAL 1 x 2-1/2; With Washer
18		219-1		1	NIPPLE, LUBE 1/8 PT x 21/32
19		219-55		1	NIPPLE, LUBE 1/8 PT x 27/32

MidWestTech | New Holland DC85 Crawler Dozer Parts Catalog | Publication 7-9261 Order the manual at mid-west-tech.com >