# PARTS CATALOG

## EH35
## COMPACT EXCAVATOR

7-9330NA

NEW HOLLAND CONSTRUCTION



Order the manual at mid-west-tech.com >

# TABLE OF CONTENTS


| | | |
|---|---|---|
| 02-01 | 00 | ENGINE, MOUNTING |
| 02-02 | 00 | ENGINE ASSY |
| 02-03 | 00 | ENGINE, CONTROL ASSY WITH DECELERATION |
| 02-04 | 00 | ENGINE, CONTROL ASSY WITHOUT DECELERATION |
| 02-05 | 00 | AIR CLEANER ASSY |
| 02-06 | 00 | MUFFLER ASSY |
| 02-07 | 00 | RADIATOR MOUNTING |
| 02-08 | 00 | RADIATOR |
| 02-09 | 00 | WATER PUMP SYSTEM |
| 02-10 | 00 | HOUSING, GEAR |
| 02-11 | 00 | MANIFOLD - INTAKE |
| 02-12 | 00 | MANIFOLD - EXHAUST |
| 02-13 | 00 | OIL PUMP |
| 02-14 | 00 | CYLINDER HEAD AND COVER |
| 02-15 | 00 | CAMSHAFT AND DRIVING GEAR |
| 02-16 | 00 | CYLINDER BLOCK |
| 02-17 | 00 | CRANKSHAFT AND PISTON |
| 02-18 | 00 | FLYWHEEL HOUSING AND OIL PAN |
| 02-19 | 00 | ENGINE FILTERS |
| 02-20 | 00 | GASKET KIT |
| 03-01 | 00 | FUEL TANK |
| 03-02 | 00 | FUEL LINES |
| 03-03 | 00 | WATER SEPARATOR ASSY |
| 03-04 | 00 | FUEL FILTER |
| 03-05 | 00 | FUEL INJECTION PUMP |
| 03-06 | 00 | GOVERNOR, FUEL INJECTION PUMP |
| 03-07 | 00 | FUEL INJECTION VALVE |
| 04-01 | 00 | STARTER MOTOR |
| 04-02 | 00 | ALTERNATOR |
| 04-03 | 00 | RELAY BOX ASSY - CANOPY |
| 04-04 | 00 | RELAY BOX ASSY - CAB |
| 04-05 | 00 | RELAY ASSY - CANOPY |
| 04-06 | 00 | RELAY ASSY - CAB |
| 04-07 | 00 | HARNESS, MAIN - CHASSIS, UPPERSTRUCTURE - CANOPY |
| 04-08 | 00 | HARNESS, MAIN - CHASSIS, UPPERSTRUCTURE - CAB |
| 04-09 | 00 | HARNESS ASSY - ENGINE |
| 04-10 | 00 | BATTERY - CABLES |
| 04-11 | 00 | BATTERY MOUNTING |
| 04-12 | 00 | LAMP ASSY - BOOM |
| 04-13 | 00 | LAMP MOUNTING - BOOM |
| 04-14 | 00 | RADIO MOUNTING |
| 04-15 | 00 | ALARM ASSY |
| 05-01 | 00 | UNDERCARRIAGE |
| 05-02 | 00 | TRACK, RUBBER |
| 05-03 | 00 | SHOE, TRACK |
| 05-04 | 00 | TRACK - IDLER |
| 05-05 | 00 | TRACK - IDLER ASSY |
| 05-06 | 00 | TRACK - ADJUSTER |
| 05-07 | 00 | TRACK - ROLLER, UPPER |
| 05-08 | 00 | TRACK - ROLLER, LOWER |
| 06-01 | 00 | POWER TAKE OFF ASSY |



Order the manual at mid-west-tech.com >

# TABLE OF CONTENTS


| | | |
|---|---|---|
| 06-02 | 00 | MOTOR - TRACK DRIVE |
| 06-03 | 00 | MOTOR - TRACK DRIVE UPPER SECTION |
| 08-01 | 00 | HYDRAULIC RESERVOIR ASSY |
| 08-02 | 00 | HYDRAULIC LINES - HYDRAULIC PUMP |
| 08-03 | 00 | HYDRAULIC LINES - SWING CYLINDER |
| 08-04 | 00 | HYDRAULIC LINES - UPPER |
| 08-05 | 00 | HYDRAULIC LINES - UPPER (NIBBLER & BREAKER) |
| 08-06 | 00 | HYDRAULIC LINES - RETURN (NIBBLER & BREAKER) |
| 08-07 | 00 | HYDRAULICS - PILOT CONTROL LINES, REMOTE CONTROL |
| 08-08 | 00 | HYRDAULICS - PILOT CONTROL LINES, MAIN |
| 08-09 | 00 | HYDRAULICS - PILOT CONTROL LINES, TRAVEL |
| 08-10 | 00 | HYDRAULICS - PILOT CONTROL LINES, SWING |
| 08-11 | 00 | HYDRAULICS - PILOT CONTROL LINES, SWING (A) |
| 08-12 | 00 | HYDRAULICS - PILOT CONTROL LINES, TRAVEL ALARM |
| 08-13 | 00 | HYDRAULICS - PILOT CONTROL LINES, SWING - TRAVEL ALARM |
| 08-14 | 00 | HYDRAULICS - PILOT CONTROL LINES, SWING - TRAVEL ALARM (A) |
| 08-15 | 00 | HYDRAULIC LINES - VALVE, SOLENOID - SWING |
| 08-16 | 00 | HYDRAULIC LINES - LOWER |
| 08-17 | 00 | HYDRAULIC LINES - BOOM |
| 08-18 | 00 | HYDRAULIC LINES - BOOM (NIBBLER & BREAKER) |
| 08-19 | 00 | HYDRAULIC LINES - ARM |
| 08-20 | 00 | PUMP ASSY |
| 08-21 | 00 | PUMP - SHAFT |
| 08-22 | 00 | PUMP - BLOCK |
| 08-23 | 00 | PUMP - PISTON |
| 08-24 | 00 | PUMP - COVER |
| 08-25 | 00 | PUMP - SPRING |
| 08-26 | 00 | PUMP - GEAR |
| 08-27 | 00 | PUMP - HOUSING |
| 08-28 | 00 | PUMP |
| 08-29 | 00 | MOUNTING - SWING MOTOR |
| 08-30 | 00 | MOTOR ASSY, SWING |
| 08-31 | 00 | GEAR ASSY, REDUCTION - MOTOR, SWING |
| 08-32 | 00 | MOTOR, SWING |
| 08-33 | 00 | MOTOR, SWING - VALVE, PRESSURE RELIEF |
| 08-34 | 00 | HYDRAULICS - JOINT, SWIVEL CENTER |
| 08-35 | 00 | VALVE MOUNTING |
| 08-36 | 00 | VALVE ASSY - CONTROL |
| 08-37 | 00 | VALVE ASSY - DOZER BLADE |
| 08-38 | 00 | VALVE ASSY - SWING |
| 08-39 | 00 | VALVE ASSY - INLET |
| 08-40 | 00 | SERVICE VALVE |
| 08-41 | 00 | VALVE ASSY - BOOM SWING |
| 08-42 | 00 | VALVE ASSY - ARM |
| 08-43 | 00 | VALVE ASSY - TRAVEL CONTROL RIGHT HAND |
| 08-44 | 00 | VALVE ASSY - STRAIGHT TRAVEL |
| 08-45 | 00 | VALVE ASSY - TRAVEL CONTROL LEFT HAND |
| 08-46 | 00 | VALVE ASSY - BOOM |
| 08-47 | 00 | VALVE ASSY - BOOM LOCK |
| 08-48 | 00 | VALVE ASSY - BUCKET |
| 08-49 | 00 | VALVE ASSY - PRESSURE RELIEF |



Order the manual at mid-west-tech.com >

# TABLE OF CONTENTS


| | | |
|---|---|---|
| 08-50 | 00 | VALVE ASSY - BLEEDER |
| 08-51 | 00 | VALVE ASSY - PILOT |
| 08-52 | 00 | VALVE ASSY - PILOT, TRAVEL |
| 08-53 | 00 | VALVE, SOLENOID - SWING |
| 08-54 | 00 | VALVE ASSY - SOLENOID, TRAVEL ALARM |
| 08-55 | 00 | VALVE, SOLENOID - TRAVEL ALARM |
| 08-56 | 00 | VALVE ASSY - SOLENOID, PRESSURE RELIEF |
| 08-57 | 00 | VALVE ASSY - STOP |
| 08-58 | 00 | VALVE ASSY - SHUTTLE |
| 08-59 | 00 | VALVE ASSY, SELECTOR - PILOT |
| 08-60 | 00 | VALVE ASSY, SELECTOR - NIBBLER & BREAKER |
| 08-61 | 00 | CYLINDER ASSY, BOOM - CANOPY |
| 08-62 | 00 | CYLINDER ASSY, BOOM - CAB |
| 08-63 | 00 | CYLINDER ASSY, ARM |
| 08-64 | 00 | CYLINDER ASSY, BUCKET |
| 08-65 | 00 | CYLINDER, DOZER BLADE |
| 08-66 | 00 | CYLINDER, SWING |
| 08-67 | 00 | MOUNTING - BOOM AND ARM CYLINDERS |
| 08-68 | 00 | HYDRAULIC TANK - FILTERS |
| 09-01 | 00 | TURNTABLE BEARING |
| 09-02 | 00 | TURNTABLE - ACCESS COVERS |
| 09-03 | 00 | COUNTERWEIGHT |
| 09-04 | 00 | COUNTERWEIGHT - GAIN |
| 09-05 | 00 | BRACKET ASSY - SWING, CANOPY (NIBBLER & BREAKE) |
| 09-06 | 00 | BRACKET ASSY - SWING, CAB (NIBBLER & BREAKER) |
| 09-07 | 00 | COVER - SUPPORTS, CANOPY |
| 09-08 | 00 | COVER - SUPPORTS, CAB |
| 09-09 | 00 | COVER - PANELS, CANOPY |
| 09-10 | 00 | COVER - PANELS, CAB |
| 09-11 | 00 | COVER AND LOCK ASSY |
| 09-12 | 00 | PLATES, FLOOR - CANOPY |
| 09-13 | 00 | PLATES, FLOOR - CAB |
| 09-14 | 00 | MAT, FLOOR - HAND CONTROL (OPTIONAL) |
| 09-15 | 00 | CANOPY |
| 09-16 | 00 | CAB - GLASS |
| 09-17 | 00 | CAB - WINDOW, FRONT |
| 09-18 | 00 | CAB DOOR |
| 09-19 | 00 | CAB - ELECTRICAL, CONNECTIONS |
| 09-20 | 00 | CAB MOUNTING |
| 09-21 | 00 | CAB HEAD GUARD |
| 09-22 | 00 | SEAT MOUNTING AND SEAT BELT |
| 09-23 | 00 | CONTROLS - OPERATORS COMPARTMENT |
| 09-24 | 00 | STAND CONTROL - CANOPY |
| 09-25 | 00 | STAND CONTROL - CAB |
| 09-26 | 00 | CONTROL BOX ASSY - LEFT HAND |
| 09-27 | 00 | CONTROL BOX ASSY - RIGHT HAND |
| 09-28 | 00 | LEVER ASSY - CANOPY |
| 09-29 | 00 | LEVER ASSY - CAB |
| 09-30 | 00 | CONTROL PEDAL AND LEVER ASSY |
| 09-31 | 00 | INSTRUMENT PANEL ASSY - CANOPY |
| 09-32 | 00 | INSTRUMENT PANEL ASSY - CANOPY (TRAVEL ALARM) |



Order the manual at mid-west-tech.com >

## LEVER ASSY - CAB

| REF | FN | PART NUMBER | YR/SN | QTY | DESCRIPTION |
|---|---|---|---|---|---|
| | | YJ03M01046F2 | | 1 | LEVER Incl. 1 - 9 |
| 2 | | PW03M01302P1 | | 1 | BRACKET |
| 3 | | ZW16H12000 | | 1 | WASHER |
| 4 | | ZN18C12010 | | 2 | NUT |
| 5 | | ZN18C08007 | | 2 | NUT |
| 6 | | ZS18C08025 | | 2 | SCREW |
| | | PM03M01499F1 | | 1 | LEVER ASSY. Incl. 8, 9 |
| 8 | | PM03M01498P1 | | 1 | LEVER |
| 9 | | (2405R312D142D) | | 2 | BUSHING |



MidWestTech | New Holland EH35 Compact Excavator Parts Catalog | Publication 7-9330 Order the manual at mid-west-tech.com >

## HEATER UNIT - CAB

| REF | FN | PART NUMBER | YR/SN | QTY | DESCRIPTION |
|---|---|---|---|---|---|
| 1 | | PM21M00005F1 | | 1 | HEATER ASSY. |
| 2 | | PM21M01020P1 | | 1 | PLATE |
| | | PM21M01026F1 | | 1 | DUCT Incl. 3 - 5 |
| 3 | | PM21M01025P1 | | 1 | DUCT |
| 4 | | PM21M01015P1 | | 2 | INSULATION, FOAM |
| 5 | | PM21M01016P1 | | 1 | RUBBER |
| 6 | | {R18T0026D53} | | 1 | HOSE |
| 7 | | {R18T0026D52} | | 1 | |
| 8 | | {YN20M01046DU} | | 1 | TUBE |
| 9 | | {YN20M01046DC} | | 1 | TUBE |
| 10 | | {PW21M01011P1} | | 1 | ELBOW |
| 11 | | PH21M01008P1 | | 1 | CONNECTOR |
| 12 | | 2444Z1630 | | 1 | CONNECTOR |
| 13 | | ZM11C08016 | | 2 | BOLT |
| 14 | | {ZM11C08020} | | 2 | |
| 15 | | ZC16X02000 | | 4 | CLIP |
| 16 | | PV21M01012P1 | | 1 | PLUG |
| 17 | | PV21M01010P1 | | 1 | BUSHING |
| 18 | | PU21M01014P1 | | 1 | GASKET |
| 24 | | 2420Z699 | | 1 | GROMMET |
| 25 | | 2432R226D13 | | 1 | CLAMP |
| 26 | | ZW16X10000 | | 1 | WASHER |
| 27 | | ZN18C10008 | | 1 | NUT |
| | | PM03M01410F4 | | 1 | COVER ASSY Incl. 28 - 36 |
| 28 | | PM03M01412P1 | | 1 | COVER |
| 29 | | PM03M01281P2 | | 1 | COVER |
| 30 | | PM03M01282P1 | | 1 | RUBBER |
| 31 | | YX21C01159F1 | | 1 | LOCK |
| 32 | | {YN12C01692D8} | | 1 | TRIM |
| 33 | | PM03M01347P1 | | 1 | RUBBER |
| 34 | | PM03M01341P1 | | 1 | INSULATION, FOAM |
| 35 | | PM03M01343P1 | | 1 | RUBBER |
| 36 | | PM03M01342P1 | | 1 | RUBBER |
| 37 | | PV01P01007P1 | | 2 | WASHER |
| 38 | | 2414Z306D2 | | 1 | CAP |
| 39 | | PA03M01093D2 | | 4 | BOLT |



MidWestTech | New Holland EH35 Compact Excavator Parts Catalog | Publication 7-9330 Order the manual at mid-west-tech.com >

TOOLS

| REF | FN | PART NUMBER | YR/SN | QTY | DESCRIPTION |
|---|---|---|---|---|---|
| 1 | | PW01T00003F1 | | 1 | GUN, GREASE |
| 2 | | LC20T01001P1 | | 1 | LABEL |
| | | PM01T00003F2 | | 1 | TOOL ASSY. Incl. 3 - 5 |
| 3 | | PM01T01002P1 | | 1 | SOCKET WRENCH |
| 4 | | PW01T01005P1 | | 1 | CASE |
| 5 | | YJ23H00001P1 | | 1 | WRENCH, OPEN END |



MidWestTech | New Holland EH35 Compact Excavator Parts Catalog | Publication 7-9330 Order the manual at mid-west-tech.com >