PTH50 SERIES

MAINTENANCE MANUAL AND PARTS CATALOG



Order Number: 812572-006
Revision: A • Printed in Germany

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

INTRODUCTION 1
Important Information 3
Manual structure 3
Text mark-ups in the manual 3
Service personnel qualification 3
Ordering spare parts 3
Ordering documentation 3

SAFETY 5
Safety Notices 7
Basic Safety Notices 8
Organisational measures 8
Personal safety equipment 8
Protecting the hazardous area 8
Hazards from stored energy 8
Repair work 8
Restoring the truck to service after repair work 9
Cleaning work 9
Handling batteries 9
Warning and instruction decals on the truck 9
Lifting gear and slings 9
Environmental protection 10

LUBRICATION & ADJUSTMENT 11
Cleaning the Truck and Components 13
Effects of incorrect cleaning 13
Electrical components 13
Roller and slide bearings 13
Corrosion-protected surfaces 13
Environmental protection 13
Cleaning the entire truck 13
Cleaning removed components 14
Cleaning mechanical components 14
Components 15
Data plate 15
PTH50 PS and S components 15
PTH50 WS components 16
Lubricants and Consumables 17
Cold store application requirements 17
Abbreviations used in the table 17
Regular inspection in accordance with FEM 4.004 19
Planned Maintenance - PTH50, PTH50 GLV and PTH50 WS 20
Maintenance Interval 20
Inspection points 21
Lubrication points 21
PTH50 PS and S Planned Maintenance 22
Maintenance Interval 22
Inspection points 22
Lubrication points 23
Troubleshooting 24

MidWestTech | Crown PTH50 Pallet Jack Service Manual & Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

All models 24
Troubleshooting (PTH50 PS only) 25

HYDRAULIC SYSTEM 27
Hydraulic Unit 29
Functional Description 29
Lifting 29
Actuating lever in neutral position 29
Lowering 29
Service 32
Approved hydraulic oils 32
Adding hydraulic oil (all models except PTH50 PS and PTH50 S) 32
Adding hydraulic oil (PTH50 PS) 33
Adding hydraulic oil (PTH50 S) 34
Replacing the Hydraulic Unit 35
Replacing the hydraulic unit (all models except PTH50 PS and PTH50 S) 35
Hydraulic unit disassembly 35
Hydraulic unit assembly 35
Replacing the hydraulic unit (PTH50 PS) 35
Hydraulic unit disassembly 35
Hydraulic unit assembly 36
Replacing the hydraulic unit (PTH50 S) 36
Hydraulic unit disassembly 36
Hydraulic unit assembly 36
Repairing the Hydraulic Unit (all models except PTH50 S version 1) 37
Replacing the piston ram and seals 37
Replacing the piston ram and seals 37
Replacing the control piston and seals 38
Replacing the valve cartridge 38
Repairing the Hydraulic Unit (PTH50 S version 2) 39
Replacing the piston ram and seals 39
Replacing the control piston and seals 39
Cleaning and repairing the control valves 40
Relief Valve 43
Checking the operation of the hydraulic unit relief valve 43
Replacing the relief valve on the hydraulic unit (all models except PTH50 S version 2) 43
Repairing and adjusting the relief valve on the hydraulic unit (PTH50 S version 2 only) 43
Testing the relief valve on the hydraulic aggregate (PTH50 PS) 43
Adjusting the relief valve on the hydraulic aggregate (PTH50 PS only) 44
Adjusting the control piston 44
Replacing the Hydraulic Aggregate (PTH50 PS) 45
Disassembly 45
Assembly 45
Replacing the Pump Connecting Plate and Hydraulic Pump (PTH50 PS) 46
Servicing the Hydraulic Aggregate (PTH50 PS) 47
Replacing the hydraulic filter 47
Replacing the pressure filter 47
Replacing the suction and return filters 47
Replacing the hydraulic oil 47

ELECTRICAL SYSTEM 49
On-Board Charger (PTH50 PS) 51
Charging the battery 51

MidWestTech | Crown PTH50 Pallet Jack Service Manual & Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

Error messages ... 52
Battery (PTH50 PS) ... 54
Replacing the battery ... 54
Miscellaneous Electrical Components and Functions ... 55
Fuses (PTH50 PS) ... 55
FU1 ... 55
FU2 ... 55
FU3 ... 55
Emergency Disconnect switch ... 55
Lift cutout on falling battery voltage ... 55
PTH50 WS, Electrical Components ... 56
PTH50 WS - Weigher System ... 57
General ... 57
Standardised weighing scales ... 57
Display resolution ... 57
Accuracy ... 57
Calibrating the 2100 Weighing Scale ... 58
Required tools ... 58
Calibration stages ... 58
Calculating the weighing curve ... 58
Decision factor for 1-point or 3-point calibration ... 59
1-point calibration of 2100 weighing scale ... 60
3-point calibration of 2100 weighing scale ... 61
Calibrating the 4100 Weighing Scale ... 63
Required tools ... 63
Calibration stages ... 63
Calculate the weighing curve ... 63
Decision factor for 1-point or 3-point calibration ... 64
1-point calibration of 4100 weighing scale ... 65
3-point calibration of the 4100 weighing scale ... 67
PTH50 WS Weighing Scale, Troubleshooting ... 69
Most common error causes ... 69
No display ... 69
No display despite buttons being pressed ... 69
Unstable display ... 69
Same weight raised several times shows different readings ... 70
Weighing scale is inaccurate ... 71
Load Cell Replacement ... 72
Load cell removal ... 72
Load cell assembly ... 73
Repairing Contactors ... 74
Wear test ... 74
Checking the contacts ... 74
Checking the coils ... 74
Checking the springs ... 74
Pump Motor (PTH50 S) ... 75
Checking the carbon brushes and commutator ... 75

BRAKE SYSTEM ... **77**
Parking Brake ... 79
Checking the parking brake setting ... 79
Adjusting the parking brake ... 79

MidWestTech | Crown PTH50 Pallet Jack Service Manual & Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >