40 Cruz-Air Series E

Parts Catalog

8-1460

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Accelerator and Shut-Off Linkage on Engine .3-19
Accelerator Master Cylinder .3-21
Accelerator Pedal and Linkage .3-15
Accelerator Slave Cylinder .3-23
Accelerator Swivel .3-25
Actuator Brake .7-179
Actuator, Steering .5-89
Air Brake Valve, Digging .7-167
Air Brake Valve, Safety .7-169
Air Chamber, Maxibrake .7-177
Air Cleaner .2-7
Air Compressor .7-149
Air Compressor Cooling and Lubrication Lines .7-147
Air Compressor Governor .7-161
Air Controls, Hi-Low Shifter .7-193
Air Cylinder, Hi-Low .7-195
Air Lines, Upper .7-187
Air Solenoid Valve: Fast Hoist .4-43
Air Solenoid Valve: Outrigger .4-45
Air Supply from Compressor to Reservoir to Actuator .7-153
Air Swivel, 3-Port .7-159
Air Valve, Foot Brake .7-171
Air Valve, Parking and Emergency .7-167
Air Valve, Single Check .7-169
Alarm, Back-up .4-79
Alcohol Evaporation Kit .7-145
Alternator .4-47
Alternator Mounting .4-51
Auxiliary Hydraulic Tubing .8-267
Auxiliary No. 1 Control and Linkage, Hoist .8-305, 8-307
Auxiliary No. 2 Control and Linkage .8-309
Axle Housing .6-105
Axle Housing and Attaching Parts .6-95
Axle Identification .6-93
Axle Lockout Control Linkage .9-327

B

Backhoe Buckets .9-371
Backhoe Buckets with Esco Cutting Edge .9-373
Back-up Alarm .4-79
Battery, Cables and Hold Down Bracket .4-53
Bearing and Counterweight, Turntable .9-329
Bearing Lubrication Line, Turntable .9-331
Boom and Dipperstick, "E" Main .9-395
Boom and Plate, Heel: For "Y" Boom and Tree Length Grapple .9-403
Boom and "Y" Tool Boom, "Y" Main .9-397

B

Boom Extension, "Y" Tool .9-399
Boom Support and Tool Box .9-333
Brackets, Engine and Transmission Mounting .9-323
Brake Actuator .7-179
Brake Air Valve, Foot .7-171
Brake Assembly, Parking .7-185
Brake Relay Valve .7-163
Brake, Swing .9-407
Brake, Swing Control .9-409
Brake Tubing .7-157
Brake Valve, Quick Release .7-159
Brakes .7-181, 7-183
Buckets:
- Backhoe .9-371
- Concrete Removal .9-381
- Ditch .9-375
- 4-in-1 .9-379
- Front Loader .9-377
- With Esco Cutting Edge, Backhoe .9-373

C

Cab and Attaching Parts .9-353, 9-355
Cab and Attaching Parts, Logger .9-363
Cab Door and Attaching Parts .9-357
Cab Front Windows and Attaching Parts .9-359
Cab Front Windows, Logger .9-365
Cab Insulation .9-361
Cab Insulation, Logger .9-367
Cab Vandal Guard and Attaching Parts .9-343
Cable, Hoses and Wiring: 30" and 60" Riser .8-277
Center Swivel Assembly .7-165
Check Air Valve, Single .7-169
Check Valve .8-235
Circuit Relief Valve .8-229
Cleaner, Air .2-7
Cold Start Kit .2-9
Collector Ring, Electrical .4-39
Collector Ring Wiring, Electrical Diagram for .4-41
Compressor, Air .7-149
Concrete Removal Bucket .9-381
Control and Linkage, Auxiliary No. 2 .8-309
Control and Linkage, Hoist and Auxiliary No. 1 .8-305, 8-307
Control and Linkage, 30" and 60" Riser .8-317
Control Handle and Linkage, Crowd .8-301
Control Pedal and Linkage, Swing .8-311
Control Pedal and Linkage, Tool .8-303
Control, Remote Shifter: Lower .8-315

MidWestTech | Case 40 Cruz Air Excavator Parts Catalog | Publication 8-1460 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX (CON'T.)

C

Control, Remote Shifter: Upper 8-313
Control, Swing Brake 9-409
Control Valve, 3-Spool 8-215, 8-223
Control Valve, 2-Spool 8-225
Controls, Fast Hoist 7-191
Controls, Hi-Low Shifter 7-193
Controls, Outrigger Pneumatic 7-189
Converter and Transmission Hydraulic Tubing, Torque 6-119
Converter Oil Filters, Torque 6-121
Converter, Torque 6-113
Cooling and Lubrication Lines, Air Compressor 7-147
Counterweight, Turntable, Bearing and 9-329
Crossover Relief Valve, Grapple 8-233
Crowd Control Handle and Linkage 8-301
Crowd Cylinder Hydraulic Tubing 8-255, 8-257
Cylinder:
- Accelerator Master 3-21
- Accelerator Slave 3-23
- 4-in-1 8-291
- Grapple Arm 8-287
- Hi-Low Air 7-195
- Hoist and Crowd 8-283
- Outrigger 8-281
- Steering 5-91
- Tool 8-285
- Wheel 7-173, 7-175
- Wrist-O-Twist 8-289

D

Decals 9-345, 9-349
Differential 6-101, 6-109
Digging Air Brake Valve 7-167
Dipperstick, "E" Main Boom and 9-395
Ditch Bucket 9-375
Door and Attaching Parts, Cab 9-357
Drive Shaft 6-137, 6-139

E

"E" Boom Grapple Hydraulic Tubing 8-269
"E" Main Boom and Dipperstick 9-395
8-Port Hydraulic Swivel 8-297
Electrical Collector Ring 4-39
Electrical Diagram for Collector Ring Wiring 4-41
Engine and Fan 2-5
Engine Shrouding and Attaching Parts 9-335
Engine Shrouding Insulation 9-349
Engine and Transmission Mounting Brackets 9-323
Engine Wiring Harness 4-29
Extension, "Y" Tool Boom 9-399

F

Fan, Engine and 2-5
Fast Hoist: Air Solenoid Valve 4-43
Fast Hoist Controls 7-191
Fast Hoist Hydraulic Tubing 8-253
Filter, Torque Converter Oil 6-121
Filters, Fuel 3-13
Filters, Hydraulic Oil 8-199
Foot Brake Air Valve 7-171
4-in-1 Bucket 9-379
4-in-1 Cylinder 8-291
4-in-1 Hydraulic Tubing 8-265
Frame and Attaching Parts 9-321
Front Loader Bucket 9-377
Fuel Filters 3-13
Fuel Tank and Lines 3-13

G

Governor, Air Compressor 7-161
Grapple Arm Cylinder 8-287
Grapple Crossover Relief Valve 8-233
Grapple Hydraulic Tubing 8-273, 8-275
Grapple Hydraulic Tubing, "E" Boom 8-269
Grapple Hydraulic Tubing, "Y" Boom 8-271
Grapple Motor, Hydraulic 8-293
Grapple, Pulpwood: 1/2 Cord 4' Wood 9-383
Grapple, Pulpwood: 5/8 Cord 8' Wood 9-385
Grapple, Pulpwood: 3/4 Cord 16' Wood 9-387
Grapple, Tree Length Wood 9-389
Guard and Attaching Parts, Cab Vandal 9-343
Guard, Upper Vandal 9-341

H

Heater Attaching Parts: Fuel Oil Fired 4-77
Heater Attaching Parts: Liquid Propane Fired 4-71
Heater: Fuel Oil Fired 4-73, 4-75
Heater: Liquid Propane Fired ..... 4-65 thru 4-69
Heavy Lift Attachment 9-405
Heel Boom and Plate: For "Y" Boom and Tree Length Grapple 9-403
Heel Plate: Used on "E" Boom 9-401
Hi-Low Air Cylinder 7-195
Hi-Low Shifter Controls 7-193
Hoist and Auxiliary No. 1 Control and Linkage 8-305, 8-307
Hoist and Crowd Cylinder 8-283
Hoist Control, Fast 7-191
Hoses and Wiring, Cable: 30" and 60" Riser 8-277
Housing and Attaching Parts, Axle 6-95
Housing, Axle 6-105
Hubs and Shafts 6-97, 6-107

MidWestTech | Case 40 Cruz Air Excavator Parts Catalog | Publication 8-1460 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX (CON'T.)

H

Hydraulic Grapple Motor 8-293
Hydraulic Oil Cooler Hydraulic Tubing 8-213
Hydraulic Oil Filter 8-197
Hydraulic Oil Tank 8-197
Hydraulic Pump 8-201, 8-203
Hydraulic Pump No. 2 to Outrigger Valve to Swivel Hydraulic Tubing 8-207
Hydraulic Swivel, 8-Port 8-297
Hydraulic Swivel: Heavy Lift Logger Attachment 8-299
Hydraulic Tubing:
- Auxiliary 8-267
- Crowd Cylinder 8-255, 8-257
- "E" Boom Grapple 8-269
- Fast Hoist 8-253
- 4-in-1 8-265
- Grapple 8-273, 8-275
- Hoist Cylinder 8-251
- Hydraulic Oil Cooler 8-213
- Low Pressure and Return 8-209
- Optional Front and Rear Outrigger 8-243, 8-245
- Power Sensing 8-239
- Rear Outrigger 8-247
- Steering 5-83, 5-85
- Tool Cylinder 8-259, 8-261
- Torque Converter and Transmission 6-119
- Wrist-O-Twist 8-263
- "Y" Boom Grapple 8-271

I

Index, Numerical 10-411
Instrument Panel and Attaching Parts 4-53
Instrument Panel Wiring Harness in Cab 4-33
Instrument Panel Wiring Harness on Engine Hood 4-27
Insulation, Cab 9-361
Insulation, Engine Shrouding 9-349

K

Kit, Alcohol Evaporation 7-145
Kit, Cold Start 2-9
Kit, Windshield Wiper 4-61, 4-63

L

Lift, Heavy Attachment 9-405
Lights and Parts, Work 4-57, 4-59
Lockout Control Linkage, Axle 9-327
Logger Cab and Attaching Parts 9-363
Logger Cab Front Windows 9-365
Logger Cab Insulation 9-367
Low Pressure and Return Hydraulic Tubing 8-209
Lubrication Lines, Air Compressor Cooling and 7-147

M

Main Boom and Dipperstick, "E" 9-395
Main Boom and "Y" Tool Boom, "Y" 9-397
Main - Lower Wiring Harness 4-31
Main Relief Valve 8-225
Maxibrake Air Chamber 7-177
Muffler and Attaching Parts 2-11

N

Numerical Index 10-411

O

Oil Cooler, and Hoses, Radiator 2-3
Oil Cooler Hydraulic Tubing, Hydraulic 8-213
Oil Filter, Hydraulic 9-199
Oil Filter, Torque Converter 6-121
Oil Tank, Hydraulic 9-197
Outrigger: Air Solenoid Valve 4-45
Outrigger Arms, Shoes and Pins 9-325
Outrigger Cylinder 8-281
Outrigger Electrical Wiring 4-37
Outrigger Hydraulic Tubing, Optional Front and Rear 8-243, 8-245
Outrigger Hydraulic Tubing, Rear 8-247
Outrigger Pneumatic Controls 7-189
Outrigger Valve to Swivel Hydraulic Tubing, Hydraulic Pump No. 2 to 8-207

P

Parking and Emergency Air Valve 7-167
Parking Brake Assembly 7-185
Pedal and Linkage, Accelerator 3-15
Planetary and Tire Rod 6-99
Pneumatic Controls, Outrigger 7-189
Power Sensing Hydraulic Tubing 8-239
Power Sensing Valve 8-241
Pulpwood Grapple ..... 9-383 thru 9-387
Pump, Hydraulic 8-201, 8-203
Pump No. 2 to Outrigger Valve to Swivel Hydraulic Tubing, Hydraulic 8-207

MidWestTech | Case 40 Cruz Air Excavator Parts Catalog | Publication 8-1460 Order the manual at mid-west-tech.com >