45 Cruz-Air

Parts Catalog

8-1710

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX
(BASIC EXCAVATOR and LOGGER SECTION)

A

Accelerator Lock Valve 367
Accelerator Master Cylinder 361
Accelerator Pedal and Linkage 351, 353
Accelerator and Shut Off Linkage 355, 357, 359
Accelerator Swivel 365
Actuator, brake 417, 419
Actuator, steering 527
Air Brake, foot valve 415
Air Brake Relay Valve 425
Air Brake Tubing:
  Actuator to Wheels 401, 403, 405
  Air Swivel to Brake Valve and Control Valves 407, 409
  Compressor to Reservoir 395, 395B
  Reservoir to Actuator 397, 399
Air Chamber, maxibrake 421
Air Check Valve 423
Air Cleaner 75, 77
Air Cleaner and Attaching Parts 71, 73
Air Compressor ..... 372 thru 393
Air Compressor Cooling Tubing 369, 371
Air Compressor Governor 377, 383, 389, 393
Air Dryer ..... 426 thru 433
Air Quick Release Brake Valve 413
Air Swivel 413
Air Valve 423, 435
Alarm, back-up 641
Alternator 49, 575
Arms, outrigger 59
Arrestor, spark 647
Axle Lockout 349
Axles:
  Axle Identification:
    Front 175
    Rear 177, 179
  Brake Cylinder 205, 207, 241, 243
  Brakes 201, 203, 237, 239
  Differential ..... 192 thru 199, 216 thru 235
  Housing 181, 209, 211
  Hubs and Shafts 183, 189, 213, 215
  Planetary and Tie Rod 185, 187, 191

B

Back-Up Alarm 641
Bearing, turntable 253
Brackets:
  Electrical Mounting 597, 599
  Heater Mounting 611, 613

B

Boom:
  "E" 299
  "Y" 303
Boom Support 53
Brake Actuator 417, 419
Brake, foot valve 415
Brake Relay Valve 425
Brake, swing 345
Brake, swing control 347
Buckets:
  Ditch 319
  Front Loader 317
  General Purpose 307, 309
  High Capacity 311, 313
  Severe Duty 315

C

Cab ..... 270 thru 293
Center Swivel Group 411
Circuit, relief valve 551, 553, 555
Cleaner, air 75, 77
Cleaner, air; and attaching parts 71, 73
Cold Weather Starter Kit 643
Column, steering 269
Control Linkage:
  Crowd and Auxiliary 335
  Hoist and Utility 333
  Swing and Tool 331
Control Valve, main 541, 543, 545
Converter, torque ..... 87 thru 125
Cooler, oil 79, 81
Counterweight, turntable; bearing 253
Cross-Over Valve 529
Cylinder, accelerator master 361
Cylinder, hydraulic:
  Crowd ..... 495 thru 497B
  Hoist 493, 493B
  Outrigger 501
  Steering 503, 503B
  Tool 499, 499B
  Wrist-O-Twist 505
Cylinder, slave 363

D

Decals ..... 600 thru 607
Defroster 609
Dipperstick 301

Printed in U.S.A.

Issued March 1982

MidWestTech | Case 45 Cruz Air Excavator Parts Catalog | Publication 8-1710 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX
(BASIC EXCAVATOR and LOGGER SECTION)

D

Drive Shaft:
- Engine to Transmission ... 247
- Transmission to Front Axle ... 249
- Transmission to Rear Axle ... 251

Dryer, air ... 426 thru 433

E

Electrical Mounting Brackets ... 597, 599
Electrical Wiring Section:
- 12 Volt:
  - Cab Lights, Back-Up Alarm and Horn ... 561
  - Collector Ring ... 587
  - Diagram of Collector Ring Harness ... 591
  - Electrical Pin and Socket Contacts ... 594
  - Engine ... 575
  - Engine Instrument Panel ... 567
  - Gauges and Jumper Wires ... 557
  - Lower Main Harness ... 581
  - Steering Column ... 571
  - Turntable ... 563
- 24 Volt:
  - Collector Ring ... 589
  - Diagram of Collector Ring Harness ... 593
  - Electrical Gauges and Jumper Wires ... 559
  - Electrical Pin and Socket Contacts ... 594
  - Engine ... 577, 579
  - Engine Instrument Panel ... 569
  - Instrument Panel ... 565
  - Lower Main Harness ... 583
  - Outrigger ... 585
  - Steering Column ... 573

Engine and Attaching Parts for CASE engine ... 65
Engine and Attaching Parts for DETROIT DIESEL engine ... 67
Engine Shrouding ... 61
Exhaust System ... 69
Engine Surge and Purge Lines ... 83

F

Filters:
- Hydraulic ... 509, 511
- Torque Converter ... 513

Flow Control Valve ... 539
Floor Mat ... 263
Floor Plate ... 263
Foot Valve for: Air Brakes ... 415
Frame and Attaching Parts ... 55, 57
Fuel Tank and Lines ... 85

G

Governor, air compressor ... 377, 383, 389, 393

H

Hand Control Valve Supports ... 263, 265
Heater ... 614 thru 635
Heater Mounting Brackets ... 611, 613
Hydraulic Cylinders:
- Crowd ... 495, 497
- Hoist ... 493
- Outrigger ... 501
- Steering ... 503
- Tool ... 499
- Wrist-O-Twist ... 505

Hydraulic Oil Filter:
- Hydraulic ... 509, 511
- Torque Converter ... 513

Hydraulic Pump, main ... 515, 515B
Hydraulic Swivel ... 507
Hydraulic Oil Tank and Attaching Parts ... 523
Hydraulic Tubing:
- Auxiliary:
  - "E" Boom ... 475
  - "Y" Boom ... 473
- Crowd, Hoist and Tool ... 465, 467
- "E" Boom and Dipperstick ... 471
- Fast Hoist ... 469
- Filter to Swivel ... 499
- Front Outrigger ... 481
- Hydraulic Oil Tank to Filter to Swivel ... 453, 455
- Hydraulic Oil Tank to Oil Cooler ... 445
- Hydraulic Oil Tank to Pump ... 447, 447B
- Main Pump to Relief Valves ... 451
- Main Valve to Swing Motor ... 463
- Power Sensing ... 457, 459
- Rear Outrigger ... 479
- Swivel to Main Valve ... 461
- Torque Converter and Transmission ... 436 thru 443
- Wrist-O-Twist ... 325
- "Y" Boom ... 473

I

Index, numerical ... 713
Instrument Panel ... 265
Insulation, engine instrument panel ... 63

Issued March 1982

Printed in U.S.A.

MidWestTech | Case 45 Cruz Air Excavator Parts Catalog | Publication 8-1710 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX
(BASIC EXCAVATOR and LOGGER SECTION)

L

Lights, work 637, 639
Lockout, axle 349
Logger and Attaching Parts:
  Cab 649, 651
  Cylinders, hydraulic:
    Grapple 691
    Grapple Boom 697, 699, 701
    Heel 693, 695
  "E" Boom, Heel Boom and Grapple Boom 663
  Grapple Hydraulic Swivel 689
  Grapple Motor 703
  Grapples:
    Pulpwood 667, 669, 671
    Tree Length 665
  Grapple Support 661
  Grapple Swivel 673
  Hydraulic Tubing:
    Grapple Cylinder 685, 687
    Grapple Motor 679, 681
    Grapple Motor Drain 683
    Main Boom Tubing:
      Pulpwood Logger 675
      Tree Length Logger 677
  Riser and Attaching Parts 655, 657, 659
  Valve, main 705, 707
  Wiper, windshield 653
  Worklight 709, 711

M

Main Frame and Attaching Parts 55, 57
Maxibrake Air Chamber 421
Motor, swing 519, 521

O

Oil Cooler and Attaching Parts 79, 81
Outrigger Air Tubing 483, 485
Outrigger Arms, Shoes and Pins 59
Outrigger Valve 547

P

Panel, instrument 265
Plate, floor 263
Power Sensing Relief Valve 533
Pumps:
  Power Steering 517
  Main Hydraulic 515, 515B
Purge Lines, engine 83

R

Radiator and Attaching Parts 79, 81
Reducer, swing ..... 336 thru 343
Relief Valve, main 549
Ripper Tooth 321

S

Seat Assembly 267
Shifter Control 327, 329
Shrouding, engine 61
Shrouding, turntable 257, 259, 261
Shut-Off Linkage 355, 357, 359
Slave Cylinder 363
Solenoid Valve 535, 537
Spark Arrestor 647
Starter Kit, cold weater 643
Steering Actuator 527
Steering Column 269
Steering Selector Valve 531
Steering Tubing:
  Pump to Swivel to Cylinder 487, 489
  Swivel to Steering Actuator 491
Support, boom 53
Support, hand control valve 263, 265
Surge Lines, engine 83
Swing Brake 345
Swing Brake Control 347
Swing Inline Relief Valve 525
Swing Motor 519, 521
Swing Reducer ..... 336 thru 343
Swivel, accelerator 365
Swivel, air 413
Swivel, center group 411
Swivel, hydraulic 507

Printed in U.S.A. Issued March 1982

MidWestTech | Case 45 Cruz Air Excavator Parts Catalog | Publication 8-1710 Order the manual at mid-west-tech.com >