W14, W14H & W14FL Loaders

S/N9119672 and After

Parts Catalog

8-1741

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

GENERAL INFORMATION

Indexes

This parts catalog is arranged for easy identification on parts. The Alphabetical Index at the front of the catalog gives location of major groups and assemblies. The Numerical Index at the rear of the catalog gives part numbers and the page on which they are listed.

Abbreviations and Terms

PIN - Product Identification Number.
SN - Serial Number.
NSS - Not sold separately.
REF - Reference. Used to clarify drawing.
RESERVED - No item listed.
UAR - Use as required.

Changes

When changes are made to the machine, revised pages for this catalog will be issued. These pages must be inserted into your catalog as soon as they are received. Failure to keep your catalog up to date will result in confusion and may cause you to order wrong parts.

Orders

Orders should specify correct part number, full description, quantity required, machine and engine model, machine and engine serial numbers, method of shipment and shipping address.

Right-Hand and Left-Hand Sides

The terms right-hand and left-hand (abbreviated to RH and LH) as used in this catalog indicate the right and left sides of the machine as viewed by the operator in the normal operating position for proper operation of the machine or attachment.

U.S. and Metric Units

Sizes, lengths, and dimensions are given in U.S. units followed by its equivalent in metric units. See item 8 below. Sizes of hardware (bolts, nuts, etc.) are given according to hardware type --- in inches for U.S. hardware; in millimeter for metric hardware. See items 9 and 10.

Description, Quantity and Machinery Items

All parts are briefly described under DESCRIPTION. The quanitity used is listed under REQ'D. Notice in the example below that the description of some items is moved in (indented) from the left-hand margin. An indented item is part of the item under which it is indented. The example shows that one hydraulic oil filter is used on the machine. Each filter contains one head assembly, one element kit, and one housing (indented items with no reference numbers and item 6). The head assembly and kit are further divided to show individual part (items 2, 3, 4 & 5).

Machinery items must be ordered from the Machinery Price List. See item 7 in the example.

REF.	PART NO.	DESCRIPTION	REQ'D
1	D 43567	FILTER ASSEMBLY - hydraulic oil	1
	D 61903	HEAD ASSEMBLY - filter	1
2	NSS	HEAD - filter	1
3	D 58199	VALVE - bypass	1
	D 43800	KIT - filter element	1
4	NSS	ELEMENT - filter	1
5	A 27994	O-RING - filter	1
6	D 42439	HOUSING - filter	1
7	REF	CANOPY - ROPS, machinery item, see page 2 for ordering	2
8	R 42849	HOSE - from upper valve port, 38" (965 mm) long	1
9	13- 728	BOLT - hex head, 7/16" - 14 NC x 1-3/4"	2
10	814- 8030	BOLT - hex head, 8 mm - 1.25 x 30 mm (8.8)	2

800732B

Order the manual at mid-west-tech.com >