45 Cruz-Air Series B

P.I.N. 6295257 & After

Parts Catalog

8-1890

MidWestTech | Case 45 Cruz Air Series B Excavator Parts Catalog | Publication 8-1890

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX
(BASIC EXCAVATOR and LOGGER SECTION)

A

Accelerator Lock Valve 3-75
Accelerator Master Cylinder 3-69
Accelerator Pedal and Linkage 3-61
Accelerator and Shut Off Linkage 3-63, 3-65, 3-67
Accelerator Slave Cylinder 3-71
Accelerator Swivel 3-73
Actuator, brake 7-263
Actuator, steering 5-149, 5-151
Air Brake Valve 7-257
Air Brake Relay Valve 7-249
Air Brake Tubing:
  Actuator to Wheels 7-239, 7-241
  Air Swivel to Brake Valve and
    Control Valves 7-271, 7-271B
  Compressor to Reservoir 7-235
  Fast Hoist 7-275
  Outrigger Pneumatic Controls 7-273
  Reservoir to Actuator 7-237
Air Chamber, maxibrake 7-261
Air Check Valve 7-255
Air Cleaner 2-17
Air Cleaner and Attaching Parts 2-15
r Compressor 7-229, 7-231, 7-233
Air Compressor Cooling Tubing 7-225, 7-227
Air Compressor Governor 7-245, 7-247
Air Quick Release Brake Valve 7-243
Air Swivel 7-243
Air Valve 7-253
Alarm, back-up 4-141
Alcohol Evaporation Kit 7-223
Alternator 4-111, 4-113
Arms, outrigger 9-409
Arrestor, spark 2-27
Axle Lockout 9-411
Axle Identification:
  Front 6-157
  Rear 6-159

B

Back-Up Alarm 4-141
Battery, Cables and Hold Down Bracket 4-77
Bearing, turntable 9-413
Brackets:
  Electrical Mounting 4-115
  Heater Mounting 4-125, 4-131
  Boom:
    "E" 9-487
    "Y" 9-491

B

Boom Support 9-417
Brakes 7-265, 7-267, 7-269
Brake Actuator 7-263
Brake, Air Valve 7-257
Brake Relay Valve 7-249
Brake, swing 9-499
Brake, swing control 9-497
Brake Wheel Cylinder 7-259
Buckets:
  Ditch 9-471
  Front Loader 9-473
  General Purpose 9-465
  High Capacity 9-467
  Severe Duty 9-469

C

Cab . . . . . 9-441 thru 9-449
Cab Insulation 9-441
Cab Window Glass 9-451
Center Swivel Group 7-251
Circuit, relief valve . . . . . 8-313 thru 8-317
Cleaner, air 2-17
Cleaner, air and attaching parts 2-15
Cold Weather Starter Kit 2-23
Column, steering 5-143
Control Linkage:
  Auxiliary 8-395
  Crowd 8-393
  Hoist and Utility 8-391
  Swing 8-389
  Tool 8-387
Control Valve, main . . . . . 8-301 thru 8-309
Converter, torque . . . . . 6-183 thru 6-191
Cooler, oil 2-3, 2-5
Counterweight, turntable; bearing 9-413
Cross-Over Valve 8-321
Cylinder, accelerator master 3-69
Cylinder, hydraulic:
  Crowd 8-363, 8-365
  Hoist 8-361
  Outrigger 8-359
  Steering 5-155
  Tool 8-367
  Wrist-O-Twist 8-375
Cylinder, slave 3-71

Printed in U.S.A.
Issued September 1982

MidWestTech | Case 45 Cruz Air Series B Excavator Parts Catalog | Publication 8-1890
Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX (CON'T.)
(BASIC EXCAVATOR and LOGGER SECTION)

D

Decals ..... 9-429 thru 9-433
Defroster 4-135
Dipperstick 9-489
Drive Shaft:
- Torque Converter to Transmission 6-219
- Transmission to Front Axle 6-215
- Transmission to Rear Axle 6-217

E

Electrical Mounting Brackets 4-115
Electrical Wiring Section:
- Back-up Alarm 4-85
- Cab Main 4-83
- Collector Ring 4-99
- Console Wiring Harness 4-91, 4-93
- Diagram of Collector Ring Harness 4-99, 4-101
- Electrical Pin and Socket Contacts 4-101
- Engine 4-87, 4-89
- Engine Hood Instrument Panel 9-421
- Engine Hood Instrument Panel Wiring 4-95
- Fast Hoist 4-85
- Instrument Panel 4-105
- Lower Main Harness 4-79
- Outrigger 4-81
- Steering Column 4-85
- Work Lights 4-97

Engine and Fan 2-9
Engine Mounting Brackets 9-407
Engine Shrouding 9-421
Engine Subassemblies
- Alternator 4-111, 4-113
- Block Heater 2-31
- Camshaft 2-41
- Crankshaft 2-37
- Cylinder Block 2-31
- Cylinder Head and Cover 2-29
- Flywheel and Housing 2-37, 2-43
- Fuel Filter System 3-53
- Fuel Injection System 3-57
- Gasket Kits 2-49
- Injector Nozzles 3-59
- Injection Pump 3-55
- Injection Pump Drive 2-39
- Oil Filter and Cooler 2-47
- Oil Pump and Pan 2-45
- Manifolds, intake and exhaust 2-21
- Piston and Connecting Rods 2-35
- Starter 4-107, 4-109

E

- Timing Gear Cover 2-39
- Turbocharging System 2-19
- Valve Mechanism 2-33
- Water Manifold and Thermostat 2-13
- Water Pump 2-11

Exhaust System 2-25
Engine Surge and Purge Lines 2-7

F

Fan, Engine and 2-9
Filters:
- Hydraulic 8-279
- Torque Converter 6-197

Flow Control Valve 8-325
Floor Mat 9-461
Floor Plate 9-461
Foot Valve for: Air Brakes 7-257
Frame and Attaching Parts 9-403, 9-405
Fuel Tank and Lines 3-51

G

Governor, air compressor 7-245, 7-247

H

Heater ..... 4-116 thru 4-129
Heater Mounting Brackets 4-125, 4-131
Heater Shrouding 4-133
Hydraulic Cylinders:
- Crowd 8-363, 8-365
- Hoist 8-361
- Outrigger 8-359
- Steering 5-155
- Tool 8-367
- Wrist-O-Twist 8-375

Hydraulic Oil Filter:
- Hydraulic 8-279
- Torque Converter 6-197

Hydraulic Pump, main 8-281
Hydraulic Swivel 8-381
Hydraulic Oil Tank and Attaching Parts 8-277
Hydraulic Tubing:
- Auxiliary:
  - "E" Boom 8-341
  - "Y" Boom 8-339
- Crowd, Hoist and Tool ..... 8-333, 8-335, P

Issued September 1982

Printed in U.S.A.

MidWestTech | Case 45 Cruz Air Series B Excavator Parts Catalog | Publication 8-1890

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX (CON'T.)
(BASIC EXCAVATOR and LOGGER SECTION)

H

"E" Boom and Dipperstick 8-337
Fast Hoist 7-275
Filter to Swivel 8-295
Front Outrigger 8-327
Hydraulic Oil Tank to Filter to Swivel 8-289, 8-291
Hydraulic Oil Tank to Oil Cooler 8-297
Hydraulic Oil Tank to Pump 8-283
Main Pump to Relief Valves 8-285
Main Valve to Swing Motor 8-331
Power Sensing 8-287
Rear Outrigger 8-329
Swivel to Main Valve 8-293
Torque Converter and Transmission ..6-193, 6-195
Wrist-O-Twist 8-343
" Boom 8-335

I

..... 10-501
..... 4-105
el 9-435

L

Lights, work 4-97
Lockout, axle 9-411
Logger and Attaching Parts:
Cab 9-453, 9-455
Cab Insulation 9-457
Cab Window Glass 9-459
Cylinders, hydraulic:
Grapple 8-369
Grapple Boom 8-371
Heel 8-373
"E" Boom, Heel Boom and Grapple Boom ... 9-495
Grapple Hydraulic Swivel 8-385
Grapple Motor 8-377
Grapples:
Pulpwood 9-475, 9-477, 9-479
Tree Length 9-481
Grapple Support 9-419
Grapple Swivel 8-383
Hydraulic Tubing:
Grapple Cylinder 8-355, 8-357
Grapple Motor 8-349, 8-351
Grapple Motor Drain 8-353
Main Boom Tubing:
Pulpwood Logger 8-345
Tree Length Logger 8-347

L

Riser and Attaching Parts 9-437, 9-439
Valve, main 8-305, 8-307, 8-309
Wiper, windshield 4-137
Worklight 4-97

M

Main Frame and Attaching Parts 9-403, 9-405
Maxibrake Air Chamber 7-261
Mirror, rear view 9-447, 9-453
Motor, swing 8-379

N

Numerical Index 10-501

O

Oil Cooler and Attaching Parts 2-3, 2-5
Outrigger Air Tubing 7-273
Outrigger Arms, Shoes and Pins 9-409
Outrigger Valve 8-311

P

Panel, instrument 4-105
Plate, floor 9-461
Power Sensing Relief Valve 8-323
Pumps:
Power Steering 5-145
Main Hydraulic 8-281
Purge Lines, engine 2-7

R

Radiator and Attaching Parts 2-3, 2-5
Reducer, swing 9-401
Relief Valve, main 8-299
Ripper Tooth 9-483

S

Seat Assembly 9-463
Shifter Control 8-397, 8-399
Shrouding, engine 9-421
Shrouding, turntable 9-423, 9-425
Shut-Off Linkage 3-63, 3-65, 3-67
Slave Cylinder 3-71
Solenoid Valve 4-103

Printed in U.S.A.
Issued September 1982

MidWestTech | Case 45 Cruz Air Series B Excavator Parts Catalog | Publication 8-1890
Order the manual at mid-west-tech.com >