W30 Loader

Parts Catalog

Bur 8-2013

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

PICTORIAL SECTION INDEX



GENERAL 1

ENGINE 2

FUEL 3

ELECTRICAL 4

TRACK/ STEER. 5

POWER TRAIN 6

BRAKES 7

HYDRAULICS 8

CHASSIS/ MTD. EQUIP. 9

NUMERICAL INDEX 10

B900289

Bur 8-2013

Issued December, 1989

Printed in U.S.A.

MidWestTech | Case W30 Loader Parts Catalog | Publication 8-2013

Order the manual at mid-west-tech.com >

GENERAL INFORMATION

Indexes

Section 1 of this catalog contains a SN and P.I.N. location guide, alphabetical index, pictorial index of the sections included, and pictorial index(es) for quick location of hoses and tubes (and other system components in some catalogs). An alphabetical index also appears at the beginning of each section. Section 10 is the Numerical Index which lists all part numbers in alpha/numeric order with their page location and reference number.

Illustration and Text

The arrangement of this parts catalog is for easy identification of parts. All parts are illustrated in "exploded views" in proper relation to each other. Reference numbers used in the illustrations refer to those on the text pages. The text pages list reference number, part number, part description and the quantity required.

Abbreviations

P.I.N. "Product Identification Number"
SN "Serial Number"
NSS "Not Serviced Separately" in the part number column indicates this part is not available for service.
REF "Reference" in the part number column indicates this part has special service information. The page where this information can be found is given in the part description column.
UAR "Use As Required" in the quantity required column indicates the number of parts used is determined by service needs.

Right-Hand and Left-Hand Identification

The reference to right-hand and left-hand in this catalog is identified by the operator standing at the rear of the basic unit (without rear attachment), looking toward the front of the machine (in normal forward travel). For pages covering any machine attachments, right-hand and left-hand are defined by the operator sitting in the position for proper operation of the attachment.

Catalog Revisions and Supplements

Changes to the product may make it necessary to revise or add pages to this catalog. A cover sheet will list all pages released in a revision or supplement. Each new or revised page will have a new issue date. All revised and new pages must be put into the parts catalog as soon as they are received.

Parts Orders

Orders must specify product model, all necessary serial numbers, correct part number, complete description, quantity required, method of shipment, and shipping address.

Text Format Explanation

An assembly may contain many service items. The component parts of an assembly or subassembly are indented. The quantity required column lists the number of assemblies required for a complete machine, and the number of components required in a complete assembly or subassembly.

The example below illustrates the use of indents and other text page elements explained on this page.

REF.	PART NO.	DESCRIPTION	REQ'D.
1	D43567	FILTER ASSEMBLY - hydraulic oil, PIN 7534840 and after	1
	D61903	HEAD ASSEMBLY - filter	1
2	NSS	HEAD - filter, order D61903 head assembly	1
3	D58199	VALVE - bypass	1
	D43800	KIT - filter element, replaces D35700 kit	1
4	NSS	ELEMENT - filter, order D43800 element kit	1
5	A27994	O-RING - filter	1
6	D61948	HOUSING - filter	1
7	REF	CANOPY - ROPS, machinery item, order from Machinery Price List	1
8	843065C1	HOSE - 132 inch (3353 mm) long, reservoir to pump	1
9	113-323	BOLT - hex head, 7/16 - 14 NC x 1-3/4 inch, plated	2
10	814-8030	BOLT - hex head, 8 mm - 1.25 x 30 mm (8.8), plated	4

MidWestTech | Case W30 Loader Parts Catalog | Publication 8-2013 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Accelerator and Linkage 3-3
Accumulator 8-49,8-49B
Air Cleaner 2-37
Air Conditioning ..... 9-67 - 9-83
Air Compressor ..... 7-11 - 7-15
Alcohol Evaporator 7-17
Alternator Assembly ..... 4-3 - 4-7
Alternator Mounting 4-49,4-51
Auxiliary Steering 4-23,5-11,5-13
Axles
  Brakes 7-3
  Differentials ..... 6-79 - 6-83
  Housings 6-77
  Mounting 6-73
  Planetary 6-75
  Ring and Pinion Gear 6-81
  Shaft - planetary 6-75

B

Backup Alarm 4-77
Batteries and Cables 4-45
Beacon - rotating ..... 4-63 - 4-67
Belts
  Alternator and Fan 2-35
  Compressor - air conditioning 9-73
  Seat 9-37,9-39
Block - engine cylinder 2-19
Blower - cab 4-75
Brake Components
  Actuator - master 7-35
  Caliper 7-3
  Parking 7-21,7-23,7-37,7-39
  Pedal 7-33
  Valve 7-33
Brake System
  Actuator - parking brake 7-37,7-39
  Actuator to wheel Cylinders 7-31
  Actuators 7-19,7-27,7-35
  Air Compressor ..... 7-11 - 7-15
  Air Lines ..... 7-5 - 7-9,7-19
  Air Pressure Protection Valve 7-9,7-25,7-51
  Air Reservoir to Actuators 7-19
  Alcohol Evaporator 7-17
  Calipers 7-3
  Governor - air compressor 7-15
  Hydraulics ..... 7-27 - 7-31
  Master Cylinder 7-19,7-27,7-35
  Master Cylinder to Wheel Cylinders 7-31
  Parking Brake Valve to Actuator 7-21,7-23
  Parking Brake - transmission 6-29,6-65
  Reservoir - brake fluid 7-47
  Treadle Assembly and Valve 7-33

B

Brake System-Cont.
  Treadle to Horn 7-25
  Treadle to Clutch Cutout 7-21
Buckets
  Clam 9-15
  Standard 9-11,9-13
  Teeth 9-17

C

Cab - ROPS ..... 9-49 - 9-83
  Air Conditioner and Heater ..... 9-65 - 9-83
  Blower 4-75
  Defroster 4-73
  Doors and Windows ..... 9-53 - 9-61
  Electrical and Lighting 4-53,4-55
  Filters - air 9-57
  Glass 9-53,9-55
  Interior Covers 9-51
  Mounting Parts 9-49
  Noise Reduction Pads 9-63
  Ventilation Compartment 9-83
  Windshield Wipers 4-69,4-71
Camshaft - engine 2-17
Canopy - ROPS 9-85
Clam Bucket 9-15
Clutch Cutout 7-21,7-23
Clutches - see Transmission
Cold Start System 4-79
Compressor - air conditioning 9-75
Condenser - air conditioning 9-69,9-71
Condenser and Compressor Lines ..... 9-77 - 9-81
Connecting Rods - engine 2-25
Console - Remote Loader Valve 9-25,9-27
Controls
  Loader Height 9-3
  Loader Lift and Dump ..... 8-71 - 8-79
  Parking Brake 7-21,7-23
  Pedal - accelerator 3-3
  Pedal - brake 733
  Return-to-Dig 9-5
  Transmission 6-3,6-5
Converter - torque 6-15,6-39
Cooler - engine oil 2-7
Cooler - steering and equipment 8-13
Cooler - transmission oil 2-35
Cores - heating and air conditioning 9-81
Counterweight 9-21
Cover - front gear 2-31
Crankshaft - engine 2-21
Cylinder - master 7-35
Cylinder Block 2-19
Cylinder Head - engine 2-15

MidWestTech | Case W30 Loader Parts Catalog | Publication 8-2013 Order the manual at mid-west-tech.com >