December 1983 Issue
Model MW24C
NSN 3805-01-150-4814

Parts Catalog

8-2160

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

			Page	Illus Figure
Section I.		Introduction	1-1	
II.		Repair Parts List	2-1	
Group	01	Engine		
		0100 Engine Mounting	2-1	1
		0101 Cylinder block assembly	2-3	2
		0101 Cylinder head	2-5	3
		0102 Crankshaft	2-7	4
		0103 Flywheel and housing	2-9	5
		0104 Piston and connecting rods	2-11	6
		0105 Rocker arms and valves	2-13	7
		0105 Timing gear cover and idler gear	2-17	8
		0105 Camshaft	2-19	9
		0106 Oil pump	2-21	10
		0106 Oil pan	2-23	11
		0106 Oil filter, dipstick, cooler, and sampling valve	2-25	12
		0108 Manifolds	2-27	13
	03	Fuel system		
		0301 Fuel injector lines	2-29	14
		0301 Fuel injector	2-31	15
		0302 Fuel injection pump mounting and gear	2-33	16
		0302 Fuel injection pump	2-35	17
		0302 Fuel injection governor	2-39	18
		0302 Fuel injection feedpump	2-43	19
		0302 Electric fuel pump and lines	2-45	20
		0302 Electric fuel pump	2-47	21
		0304 Air cleaner	2-49	22
		0306 Fuel tank and lines	2-51	23
		0309 Fuel filters	2-53	24
		0311 Cold start kit	2-55	25
		0312 Accelerator	2-57	26
	04	Exhaust system		
		0401 Muffler and pipe	2-59	27
	05	Cooling system		
		0501 Radiator	2-61	28
		0503 Water manifold and thermostat	2-63	29
		0504 Water pump	2-65	30
		0505 Fan blade	2-67	31
	06	Electrical system		
		0601 Alternator and mounting	2-69	32
		0601 Alternator	2-71	33
		0603 Starter and mounting	2-73	34
		0603 Starter	2-75	35
		0607 Left hand instrument panel	2-79	36
		0607 Right hand instrument panel	2-81	37
		0607 Hourmeter/tachometer	2-83	38
		0608 Return-to-dig and bucket height circuits	2-85	39
		0608 Auxiliary steering electrical system	2-87	40
		0609 Front flood and driving lamps and mounting	2-89	41

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS (continued)

			Page	Illus Figure
Group	06	Electrical system (continued)		
		0609 Front and rear flood lamps	2-91	42
		0609 Black out driving lamp	2-93	43
		0609 Stop and tail light	2-95	44
		0609 Black out stop light-tail light	2-97	45
		0610 Sending units and warning switches	2-99	46
		0612 Batteries and slave receptacle	2-101	47
		0613 Front wiring harness	2-103	48
		0613 Rear wiring harness	2-105	49
		0613 Black out wiring harness	2-107	50
		0613 Cab upper wiring harness	2-109	51
		0613 Cab lower wiring harness	2-111	52
		0613 Cab console wiring harness	2-113	53
	07	Transmission		
		0700 Transmission mounting	2-115	54
		0708 Torque converter group	2-117	55
		0708 Converter housing	2-119	56
		0710 Transmission group	2-121	57
		0710 Transmission case	2-123	58
		0713 Forward clutch and planetary assembly	2-125	59
		0713 Reverse clutch and planetary assembly	2-127	60
		0713 High range clutch and planetary assembly	2-129	61
		0713 Output shaft	2-131	62
		0714 Control valve and mounting	2-133	63
		0714 Transmission control linkage	2-135	64
		0721 Charging pump	2-139	65
		0721 Filter and lines	2-141	66
		0721 Transmission cooler lines	2-143	67
	09	Drive shaft assemblies		
		0900 Front drive shaft assembly	2-145	68
		0900 Center drive shaft assembly	2-147	69
		0900 Rear drive shaft assembly	2-149	70
	10	Front axle		
		1000 Front axle assembly and mounting	2-151	71
		1002 Front axle differential carrier assembly	2-153	72
		1003 Front axle planetary assembly	2-157	73
	11	Rear axle		
		1100 Rear axle assembly and mounting	2-159	74
		1102 Rear axle differential carrier assembly	2-161	75
		1103 Rear axle planetary assembly	2-165	76
	12	Brakes		
		1201 Parking brake system	2-167	77
		1201 Parking brake	2-169	78
		1202 Service brakes	2-171	79
		1204 Hydraulic brake system hoses, lines, and fittings	2-173	80
		1204 Service brake caliper	2-175	81
		1204 Brake hydraulic reservoir	2-177	82

MidWestTech | Case MW24C Loader Parts Catalog | Publication 8-2160 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS (continued)

			Page	Illus Figure
Group	12	Brakes (continued)		
		1208 Air brake system hoses, lines, and fittings ...	2-179	83
		1208 Brake actuator	2-183	84
		1208 Brake treadle and valve assembly	2-185	85
		1208 Air reservoir	2-187	86
		1208 Double check valve and stop light switch	2-189	87
		1208 Pressure protection valve	2-191	88
		1209 Air compressor assembly	2-193	89
		1209 Governor assembly	2-197	90
		1209 Air compressor hoses, lines, and fittings	2-199	91
	13	Wheels and Tires		
		1311 Wheel and tire assembly	2-201	92
	14	Steering		
		1401 Steering wheel	2-203	93
		1407 Steering gear and steering column mounting	2-205	94
		1407 Steering gear and steering column	2-207	95
		1410 Auxiliary/emergency steering pump and motor and mounting	2-209	96
		1410 Auxiliary steering motor	2-211	97
		1411 Steering system hoses, lines, and fittings fittings	2-213	98
		1411 Auxiliary steering system hoses, lines, and fittings	2-215	99
		1411 Hydraulic oil cooler	2-217	100
		1411 Steering hydraulic filter and mounting	2-219	101
		1412 Steering cylinder assemblies and mounting	2-221	102
		1414 Flow control valve	2-223	103
	15	Frame		
		1501 Front chassis assembly	2-225	104
		1501 Chassis spindle assembly	2-227	105
		1501 Rear chassis assembly	2-229	106
	18	Body, cab, hood and hull		
		1801 Engine hood and guard assembly	2-231	107
		1801 Cab mounting	2-233	108
		1801 Cab noise reduction pads	2-235	109
		1802 Fenders	2-237	110
		1803 Cab latches	2-239	111
		1803 Cab doors	2-241	112
		1806 Operator's seat and seat support	2-245	113
	22	Accessories		
		2202 Outside mirrors.....	2-247	114
		2202 Cab inside mirror	2-249	115
		2202 Cab dome light	2-251	116
		2202 Windshield wiper mounting	2-253	117
		2202 Windshield wiper motor	2-255	118
		2202 Defogger assembly	2-257	119
		2202 Cab fan assembly	2-259	120
		2202 Windshield washer	2-261	121

MidWestTech | Case MW24C Loader Parts Catalog | Publication 8-2160 Order the manual at mid-west-tech.com >