1825 UNI-LOADER

Parts Catalogue - Catalogue Pièces
Ersatzteilkatalog - Catalogo Repuestos

8-3421

MidWestTech | Case 1825 Uni Loader Parts Catalog | Publication 8-3421

Order the manual at mid-west-tech.com >

GENERAL INFORMATION

Indexes

The Alphabetical Index at the front of the catalog gives page number location of major parts and systems. The Pictorial Index identifies 9 major sections of tractor systems in consecutive order as they appear in the catalog, with page number references per section. The Section Index at the front of each section (marked with a black number tab) lists parts or systems covered in that section in alphabetical order. The Numerical Index at the rear of the catalog gives part numbers in alpha/numerical order and the page on which they are listed.

Orders

Orders should specify correct part number, full description, quantity required, machine and engine model, machine and engine serial numbers, method of shipment and shipping address.

Changes

When changes are made to the machine, revised pages for this catalog will be issued. These pages must be inserted into your catalog as soon as they are received. Failure to keep your catalog up to date will result in confusion and may cause you to order wrong parts.

Abbreviations and Terms

PIN - Product Identification Number.
SN - Serial Number.
NSS - Not sold separately.
REF - Reference. Used to clarify drawing.
RESERVED - No item listed.
UAR - Use as required.

Right-Hand and Left-Hand Sides

The terms right-hand and left-hand as used in this catalog are identified by the operator standing at the rear of the basic unit (without rear attachment), looking toward the front of the machine (normal forward travel). For pages covering any machine attachments, the terms right-hand and left-hand are defined by the operator sitting in the normal operating position for proper operation of the attachment.

U.S. and Metric Units

Lengths and dimensions are given in U.S. units followed by their equivalent in metric units. See item 8 below. Hardware sizes are given in inches for U.S. hardware or in millimeters for metric hardware. See items 9 and 10 below.

Text Format Explanation

All parts are briefly described under DESCRIPTION. The quantity used is listed under REQ'D. Notice in the example below that the description of some items is moved in (indented) from the left-hand margin. An indented item is part of the assembly under which it is indented. The example below shows that one hydraulic oil filter is used on the machine. Each filter contains one head assembly, one element kit, and one housing (items indented one indent space). The head assembly and kit have further indented items under them to show individual parts (items 2 and 3, and 4 and 5).

Machinery items must be ordered from the Machinery Price List. See item 7 in the example.

REF.	PART NO.	DESCRIPTION	REQ'D.
1	D 43567	FILTER ASSEMBLY - hydraulic oil, PIN 7534840 and after	1
	D 61903	HEAD ASSEMBLY - filter	1
2	NSS	HEAD - filter, order D61903 head assembly	1
3	D 58199	BYPASS VALVE - filter	1
	D 43800	KIT - filter element (replaces D35700 kit)	1
4	NSS	ELEMENT - filter, order D43800 element kit	1
5	A 27994	O-RING - filter	1
6	D 42439	HOUSING - filter	1
7	REF	CANOPY - ROPS, machinery item, see page 2 for ordering	1
8	R 42849	HOSE - 38" (965 mm) long, upper valve port	1
9	113- 323	BOLT - hex head, 7/16" - 14 NC x 1-3/4", plated	2
10	814- 8030	BOLT - hex head, 8 mm - 1.25 x 30 mm (8.8), plated	2

861622 A

MidWestTech | Case 1825 Uni Loader Parts Catalog | Publication 8-3421 Order the manual at mid-west-tech.com >