580K Construction King Loader Backhoe

Parts Catalog

Bur. 8-3462

CASE

MidWestTech | Case 580K Construction King Loader Backhoe Parts Catalog | Publication 8-3462

Order the manual at mid-west-tech.com >

PICTORIAL SECTION INDEX



GENERAL 1



ENGINE 2



FUEL 3



ELECTRICAL 4



STEERING/ TRACK 5



POWER TRAIN 6



BRAKES 7



HYDRAULICS 8



CHASSIS/ MOUNTED EQUIPMENT 9

NUMERICAL INDEX 10

B890757

Bur 8-3462 Issued February, 1989 Printed in U.S.A.

MidWestTech | Case 580K Construction King Loader Backhoe Parts Catalog | Publication 8... Order the manual at mid-west-tech.com >

GENERAL INFORMATION

Indexes

Section 1 of this catalog contains a SN and P.I.N. location guide, alphabetical index, pictorial index of the sections included, and pictorial index(es) for quick location of hoses and tubes (and other system components in some catalogs). An alphabetical index also appears at the beginning of each section. Section 10 is the Numerical Index which lists all part numbers in alpha/numeric order with their page location and reference number.

Illustration and Text

The arrangement of this parts catalog is for easy identification of parts. All parts are illustrated in "exploded views" in proper relation to each other. Reference numbers used in the illustrations refer to those on the text pages. The text pages list reference number, part number, part description and the quantity required.

Abbreviations

P.I.N. "Product Identification Number"
SN "Serial Number"
NSS "Not Serviced Separately" in the part number column indicates this part is not available for service.
REF "Reference" in the part number column indicates this part has special service information. The page where this information can be found is given in the part description column.
UAR "Use As Required" in the quantity required column indicates the number of parts used is determined by service needs.

Right-Hand and Left-Hand Identification

The reference to right-hand and left-hand in this catalog is identified by the operator standing at the rear of the basic unit (without rear attachment), looking toward the front of the machine (in normal forward travel). For pages covering any machine attachments, right-hand and left-hand are defined by the operator sitting in the position for proper operation of the attachment.

Catalog Revisions and Supplements

Changes to the product may make it necessary to revise or add pages to this catalog. A cover sheet will list all pages released in a revision or supplement. Each new or revised page will have a new issue date. All revised and new pages must be put into the parts catalog as soon as they are received.

Parts Orders

Orders must specify product model, all necessary serial numbers, correct part number, complete description, quantity required, method of shipment, and shipping address.

Text Format Explanation

An assembly may contain many service items. The component parts of an assembly or subassembly are indented. The quantity required column lists the number of assemblies required for a complete machine, and the number of components required in a complete assembly or subassembly.

The example below illustrates the use of indents and other text page elements explained on this page.

REF.	PART NO.	DESCRIPTION	REQ'D.
1	D43567	FILTER ASSEMBLY - hydraulic oil, PIN 7534840 and after	1
	D61903	HEAD ASSEMBLY - filter	1
2	NSS	HEAD - filter, order D61903 head assembly	1
3	D58199	VALVE - bypass	1
	D43800	KIT - filter element, replaces D35700 kit	1
4	NSS	ELEMENT - filter, order D43800 element kit	1
5	A27994	O-RING - filter	1
6	D61948	HOUSING - filter	1
7	REF	CANOPY - ROPS, machinery item, order from Machinery Price List	1
8	843065C1	HOSE - 132 inch (3353 mm) long, reservoir to pump	1
9	113-323	BOLT - hex head, 7/16 - 14 NC x 1-3/4 inch, plated	2
10	814-8030	BOLT - hex head, 8 mm - 1.25 x 30 mm (8.8), plated	4

MidWestTech | Case 580K Construction King Loader Backhoe Parts Catalog | Publication 8... Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Air Cleaner ..... 2-15 - 2-21
Air Conditioner
  Blower 9-615
  Compressor 4-95
  Compressor Mounting 4-99
  Condenser 9-623
  Controls 9-605
  Evaporator 9-621
  Filter - air 9-613
  Receiver-Drier 9-625
Alarm - warning 4-141
Alarm - backup 4-139
Alternator - electrical 4-93
Alternator Mounting 4-97
Antirollback - loader 9-447
Armrests - seat 9-585
Axle
  Front - four wheel drive ..... 6-217 - 6-229
  Front - two wheel drive 5-171,5,173
  Rear 6-245
Axle Mounting - front four wheel drive 6-213

B

Backhoe
  Boom 9-489
  Boom Latch 9-493,9-495
  Bucket Links - attachments 9-499,9-503
  Buckets ..... 9-517 - 9-527
  Controls (See Controls)
  Control Tower 9-459,9-461
  Coupler - bucket ..... 9-497 - 9-515
  Dipper 9-497,9-501
  Extendable Dipper 9-505,9-509,9-513
  Frame and Mounting Parts 9-481,9-483
  Frost Point 9-499,9-503
  Hydraulics (See Hydraulic Systems)
  Stabilizers 9-481
  Swing Tower 9-485
Backup Alarm 4-139
Battery 4-107,4-109
Beacon - rotating ..... 4-143 - 4-147
Belts - fan, alternator, and
  compressor 2-13,4-97,4-99
Belts - seat 9-571
Boom Latch 9-493,9-495
Box - operators tool 9-631
Brake Master Cylinder 7-267
Brake System ..... 7-255 - 7-269
Buckets - backhoe ..... 9-517 - 9-527

B

Buckets - loader 9-455,9-457

C

Cab
  Air Conditioner ..... 9-621 - 9-625
  Air Filter 9-613
  Blower 9-615
  Consoles - control 9-591
  Covers - interior 9-589
  Doors and Windows/Glass ..... 9-593 - 9-603
  Electrical and
    Lighting 4-127,4-131,4-135,9-605
  Frame and Roof Cap 9-589
  Headliner, Louvers, and Dome Lamps 9-611
  Heater 9-617,9-619
  Mounting Parts 9-587
  Panel - cab control 9-605
  Windshield Wipers 9-607,9-609
Canopy - ROPS 9-627
Chassis - tractor 9-543
Cluster - electronic instrument 4-115
Cluster - instrument 4-121
Clutch Cutout - power shuttle 4-123
Cold Start System 2-25,4-109
Column - steering 5-155,5-157,5-161,5-163
Compressor - air conditioner 4-95
Compressor Mounting 4-99
Concrete Breaker Fork 9-529
Control Center - instrument, electronic 4-115
Controls
  Antirollback - loader 9-447
  Backhoe ..... 9-463 - 9-477
  Brake 7-263,7-269
  Boom Latch 9-493,9-495
  Clutch Cutout 4-123
  Engine Speed - throttle 3-75,3-77
  Extendable Dipper 9-471,9-477
  Front Axle Drive - 4WD 6-211
  Hitch - three-point 9-531
  Loader - lift, bucket, and clam 9-443,9-445
  Power Shuttle 6-199,6-203
  Return-to-Dig - loader 9-449
  Steering 5-151,5-155
  Swing Sequence Valve - backhoe 9-479
  Transmission Shift 6-251
Control Tower - backhoe 9-459,9-461
Converter - torque 6-181
Cooling Systems
  Engine 2-13

Bur 8-3462 Issued February, 1989 Printed in U.S.A.

MidWestTech | Case 580K Construction King Loader Backhoe Parts Catalog | Publication 8... Order the manual at mid-west-tech.com >