265
Tractor

Parts Catalog

8-3940

CASE IH AGRICULTURE

MidWestTech | Case 265 Tractor Parts Catalog | Publication 8-3940

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Adapters, Hydraulic Coupling 8-35
Air Cleaner 2-7
Alternator Assembly 4-15
Alternator Mounting 4-11
Arm, Lift 9-3
Auxiliary Electric Outlet 4-9
Auxiliary Outlet Harness 4-9
Auxiliary Valve Kit 8-35
Axle, Front, Adjustable 5-13,15
Axle, Rear 6-31,33

B

Battery 4-3
Battery Cables 4-3
Bearing, Engine Main 2-21
Belt, Fan 2-5
Belt, Seat 9-31
Block, Cylinder 2-21
Brake Pedals 7-5
Brakes 7-3

C

Cable, Battery 4-3
Camshaft, Engine 2-19
Cap, Main Bearing 2-21
Cluster, Instrument 4-7
Clutch, Engine 6-3
Clutch Housing 6-5
Connecting Rod 2-23
Connecting Rod Bearing 2-23
Controls, Mid Hydraulic Lift 8-41
Controls, PTO 6-47
Coolant Temperature Indicator 2-5
Counter and Selector Gears, Lower 6-25
Counter and Selector Gears, Upper 6-19,21,23
Coupling, Hydraulic 8-35
Cover, Cylinder Head 2-17
Crankshaft, Engine 2-23
Cylinder Block, Engine 2-21
Cylinder Block Gasket Kit 2-29
Cylinder Block Heater 2-9
Cylinder Head, Engine 2-17

D

Decals, Identification 9-25
Decals, Instruction 9-27
Decals, Safety 9-29
Differential Assembly 6-27
Differential Housing 6-5
Differential Lock 6-29
Dipstick, Engine Oil 2-21
Dipstick, Transmission Oil 6-5

D

Drawbar 9-11
Drive, Fuel Injection Pump 2-19

E

Electric Outlet, Auxiliary 4-9
Electrical Harness, Auxiliary Outlet 4-9
Electrical Harnesses 4-3
Engine Cylinder Block 2-21
Engine Block Heater 2-9
Engine Clutch 6-3
Engine Crankshaft 2-23
Engine Cylinder Head 2-17
Exhaust System, Horizontal 2-15
Exhaust System, Vertical 2-13

F

Fan, Engine 2-5
Fan, Belt 2-5
Fenders 9-19
Filter, Engine Fuel 3-7
Filter, Engine Oil 2-25
Final Drive Housing 6-5
Flasher Lamp 4-3
Flood Lamp, Rear 4-17
Front End Weights 9-13
Flywheel, Engine 2-23
Foot Inching Pedal 6-11,13
Frame, Front, Adjustable Axle 5-13
Front Wheel 5-19
Fuel Filter 3-7
Fuel Injection Pump 3-3
Fuel Injection Pump Drive 2-19
Fuel Injection System 3-9
Fuel Injector 3-11
Fuel Shut Off, Engine 3-13
Fuel Tank and Supports 3-15
Fuel Tank Cover 9-17
Fuel Tank Level Sender 3-15
Fuses 4-7
Fuse Holder 4-7

G

Gasket Kits, Engine 2-29
Gasket Kits, Valve Grind 2-29
Gear Bevel 6-27
Gear Box Assembly, Manual Steering 5-5
Gear Box Assembly, Power Steering 5-11
Gear Cover, Front 2-27
Gear, Pinion 6-27
Gear Shift Linkage 6-7,9
Glow Plug 4-11
Governor Controls 3-5

Rac 8-3940 Issued December, 1987 Printed in U.S.A.

MidWestTech | Case 265 Tractor Parts Catalog | Publication 8-3940 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

G

Grille, Front....9-17
Guide, Engine Valve....2-17

H

Harness, Auxiliary Outlet....4-9
Harnesses, Electrical....4-3
Head Lamp....4-3
Heater, Cylinder Block....2-9
Hitch, Load Arms....9-9
Hitch, Load Control Linkage....8-27,33
Hitch Housing....9-3
Hitch Lift Arms....9-3
Hitch Rockshaft....9-3
Hitch System, Piston....9-5
Hitch System, Position and Load Control Levers....8-31,33
Hitch System, Position Control Levers without Load Control....8-27,29
Hitch, Three Point....9-7,9
Holder, Fuse....4-7
Hood....9-15
Hood Latch....9-15
Hood Supports....9-15
Housing Clutch....6-5
Housing, Differential....6-5
Housing, Rear Axle....6-5
Hub, Front Wheel, Adjustable Axle....5-13
Hydraulic Cover Assembly....8-25
Hydraulic Control Valve....8-23
Hydraulic Control Valve Mounting....8-21
Hydraulic Lift, Mid....8-37,39
Hydraulic Lift, Mid Controls....8-41
Hydraulic Lift, Mid Cylinder....8-43
Hydraulic Lift, Mid Valve....8-45
Hydraulic Lines, Pump....8-3,11
Hydraulic Oil Filter....8-3,5,9
Hydraulic Pump Assembly, Auxiliary....8-19
Hydraulic Pump Assembly, Main....8-17

I

Idler Shaft....6-19
Inching Pedal....6-11,13
Injection Pump, Fuel....3-3
Injection System, Engine Fuel....3-9
Instrument Cluster....4-7
Instrument Panel Shroud....9-17

K

Key, Starting....4-7

L

Lamp, Flasher Warning....4-3
Lamp, Head....4-3
Lamp, Instrument Cluster....4-7
Lamp, Tail....4-3
Lamp, Work Rear....4-17
Lamp, Working Bottom....4-5
Latch, Hood....9-15
Light Switch....4-7
Linkage, Load Control....8-31,33
Linkage, Range Shift....6-7,9
Load Control Linkage....8-31,33
Lower Link....9-9

M

Main Shaft....6-19,21
Manifold, Exhaust....2-11
Manifold, Intake....2-11
Master Brakes....7-3
Mid PTO....6-51
Controls....6-53
Muffler, Horizontal....2-15
Muffler, Vertical....2-13

N

Nozzle, Fuel Injector....3-11

O

Oil Filter, Engine....2-25
Oil Pan, Engine....2-27
Oil Pump, Engine....2-25
Oil Filter, Hydraulic....8-3,5,9

P

Pan, Engine Oil....2-27
Park Lock Control....7-7
Pedals, Brake....7-5
Piston, Engine....2-23
Piston, Hitch System....9-5
Plug, Glow....4-11
Position Control Levers, with Load Control....8-31,33
Position Control Levers, without Load Control....8-27,29
Power Steering Valve....5-9
PTO Clutch....6-49
PTO Gears and Shafts....6-49
PTO, Center Rear....6-55
PTO - Shield....6-49
Pulley, Fan Drive....2-5
Pulley, Fan Drive, Crankshaft....2-23
Pump, Engine Oil....2-25
Pump, Hydraulic Auxiliary....8-19
Pump, Hydraulic, Main....8-17

Rac 8-3940 Issued December, 1987 Printed in U.S.A.

MidWestTech | Case 265 Tractor Parts Catalog | Publication 8-3940 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

P

Pump, Water 2-5
Push Rod, Engine 2-19

R

Radiator and Attaching Parts 2-3
Range Gears 6-15,17
Range Shift Linkage 6-7,9
Rocker Arm, Engine 2-19
Rockshaft, Hitch 9-3
Rod, Connecting 2-23
Rod, Push 2-19
ROPS Frame 9-31

S

Seat 9-21
Seat Belt 9-31
Seat Supports 9-21
Sender, Fuel Tank Level 3-15
Shroud, Fan 2-3
Shroud, Instrument Panel 9-17
Shut Off, Engine 4-7
Shut Off, Fuel 3-13
Slow Moving Vehicle Emblem 9-23
Spindle, Front Wheel, Adjustable Axle 5-13
Starter Assembly 4-13
Starter Mounting 4-11
Starting Key 4-7
Starting Switch 4-7
Steering Column, Manual Steering 5-3
Steering Column, Power Steering 5-7
Steering Gear, Manual Steering 5-3
Steering Gear, Power Steering 5-7
Steering Linkage, Adjustable Axle 5-17
Steering, Tie Rod, Adjustable Axle 5-17
Steering Wheel, Manual Steering 5-3
Steering Wheel, Power Steering 5-7
Step and Supports 9-19
Sunshade 9-35
Switch, Light 4-7
Switch, Neutral Start 4-5
Switch, Starting 4-7

T

Tachometer 4-7
Tail Lamp 4-3
Tank, Fuel 3-15
Thermostat, Engine Temperature 2-5
Throttle Control 3-13
Tie Rod, Steering, Adjustable Axle 5-17
Timing Gear Cover 2-27
Tool Box 9-33
Transmission Housing 6-5

U

Upper Link Bracket 8-33

V

Valve, Exhaust 2-19
Valve Grind Gasket Kit 2-29
Valve, Hydraulic Control 8-23
Valve, Intake 2-19
Valve Mechanism 2-19
Valve, Power Steering 5-9

W

Water Pump 2-5
Weight, Front End 9-13
Weights, Rear Wheel 6-43,45
Wheel, Front 5-19
Wheel, Rear, One Piece 6-35
Wheel, Rear, Two Piece
Rim and Disc 6-37,39,41
Wheel, Spindle, Front, Adjustable Axle 5-13
Wheel, Steering, Manual Steering 5-3
Wheel, Steering, Power Steering 5-7
Wheel Weights 6-43,45
Work Lamp, Rear 4-17
Working Lamp, Bottom 4-5

Rac 8-3940 Issued December, 1987 Printed in U.S.A.

MidWestTech | Case 265 Tractor Parts Catalog | Publication 8-3940 Order the manual at mid-west-tech.com >