Farmall 31, Farmall 35 Tractors

Repair Manual

47924636

10/08
1st Printing

CASE IH AGRICULTURE

MidWestTech | Case Farmall 31, 35 Tractor Service Manual | Publication 84132127

Order the manual at mid-west-tech.com >

FARMALL 31, FARMALL 35 REPAIR MANUAL COMPLETE CONTENTS

SECTION 00 - GENERAL INFORMATION 2

SECTION 10 - ENGINE 3

SECTION 18 - CLUTCH 11

SECTION 21 - GEAR TRANSMISSION 12

SECTION 25 - FWD FRONT AXLE 15

SECTION 27 - DIFFERENTIAL, REAR AXLE 17

SECTION 29 - HYDROSTATIC TRANSMISSION 18

SECTION 31 - POWER TAKE-OFF SYSTEMS 22

SECTION 33 - BRAKES 24

SECTION 35 - HYDRAULIC SYSTEM 24

SECTION 41 - STEERING SYSTEMS 28

SECTION 44 - WHEELS AND TIRES 30

SECTION 55 - ELECTRICAL SYSTEM 31

SECTION 90 - PLATFORM 39

The following pages are the collation of the contents pages from each section and chapter of the Farmall 31, Farmall 35 Repair manual. Complete Repair part # 84132127.

The sections used through out all Case IH product Repair manuals may not be used for each product. Each Repair manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Repair manual and which sections are in each book.

The sections listed above are the sections utilized for the Farmall 31, Farmall 35 Tractors.

© 2008 CNH America LLC
Printed In U.S.A.

84132131 10/08
1st Printing

MidWestTech | Case Farmall 31, 35 Tractor Service Manual | Publication 84132127 Order the manual at mid-west-tech.com >

SECTION 00 - GENERAL INFORMATION

BOOK 1 - 84132128

Chapter 1 - General Information

CONTENTS

Section	Description	Page
	Precautionary Statements	2
	Personal Safety	2
	Machine Safety	2
	Information	2
	Safety	3
	Precautionary Statements	3
	The Tractor	3
	Servicing the Tractor	3
	Operating the Tractor	4
	Driving the Tractor	4
	Operating the PTO	5
	Diesel Fuel	5
	Safety Frame (ROPS)	5
	Decals	6
	Safety Decals	6
	Instruction Decals	8
	Ecology and the Environment	12
	Helpful Hints	12
	International Symbols	13
	Specifications	14
	General Dimensions	20
	Minimum Hardware Tightening Torques	23
	Lubrication and Maintenance	25
	Lubrication	25
	Liquid Ballast (Optional)	27
	Tire Pressure	27
	Rear Tire Liquid	27

MidWestTech | Case Farmall 31, 35 Tractor Service Manual | Publication 84132127 Order the manual at mid-west-tech.com >

SECTION 10 - ENGINE

BOOK 1 - 84132128

Chapter 1 - Engine Systems

CONTENTS

Section	Description	Page
	Specifications	6
	Cooling System All Models	13
	Engine Bolt Torque Specifications	14
	Engine Fuel System Bolt Torque Specifications	14
	Metric Bolt Torque Specifications	15
	Special Tools	16
	Compression Test and Tools	16
	Description of Operation - General Information	17
	Cylinder Head and Valve Train Components	18
	Cylinder Block Assembly	18
	Troubleshooting	20
	Overhaul	24
	Engine	24
	Preparation	24
	Fuel Injector and Glow Plug	25
	Removal	25
	Oil Pressure Switch	26
	Removal	26
	Temperature Sending Switch and Alternator	26
	Removal	26
	Fan, Water Pump and External Oil Tube	26
	Removal	26
	Head Cover	27
	Removal	27
	Rocker Arm Shaft and Support Bracket	27
	Removal	27
	Cylinder Head	28
	Removal	28
	Valve Tappet	28
	Removal	28
	Fuel Shutoff Solenoid	28
	Removal	28

MidWestTech | Case Farmall 31, 35 Tractor Service Manual | Publication 84132127 Order the manual at mid-west-tech.com >