L720, L730 Loaders

Operator's Manual

84157387 9/08
Replaces 87753759

CASE IH AGRICULTURE

MidWestTech | Case L720, L730 Loader Operator's Manual | Publication 84157387

Order the manual at mid-west-tech.com >

CONTENTS

SAFETY 0-7

GENERAL INFORMATION 1-1

OPERATION 2-1

LUBRICATION AND MAINTENANCE 3-1

TROUBLESHOOTING 4-1

OPTIONAL EQUIPMENT 5-1

SPECIFICATIONS 6-1

INDEX 6-11


PREDELIVERY REPORT 6-13

MidWestTech | Case L720, L730 Loader Operator's Manual | Publication 84157387 Order the manual at mid-west-tech.com >

3rd Hydraulic Function

The third hydraulic function is controlled by a switch or switches on the front of the control lever, 1.

On tractor with loader control valve, press the loader third hydraulic function button (A) and move the hydraulic control lever to the right to open the grapple, on units equipped with electric diverter valve system. On Live 3rd units press and hold the top button to open the grapple. Consult with your dealer as to the style of system on your tractor/loader.




12

Loader with Mechanical Self-Leveling

Parallel links keep the base of the attachment in the same angular position during the entire lift/lowering movement.

Loader without Self-Leveling

The base of attachment changes its angle in relation to the ground during the entire lift/lowering movement.




13

INSTALLING THE LOADER

NOTE: *The accessory box markings coincide with the loader and the base. The decal installed on the accessory sack for the base contains information about the number of packages and the part numbers of the components, in addition to information about the tractor model. Check that these coincide.*

Read through the installation instructions which accompany each kit before making any attempt at installation.



14

⚠ CAUTION ⚠

Pinch risk.

The locking wheel is spring loaded. Handle carefully.

Install Quick Lock on the left and right bearing boxes. Install stop (A) on the left and right subframes.

Install the subframe set and connect the loader valve or hose kit to the tractor's hydraulics in accordance with the installation instructions.

MidWestTech | Case L720, L730 Loader Operator's Manual | Publication 84157387 Order the manual at mid-west-tech.com >

SECTION 3
LUBRICATION AND MAINTENANCE


LUBRICATION POINTS

Lubricate the following grease fittings (zerks) using multi-purpose lithium-based grease, every ten (10) hours of loader operation.

⚠ WARNING ⚠

To prevent personal injury or death due to loader falling, support loader with a solid support when loader is raised for access to bucket pivot pin grease zerks.

Grease zerks at each pivot pin and links on both sides of the loader.



1

STORAGE

Store hoses, on main frame so coupler(s) are off the ground.

Apply a thin layer of grease to exposed cylinder rods as protection.

HYDRAULIC SYSTEM

Frequently check the oil level in the tractor hydraulic oil reservoir when the loader is lowered to the ground. Use oil specified in the tractor operators manual.

MidWestTech | Case L720, L730 Loader Operator's Manual | Publication 84157387 Order the manual at mid-west-tech.com >

SECTION 6
SPECIFICATIONS

LOADER SPECIFICATION

The following specifications are intended to be used as a general guide. Due to variations in tractor models, tire size, and hydraulic system, these specifications apply only to the tractor specified in each example.

Other tractor models and/or tractor variations may have different values. Specifications are to current ASAE Standard S301 .3.

The technical data may vary, depending on the tractor model and implement.

Loader Model	**L720 (NSL)**	**L720 (MSL)**	**L720 (NSL)**	**L720 (MSL)**
Tractor Model Series	**JXC 60-75**	**JXC 60-75**	**JX 55-70**	**JX 55-70**
Hydraulic Pressure	2850 psi (196 bar)	2850 psi (196 bar)	2850 psi (196 bar)	2850 psi (196 bar)
Hydraulic Flow	15 gpm 56.8 l/m	15 gpm 56.8 l/m	15 gpm 56.8 l/m	15 gpm 56.8 l/m
Front Tires	10 x 16 (2WD) 320/70 x R24 (FWD)	10 x 16 (2WD) 320/70 x R24 (FWD)	10 x 16 (2WD) 11.2 x R24 (FWD)	10 x 16 (2WD) 11.2 x R24 (FWD)
Rear Tires	480/70 x R28	480/70 x R28	12.4 x R36	12.4 x R36
Wheelbase (WB)	93 in (2362 mm)	93 in (2362 mm)	83 in (2120 mm)	83 in (2120 mm)
Lifting Capacity and Breakout Force at 2730 psi (188 bar) at pivot pin (lb / kg)				
Max. lifting height (lb / kg)	3300 / 1497	3200 / 1451	3300 / 1497	3200 / 1451
59 in / 1.5m lift height (lb / kg)	3750 / 1700	3650 / 1655	3750 / 1700	3650 / 1655
Ground line (breakout force) (lb / kg)	4200 / 1905	3850 / 1746	4200 / 1905	3850 / 1746
Lifting Capacity and Breakout Force at 2730 psi (188 bar) at 31.5in / 800 mm forward of pivot pin (lb / kg)				
Max. lifting height (lb / kg)	2100 / 953	2500 / 1134	2100 / 953	2500 / 1134
59 in / 1.5m lift height (lb / kg)	2400 / 1089	2950 / 1338	2400 / 1089	2950 / 1338
Ground line (breakout force) (lb / kg)	2650 / 1202	3200 / 1451	2650 / 1202	3200 / 1451

NOTE: *NSL – Non Self Leveling*
MSL – Mechanical Self Leveling

MidWestTech | Case L720, L730 Loader Operator's Manual | Publication 84157387 Order the manual at mid-west-tech.com >