CASE
CONSTRUCTION

OPERATOR'S MANUAL

ARTICULATED TRUCKS

335B
340B
TIER 3

MULTIPLEX
SIMPLEMUX

84158224 NA

Issued 01Oct 08

MidWestTech | Case 335B, 340B Tier 3 Multiplex, Simplemux Articulated Truck Operator's... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - TO THE OWNER/SAFETY 1-1

335b And 340b Articulated Trucks 1-1
Legal Documents 1-2
Keys And Documents Provided 1-2
Chassis Validity 1-3
Conformity Marking 1-5
Vibration Levels Transmitted To The Operator 1-5
Right, Left, Front And Rear Of The Vehicle 1-6
Type, Serial Number And Year Of Manufacture 1-7
Component Serial Numbers 1-7
Position Of Identification Data On Main Component Groups 1-9
Identification Of The Main Components Of The Vehicle 1-12
Safety Rules 1-15
Prevention Of Fires 1-16
Overturning Accidents 1-16
Instructions For Use 1-17
Maintenance Instructions 1-20
Decals And Plates 1-23
Hand Signals 1-35

SECTION 2 - CONTROLS/INSTRUMENTS/ACCESSORIES 2-1

Accessing The Cab 2-1
Door 2-2
Location Of Controls, Instruments And Accessories - Type A 2-4
Location Of Controls, Instruments And Accessories - Type B 2-6
Driver's Seat (Electro-pneumatic) 2-12
Folding Seat 2-13
Seat Belts 2-13
Accessory Functions 2-14

SECTION 3 - OPERATING INSTRUCTIONS 3-1

Before Operating The Vehicle 3-1
Operating The Vehicle 3-1
Run-in Period 3-2
Filling The Fuel Tank 3-3
Starting And Stopping The Engine 3-4
Multifunctional Display - Type A 3-13
Multifunctional Display - Type B 3-48
Starting The Vehicle 3-82

MidWestTech | Case 335B, 340B Tier 3 Multiplex, Simplemux Articulated Truck Operator's... Order the manual at mid-west-tech.com >

Stopping And Parking The Vehicle 3-83
Driving The Vehicle 3-85
Using The Automatic Transmission 3-86
Using The Integrated Auxiliary Brake Control 3-90
Using The Differential Lock 3-91
Working With The Vehicle 3-92
Dumping The Body 3-96
Emergency Stopping 3-100
Emergency Steering 3-101
Replacing A Complete Wheel 3-102
Climate Control System Operation 3-106
Overturning Accidents 3-108
In The Event Of Overturning 3-109
Rescuing The Vehicle 3-110
Towing The Vehicle 3-110
Transporting The Vehicle 3-114
SECTION 4 - SERVICING INTERVALS/LUBRICATION/FLUIDS 4-1
Servicing Instructions 4-1
Location Of Main Components Used For Maintenance 4-4
Preliminary Operations 4-9
Scheduled Maintenance Program In Hours 4-20
Lubrication And Scheduled Replacement Chart 4-22
Daily Operations 4-24
Engine 4-27
Adjustment Of Engine Valve Rocker Clearances 4-32
Fuel Supply System 4-32
Air Intake System 4-35
Exhaust System 4-39
Cooling System 4-40
Automatic Transmission 4-44
Drive Line Shaft Support 4-48
Front Differential 4-49
Front And Rear Hubs 4-50
Rear Tandem Axles 4-51
Hydraulic System 4-55
Brake Cooling Circuit (For Wet Brakes Models Only) 4-62
Hood Opening System 4-66

MidWestTech | Case 335B, 340B Tier 3 Multiplex, Simplemux Articulated Truck Operator's... Order the manual at mid-west-tech.com >

Cab Tipping System 4-66
Greasing 4-67
SECTION 5 - MAINTENANCE/ADJUSTMENTS 5-1
Suspension 5-1
Braking Circuit 5-6
Steering Circuit 5-7
Tires And Wheels 5-8
Air Conditioning System 5-12
Compressed Air System 5-14
Bodywork 5-15
SECTION 6 - ELECTRICAL SYSTEM 6-1
Electrical Power 6-1
Battery Maintenance (Not Sealed) 6-7
Interconnection Control Unit 6-11
Relays And Fuses - Type A 6-12
Relays And Fuses - Type B 6-17
Lighting System 6-23
SECTION 7 - STORAGE 7-1
Storing The Vehicle 7-1
SECTION 8 - SPECIFICATIONS 8-1
Main Groups 8-1
Dimensions 8-2
Weights 8-4
Center Of Gravity (Horizontal Position) 8-5
Performance 8-6
Main Group Characteristics 8-8
Tightening Torque 8-13
Capacities 8-14
Lubricants, Fluids And Consumable Materials 8-15
Fluid Level Table 8-16
SECTION 9 - ALPHABETICAL INDEX 9-1

MidWestTech | Case 335B, 340B Tier 3 Multiplex, Simplemux Articulated Truck Operator's... Order the manual at mid-west-tech.com >