W14,W14H,W14FL
Loaders

PIN 9119672 AND AFTER

Service Manual

8-41980

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

RUN-IN INSTRUCTIONS 4

ENGINE SPECIFICATION DETAILS

Cylinder Sleeves 5

Piston with 1.62" (41.15 mm) Pin Bore 5

Piston with 1.80" (45.72 mm) Pin Bore 5

Piston Pin for Piston with 1.62" (41.15 mm) Pin Bore 5

Piston Pin for Piston with 1.80" (45.72 mm) Pin Bore 5

Piston Rings 6

Connecting Rod For Piston with 1.62" (41.15 mm) Pin Bore 6

Connecting Rod For Piston with 1.80" (45.72 mm) Pin Bore 6

Crankshaft with 3" (76.2 mm) Main Bearing Journals 7

Crankshaft with 3.5 " (88.9 mm) Main Bearing Journals 7

Camshaft 8

Valve Push Rod Lifters 8

Gear Train 9

Oil Pump and Two Gear Balancer 9

Oil Pump and Three Gear Balancer 9

Oil Pump, Front Mount 10

Cylinder Head 11

Exhaust Valve 11

Intake Valve 11

Intake and Exhaust Valve Guides 12

Valve Spring 12

Rocker Arm Assembly 12

Intake Valve Timing 12


SPECIAL TORQUES 13-14

GENERAL TORQUE SPECIFICATION TABLE 15

MidWestTech | Case W14, W14H, W14FL Loader Service Manual | Publication 8-41980 Order the manual at mid-west-tech.com >

CYLINDER HEAD ASSEMBLY AND INSTALLATION

STEP 61



Apply lubrication to the valves using clean engine oil and install the valves in the cylinder head.

STEP 62



Install the valve spring seat (flat side down).

STEP 63



Install the valve spring. Either end of the valve spring can be installed in the valve spring seat because both ends of the spring are closed and ground.

NOTE: *See specification details section in the Service Manual for spring specifications.*


STEP 64



Install the valve rotators (flat side up). Install the valve rotators with the original valves because these parts are worn as counterparts of each other.


IMPORTANT: *Always install new rotators and valve keepers when new valves are installed.*

STEP 65



Push down the valve springs with a spring compressor. Install a new valve seal in the lower valve stem groove.

STEP 66



Install the valve keepers in the upper valve stem groove.

Order the manual at mid-west-tech.com >