

NEW HOLLAND

H6730
H6740
H6750

SERVICE MANUAL

84207377 4/09
1st Printing

MidWestTech | New Holland H6730, H6740, H6750 Disc Mower Service Manual | Publication 84207377

Order the manual at mid-west-tech.com >

SECTION 00 - GENERAL INFORMATION

Chapter 1 - General Information

CONTENTS

Section	Description	Page
	Precautionary Statements	2
	General Information	3
	Before Using the New Machine	3
	After 8 Hours of Operation	3
	Tractor Requirements	4
	Attaching the Mower to the Tractor	5
	Model H6730	5
	Attaching the Mower to the Tractor	9
	Model H6740 and H6750	9
	Lowering the Cutter Bar for Field Operation	15
	Transporting the Mower	16
	Removing the Mower from the Tractor	16
	Storing the Mower	18
	Specifications	19

MidWestTech | New Holland H6730, H6740, H6750 Disc Mower Service Manual | Publicati... Order the manual at mid-west-tech.com >

SECTION 00 - GENERAL INFORMATION

Chapter 2 - Adjustments

CONTENTS

Section	Description	Page
	Opening Fields	2
	Field Cutting	2
	Operating Recommendations	4
	Cutter Bar Flotation	5
	Cutting Height	8
	Breakaway Latch	9
	Right Swathboard (Standard)	10
	Drive Belt	10
	Drive Belt Replacement	10

MidWestTech | New Holland H6730, H6740, H6750 Disc Mower Service Manual | Publicati... Order the manual at mid-west-tech.com >

SECTION 00 - GENERAL INFORMATION

Chapter 3 - Lubrication


CONTENTS

Section	Description	Page
	Bevel Gearbox	2
	Grease Fittings	2
	Gearboxes	2
	Bevel Gearbox Breather	3
	Drive Module	3
	Drive Module Breather	3
	Cutter Bar Modules	4
	Grease Fittings	5

MidWestTech | New Holland H6730, H6740, H6750 Disc Mower Service Manual | Publicati... Order the manual at mid-west-tech.com >

Lighter cutter bar weight will reduce pull on the tractor, but setting flotation too light will prevent the cutter bar from staying on the ground at faster ground speeds. The cutter bar weight may be felt by lifting on the right end of the canopy support, 1.


NOTE: *When completing adjustment, position flotation spring rod so that hole, 2, Figure 39, is slightly above horizontal as viewed from the rear before tightening the jam nut, as this will ease flotation pin installation.*



3

After adjustment, reinstall the pin, 1, which is wired to the jack stand in the flotation spring rod hole. The pin has two detent balls and is properly installed when detents are on either side of the flotation spring rod.

NOTE: *If the pin is inserted too far, the retaining ring may be knocked off and the pin may be lost, causing loss of flotation.*




4

Model H6750

Cutter bar flotation is controlled by the height of the frame off the ground and the length of the flotation spring.

Adjust the limit chains so the hitch pins, 1, are as close to, but not less than, 457 mm (18 in) as possible from the ground. This adjustment is explained in the "Attaching the Mower to the Tractor" section of this manual.

NOTE: *If the high stubble kit is installed on the mower, adjust the frame height to 508 mm (20 in) from the ground in order to provide adequate flotation.*



5

MidWestTech | New Holland H6730, H6740, H6750 Disc Mower Service Manual | Publicati... Order the manual at mid-west-tech.com >

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	CORRECTION
Vibration.	PTO shaft or U-joint damage.	Inspect and repair PTO shaft.
	Material buildup in cutter bar drums.	Remove top cover and clean out drums.
	Cutter bar components damaged or missing.	Inspect and repair components.
Cutter bar not floating.	Main frame setting incorrect.	Adjust check chains to carry main frame 450 mm (18 in) from ground and parallel.
	Cutter bar pivot points binding.	Clean and lubricate pivot points.
	Flotation system not engaged.	Install jack pin into flotation spring upper rod.
	Flotation spring adjustment.	Adjust flotation spring tension.
	High stubble kit installed.	Readjust check chains to carry main frame 508 mm (20 in) from ground and parallel.
Machine breaking back too easily.	Insufficient tension on breakaway spring.	Tighten breakaway spring until nut bottoms out.
	Ground speed too fast for crop conditions.	Reduce ground speed.
	Insufficient cutter bar flotation.	Check and adjust flotation system.
Difficulty in obtaining correct angle on cutter bar.	Lack of adjustment on top link.	Reposition top link to rear hole in main frame.
Uneven stubble/streaking.	Too much tilt on cutter bar.	Reduce tilt.
	Low PTO speed.	Run PTO at 540 RPM. (Do not over-speed)
	Excessive forward speed.	Reduce forward speed.
	Knives dull or broken.	Install new knives.
	Knives stuck under disc.	Straighten or replace knives.
	Knives installed on wrong discs.	Install knives on correct discs.
	Drive belt loose.	Tighten drive belt spring to correct length.

MidWestTech | New Holland H6730, H6740, H6750 Disc Mower Service Manual | Publicati... Order the manual at mid-west-tech.com >