NEW HOLLAND

ENGINES NEF

Tier 3

F4CE9484, F4CE9684, F4DE9484, F4DE9684, F4DE9687, F4GE9484, F4GE9684, F4HE9484, F4HE9684

SERVICE MANUAL

84250493

Issued 12-2009

NEW HOLLAND CONSTRUCTION

www.newhollandconstruction.com

MidWestTech | New Holland NEF Tier 3 F4CE9484, F4CE9684, F4DE9484, F4DE9684, F4...

Order the manual at mid-west-tech.com >

Contents

POWER PRODUCTION - B

ENGINE - 10.A

TECHNICAL DATA
ENGINE
General specification 9
F4HE9484, F4HE9684
General specification 14
F4DE9484, F4DE9684, F4DE9687
Service limits Maintenance Planning 19
F4DE9484, F4HE9484, F4DE9684, F4DE9687, F4HE9684
General specification 20
F4CE9484, F4CE9684
General specification 24
F4GE9484, F4GE9684
Service limits Maintenance Planning 28
F4CE9484, F4GE9484, F4CE9684, F4GE9684

FUNCTIONAL DATA
ENGINE
Component localisation 29
F4HE9484, F4HE9684
Component localisation 30
F4DE9484, F4DE9684, F4DE9687
Component localisation 31
F4CE9484, F4CE9684
Component localisation 32
F4GE9484, F4GE9684
Valve drive
Overview 33
F4DE9484, F4HE9484, F4DE9684, F4DE9687, F4HE9684
Connecting rod and piston
Overview 35
Wiring harness
Electrical schema 36
F4HE9484, F4HE9684
Electrical schema 38
F4DE9484, F4DE9684, F4DE9687
Electronic control
Control module - Detailed view 42
F4DE9484, F4HE9484, F4DE9684, F4DE9687, F4HE9684
Control module - Overview 43
F4DE9484, F4HE9484, F4DE9684, F4DE9687, F4HE9684
Sensing system
Crankshaft sensor - Overview 45
F4HE9484, F4HE9684

MidWestTech | New Holland NEF Tier 3 F4CE9484, F4CE9684, F4DE9484, F4DE9684, F4... Order the manual at mid-west-tech.com >

Camshaft speed sensor - Overview 46
F4HE9484, F4HE9684
Crankshaft sensor - Overview 47
F4DE9484, F4DE9684, F4DE9687
Camshaft speed sensor - Overview 48
F4DE9484, F4DE9684, F4DE9687
Crankshaft sensor - Overview 49
F4CE9484, F4CE9684

SERVICE

ENGINE

Place on stand 50
F4HE9484, F4HE9684
Place on stand 52
F4DE9484, F4DE9684, F4DE9687
Place on stand 54
F4GE9484, F4GE9684
Place on stand 56
F4CE9484, F4CE9684
Service instruction Maintenance Procedures 57
Service instruction Maintenance Procedures 62
F4DE9484, F4DE9684, F4DE9687
Service instruction Maintenance Procedures 67
F4GE9484, F4GE9684
Service instruction Maintenance Procedures 72
F4CE9484, F4CE9684

Valve drive

Rocker assembly Housing - Remove 77
Rocker assembly Housing - Install 78
Rocker assembly - Disassemble 79
F4DE9484, F4HE9484, F4DE9684, F4DE9687, F4HE9684
Rocker assembly Shaft - Clearance 80
Rocker assembly - Install 81
F4DE9484, F4HE9484, F4DE9684, F4DE9687, F4HE9684
Rocker assembly Rocker arm - Adjust 82
Camshaft Gear - Remove 83
Camshaft Gear - Remove 84
F4DE9484, F4DE9684, F4DE9687
Camshaft Gear - Install 85
Camshaft - Remove 86
Camshaft - Measure 87
Camshaft - Install 89
Camshaft - End play 90
Camshaft Push rod - Install 91
Camshaft Tappet - Remove 92
Camshaft Tappet - Measure 93
Camshaft Tappet - Measure 94
F4CE9484, F4GE9484, F4CE9684, F4GE9684
Camshaft Tappet - Install 95
Camshaft Bushing - Measure 96

MidWestTech | New Holland NEF Tier 3 F4CE9484, F4CE9684, F4DE9484, F4DE9684, F4... Order the manual at mid-west-tech.com >

Camshaft Bushing - Replace 97
Valve assembly - Remove 98
F4DE9484, F4HE9484, F4DE9684, F4DE9687, F4HE9684
Valve assembly Valve - Measure 99
Valve assembly Valve - Cleaning 100
Valve assembly Spring - Check 101
Valve assembly - Install 102
F4DE9484, F4HE9484, F4DE9684, F4DE9687, F4HE9684
Rocker assembly - Remove 103
F4CE9484, F4GE9484, F4CE9684, F4GE9684
Camshaft Gear - Remove 104
F4CE9484, F4CE9684
Camshaft Gear - Install 105
F4GE9484, F4GE9684
Camshaft Gear - Install 107
F4CE9484, F4CE9684
Rocker assembly - Check 109
F4CE9484, F4GE9484, F4CE9684, F4GE9684
Camshaft Push rod - Install 111
F4CE9484, F4GE9484, F4CE9684, F4GE9684
Rocker assembly - Install 112
F4CE9484, F4GE9484, F4CE9684, F4GE9684
Rocker assembly Rocker arm - Adjust 113
F4CE9484, F4GE9484, F4CE9684, F4GE9684
Valve assembly - Remove 114
F4CE9484, F4GE9484, F4CE9684, F4GE9684
Valve assembly Valve - Measure 115
F4CE9484, F4GE9484, F4CE9684, F4GE9684
Valve assembly Spring - Check 116
F4CE9484, F4GE9484, F4CE9684, F4GE9684
Valve assembly - Install 117
F4CE9484, F4GE9484, F4CE9684, F4GE9684

Auxiliary drive

Remove 118
F4HE9484, F4HE9684
Install 119
F4HE9484, F4HE9684
Install 120
F4CE9484, F4CE9684
Remove 121
F4GE9484, F4GE9684
Install 122
F4GE9484, F4GE9684
Remove 123
F4CE9484, F4CE9684

Crankshaft

Front seal - Remove 124
Front seal - Install 125
Rear seal - Remove 126
Rear seal - Install 127
Main bearing - Remove 128
Main bearing - Install 129

MidWestTech | New Holland NEF Tier 3 F4CE9484, F4CE9684, F4DE9484, F4DE9684, F4... Order the manual at mid-west-tech.com >