750L
Tier 3
Fire Dozer

OPERATOR'S MANUAL

Part number 84511948
1st edition English
July 2011

CASE CONSTRUCTION

MidWestTech | Case 750L Tier 3 Fire Dozer Operator's Manual | Publication 84511948 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

CHAPTER 1
GENERAL INFORMATION
TO THE OWNER 1-1
RIGHT, LEFT, FRONT, AND REAR OF THE MACHINE 1-2
IDENTIFICATION NUMBERS 1-3
MACHINE COMPONENTS 1-4

CHAPTER 2
SAFETY AND DECALS
TABLE OF CONTENTS 2-1
SAFETY AND SAFETY DECALS 2-3
SAFETY DECALS 2-11

CHAPTER 3
INSTRUMENTS AND CONTROLS
TABLE OF CONTENTS 3-1
INSTRUMENT PANEL 3-3
BRAKE, DECELERATOR AND FOOTREST 3-14
PARKING BRAKES 3-14
DIRECTION CONTROL, HYDROSTATIC DRIVE CONTROL, HAND THROTTLE 3-15

CHAPTER 4
OPERATING INSTRUCTIONS
TABLE OF CONTENTS 4-1
RUN-IN PERIOD OF A NEW MACHINE 4-3
ENGINE OPERATION 4-4
CRAWLER OPERATION 4-6
MOVING A DISABLED CRAWLER 4-13
TRANSPORTING THE MACHINE 4-16
OPERATING IN HOT WEATHER 4-18
OPERATING IN COLD WEATHER 4-18
BOOSTER BATTERY CONNECTION TO MACHINE BATTERY 4-20
TILTING THE CAB 4-21
DOZER OPERATION 4-24
TRACK SYSTEMS 4-26
FACTORS CONTROLLING UNDERCARRIAGE WEAR 4-28

CHAPTER 5
LUBRICATION, FILTERS, AND FLUIDS
TABLE OF CONTENTS 5-1
LUBRICATION, FILTERS, AND FLUIDS 5-3
SYSTEMGARD LUBRICATION ANALYSIS PROGRAM 5-4
PLASTIC AND RESIN PARTS 5-4
ENGINE HOURMETER 5-4
FLUIDS AND LUBRICANTS 5-5
LUBRICATION AND MAINTENANCE CHART 5-6
ACCESS DOORS 5-7
AS REQUIRED MAINTENANCE 5-8
TRACK MAINTENANCE 5-9
EVERY 10 HOURS 5-12
INITIAL 20 HOUR TRACK SHOE BOLT TORQUE 5-14
EVERY 50 HOURS 5-15
EVERY 250 HOURS 5-16
EVERY 500 HOURS 5-17
EVERY 1000 HOURS 5-22

MidWestTech | Case 750L Tier 3 Fire Dozer Operator's Manual | Publication 84511948 Order the manual at mid-west-tech.com >

EVERY 2000 HOURS 5-26

CHAPTER 6
MAINTENANCE AND ADJUSTMENTS
TABLE OF CONTENTS 6-1
TRACKS 6-3
ROLL-OVER PROTECTIVE STRUCTURE 6-6
MACHINE CLEANING 6-7
ADJUSTING THE RIPPER SHANKS 6-7
DOZER BLADE PITCH ADJUSTMENT 6-8
FIRE EXTINGUISHER MOUNTING (IF EQUIPPED) 6-9
FAN AND AIR CONDITIONING DRIVE BELT 6-9
MACHINE STORAGE 6-10

CHAPTER 7
ELECTRICAL
TABLE OF CONTENTS 7-1
ELECTRICAL SYSTEM 7-3
FUSES AND RELAYS 7-5

CHAPTER 8
SPECIFICATIONS
TABLE OF CONTENTS 8-1
SPECIFICATIONS 8-3
TRACK SYSTEM 8-4
TRANSPORT DIMENSIONS 8-5
OPERATING DATA AND DIMENSIONS 8-6
OPERATING DATA AND DIMENSIONS - RIPPER 8-8
WEIGHTS 8-8

CHAPTER 9
INDEX

MidWestTech | Case 750L Tier 3 Fire Dozer Operator's Manual | Publication 84511948 Order the manual at mid-west-tech.com >


Chapter 2
SAFETY AND DECALS

TABLE OF CONTENTS

SAFETY AND SAFETY DECALS 2-3
GENERAL AND SPECIFIC SAFETY INFORMATION 2-3
UTILITY SAFETY 2-4
OPERATOR PRECAUTIONS 2-5
Personnel Precautions 2-5
Operator - General 2-5
Proper Entry And Exit 2-5
Starting And Stopping Precautions 2-6
Operating Precautions 2-7
Maintenance Precautions 2-8
Fuel Handling Precautions 2-9
Burn Prevention 2-9
Hazardous Chemical Precautions 2-9
Transporting Precautions 2-10
Roll-over Protective Structure 2-10
Fire Extinguisher 2-10
Seat Belt Precautions 2-10
To Fasten The Seat Belt 2-10
To Unfasten The Seat Belt 2-10
Specific Precautions To This Machine 2-10
SAFETY DECALS 2-11
READ OPERATOR'S MANUAL 2-11
READ REPAIR MANUAL 2-11


MidWestTech | Case 750L Tier 3 Fire Dozer Operator's Manual | Publication 84511948 Order the manual at mid-west-tech.com >

DIRECTION CONTROL, HYDROSTATIC DRIVE CONTROL, HAND THROTTLE




BD06E060-01

Figure 46



BD06E061-01

Figure 47



BD02M166-01

Figure 48

1. DIRECTION CONTROL LEVER

This lever controls the forward speed, neutral or reverse speed, as well as turning.

To turn, push or pull the lever to the direction you want the crawler to go, in forward or reverse. The crawler will not move unless engine rpms are 1000 or higher.

This lever has detent positions in forward and reverse. The lever will stay in the forward or reverse position until the operator pulls it out. At start up the crawler must be in Neutral for several seconds before it will move.

The Direction Control Lever position will be displayed on the instrument gauge.

2. HYDROSTATIC DRIVE SPEED UP/DOWN BUTTONS

A. UP BUTTON (Drive speed increase)

B. DOWN BUTTON (Drive speed decrease)

These two buttons change the speed of the crawler from low to high. The maximum speed is selectable in a range of 10 increments. To increase track speed push the upper button. To decrease track speed push the lower button. The operator may choose to hold the appropriate button in the DOWN or UP position to allow the speed to increment. The speed range will be indicated by the needle on the Hydrostatic Drive Speed Gauge.

NOTE: *Top speed is limited to 90% from the factory.*

MidWestTech | Case 750L Tier 3 Fire Dozer Operator's Manual | Publication 84511948 Order the manual at mid-west-tech.com >

EVERY 500 HOURS

FUEL FILTER REPLACEMENT

Close the fuel shutoff valve (if equipped).



BD08A412 Figure 50

1. Clean the filter head and the outside of the fuel filter.
2. Turn the filter counterclockwise and remove from the filter head.
3. Apply a thin layer of clean oil to the gasket of the new filter.
4. Install the filter. Use your hands to tighten the filter 3/4 turn after the filter makes contact with the filter head.
5. Loosen the filter approximately one turn.
6. Tighten the filter until the filter is touching the filter head and then tighten 3/4 turn. Do not use a strap wrench.
7. Open the shutoff valve at the hand primer.
8. Remove the air from the fuel system. See removing air from the fuel system.

In Line Filter Replacement

Replace the in line filter after 500 hours of operation.



BD02M137 Figure 51

9. Make sure the filter is placed in line with the correct flow direction.

REMOVING AIR FROM THE FUEL SYSTEM

Air must be removed from the fuel system if one or more of the following conditions occurs:


A. If the engine stops because of no fuel in the tank.

B. If the fuel filters are replaced.

C. If the fuel system is serviced.

D. If the machine has been in storage.

1. If necessary, fill the fuel tank.
2. Make sure the fuel tank shutoff valve is in the ON position.
3. Loosen the air bleed screw (1) on the filter head 1 or 2 turns.




BD07G163-01 Figure 52

1. AIR BLEED FITTING
2. HAND PRIMER

4. Operate the hand primer (2) until fuel with no air bubbles flows from around the air bleed screw.
5. Tighten the air bleed screw.
6. Start the engine and check for fuel leaks.

MidWestTech | Case 750L Tier 3 Fire Dozer Operator's Manual | Publication 84511948 Order the manual at mid-west-tech.com >

TRANSPORT DIMENSIONS



BS02H072

Figure 1

TRANSPORT LENGTH AND WIDTH WITH BLADE FULLY ANGLED AT 25°

Blade width	(A) Transport width		(B) 750L w/o Drawbar	
2489 mm (98 in)	2489 mm	98 in	4171 mm	164.2 in
2642 mm (104 in)	2446 mm	96.3 in	4696 mm	184.9 in
2794 mm (110 in)	2585 mm	101.8 in	4728 mm	186.1 in
3048 mm (120 in)	2815 mm	110.8 in	4782 mm	188.3 in
3150 mm (124 in)	2907 mm	114.4 in	4803 mm	189.1 in
3302 mm (130 in)	3043 mm	119.8 in	4835 mm	190.4 in

NOTE: *Add 150 mm (5.9 in) for drawbar. If unit is equipped with ripper add 975 mm (38.4 in).*

NOTE: *The 98 inch blade is in a straight position when the machine is transported.*

MidWestTech | Case 750L Tier 3 Fire Dozer Operator's Manual | Publication 84511948 Order the manual at mid-west-tech.com >