1085C Excavator

Parts Catalog

8-5490

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

GENERAL INFORMATION

Indexes

Section 1 of this catalog contains a SN and P I N location guide, alphabetical index, pictorial index of the sections included, and pictorial index(es) for quick location of hoses and tubes (and other system components in some catalogs). An alphabetical index also appears at the beginning of each section. Section 10 is the Numerical Index which lists all part numbers in alpha/numeric order with their page location and reference number.

Illustration and Text

The arrangement of this parts catalog is for easy identification of parts. All parts are illustrated in "exploded views" in proper relation to each other. Reference numbers used in the illustrations refer to those on the text pages. The text pages list reference number, part number, part description and the quantity required.

Abbreviations

P I N "Product Identification Number"
SN "Serial Number"
NSS "Not Serviced Separately" in the part number column indicates this part is not available for service.
REF "Reference" in the part number column indicates this part has special service information. The page where this information can be found is given in the part description column.
UAR "Use As Required" in the quantity required column indicates the number of parts used is determined by service needs.

Right-Hand and Left-Hand Identification

The reference to right-hand and left-hand in this catalog is identified by the operator standing at the rear of the basic unit (without rear attachment), looking toward the front of the machine (in normal forward travel). For pages covering any machine attachments, right-hand and left-hand are defined by the operator sitting in the position for proper operation of the attachment.

Catalog Revisions and Supplements

Changes to the product may make it necessary to revise or add pages to this catalog. A cover sheet will list all pages released in a revision or supplement. Each new or revised page will have a new issue date. All revised and new pages must be put into the parts catalog as soon as they are received.

Parts Orders

Orders must specify product model, all necessary serial numbers, correct part number, complete description, quantity required, method of shipment, and shipping address.

Text Format Explanation

An assembly may contain many service items. The component parts of an assembly or subassembly are indented. The quantity required column lists the number of assemblies required for a complete machine, and the number of components required in a complete assembly or subassembly.

The example below illustrates the use of indents and other text page elements explained on this page.

REF	PART NO	DESCRIPTION	REQ'D
1	D43567	FILTER ASSEMBLY - hydraulic oil, PIN 7534840 and after	1
	D61903	HEAD ASSEMBLY - filter	1
2	NSS	HEAD - filter, order D61903 head assembly	1
3	D58199	VALVE - bypass	1
	D43800	KIT - filter element, replaces D35700 kit	1
4	NSS	ELEMENT - filter, order D43800 element kit	1
5	A27994	O-RING - filter	1
6	D61948	HOUSING - filter	1
7	REF	CANOPY - ROPS, machinery item, order from Machinery Price List	1
8	843065C1	HOSE - 132 inch (3353 mm) long, reservoir to pump	1
9	113-323	BOLT - hex head, 7/16 - 14 NC x 1-3/4 inch, plated	2
10	814-8030	BOLT - hex head, 8 mm - 1.25 x 30 mm (8.8), plated	4

MidWestTech | Case 1085C Excavator Parts Catalog | Publication 8-5490 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Accumulator
- Brake ... 7-19
- Steering ... 5-25

Air Cleaner Assembly ... 2-11
Air Cleaner Mounting ... 2-9
Air Intake Parts ... 2-9
Alternator Assembly ... 4-5
Alternator Mounting ... 4-7
Arm - excavating
- Extendahoe Arm ... 9-57
- Rigid Arm ... 9-55

Arm - material handling boom ... 9-63
Arm - outrigger
- Excavator Boom ... 9-27
- Material Handling Boom ... 9-29

Armrest - seat ... 9-49
Axle - front ... 6-29 - 6-39,7-3
Axle - rear drive ... 6-41 - 6-49,7-5,7-7
Axle Oscillation Lock ... 8-117

B

Backup Alarm ... 4-21
Batteries And Cables ... 4-11
Bearings - engine
- Camshaft ... 2-37
- Main ... 2-43
- Rod ... 2-47

Bearing - turntable ... 9-15
Belt - fan ... 2-17
Block - engine cylinder ... 2-39,2-41
Block Heater ... 2-41
Boom - excavating
- Extendahoe Arm ... 9-57
- Rigid Arm ... 9-55

Boom - material handling ... 9-63
Boom Lubrication Lines ... 9-61
Boom Support ... 9-31
Brake - swing ... 9-7
Brake Calipers ... 7-3,7-5
Buckets
- Backhoe ... 9-67
- 4-in-1 ... 9-69

C

Cab - material handling
- Assembly - basic cab ... 9-81,9-83
- Door ... 9-83
- Glass ... 9-87
- Harness - electrical ... 4-17
- Insulation ... 9-85
- Window Guards ... 9-81,9-83
- Windshield ... 9-87

C

Cab - material handling-Cont
- Windshield Wiper ... 4-49

Cab - standard
- Door ... 9-73,9-77
- Harness - electrical ... 4-17
- Insulation ... 9-71
- Mounting ... 9-47
- Overhead Guard ... 9-89
- Windows - Lexan ... 9-71
- Windshield and Guards ... 9-75
- Windshield Cables ... 9-77
- Windshield Washer ... 4-55
- Windshield Wiper ... 4-51

Cab Heater ... 4-37 - 4-45
Cab Riser ... 9-39
Cables - battery ... 4-11
Calipers - brake ... 7-3,7-5
Camshaft - engine ... 2-37
Clutches - transmission ... 6-25
Cold Weather Starting System ... 2-13
Column - steering ... 5-3
Connecting Rods - engine ... 2-47
Consoles
- Left-Hand Tilt ... 9-41
- Right-Hand Control ... 9-43
- Steering Column ... 5-5

Controls
- Accelerator Pedal and Linkage ... 3-5 - 3-9
- Brake Pedal ... 7-13
- Foot Pedal - equipment ... 9-3
- Left-Hand Console Tilt ... 9-45
- Swing Brake ... 9-5
- Throttle ... 3-15
- Transmission Shift ... 6-59

Converter - torque ... 6-3 - 6-7
Coolant Reservoir and Hoses - engine ... 2-7
Cooler - engine oil ... 2-29
Cooler - hydraulic oil ... 2-5,8-7
Covers
- Engine ... 9-33
- Steering Column ... 5-5
- Turntable Security ... 9-37
- Turntable Side and Front ... 9-35

Crankshaft - engine ... 2-43
Cylinder - accelerator
- Master ... 3-11
- Slave ... 3-13

Cylinder Block - engine ... 2-39,2-41
Cylinder Head - engine ... 2-35
Cylinders - hydraulic

MidWestTech | Case 1085C Excavator Parts Catalog | Publication 8-5490 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

C

Cylinders - hydraulic-Cont.
- Arm ... 8-85,8-87
- Boom ... 8-89
- Bucket - 4-in-1 ... 8-99
- Extendahoe ... 8-95
- Lockout - front axle oscillation ... 8-121
- Outrigger ... 8-97
- Steering ... 5-29
- Steering Cylinder Mounting ... 6-29
- Tool ... 8-91
- Wrist-O-Twist ... 8-93

D

Decals ... 9-91 - 9-103
Defroster Fan ... 4-47
Dipsticks
- Engine Oil ... 2-39
- Transmission Oil ... 6-23

Drive Shaft
- Torque Converter to Transmission ... 6-51
- Transmission to Axles ... 6-53,6-55

E

Electrical System
- Alternator ... 4-5
- Batteries and Cables ... 4-11
- Cold Start ... 2-13
- Harnesses
  - Backup Alarm ... 4-21
  - Cab ... 4-17
  - Cab Riser Extensions ... 4-19,4-35
  - Electrical Swivel ... 4-35
  - Engine ... 4-9
  - Instrument Panel ... 4-27
  - Lamps - work ... 4-29
  - Main Frame Lower - lamps ... 4-13
  - Outrigger ... 4-13
  - Relay Panel ... 4-15
  - Right Console - switches and fuses ... 4-25
  - Steering Console ... 4-23
  - Turn Signal ... 4-23
  - Turntable ... 4-19
- Starter Assembly ... 4-3
- Starter Mounting ... 4-7

Engine Components
- Block Heater ... 2-41
- Camshaft ... 2-37
- Connecting Rods ... 2-47
- Crankshaft ... 2-43
- Cylinder Block ... 2-39,2-41
- Cylinder Head ... 2-35

E

Engine Components-Cont.
- Cylinder Head Cover ... 2-33
- Flywheel and Housing ... 2-45
- Front Gear Cover ... 2-21
- Fuel Filter ... 3-19
- Fuel Injection Nozzle ... 3-23
- Fuel Injection Pump and Drive ... 3-21
- Fuel Injection System ... 3-17
- Fuel Lift Pump ... 3-19
- Gasket Kits ... 2-49
- Manifolds - intake and exhaust ... 2-23
- Oil Filter and Cooler ... 2-29
- Oil Pan ... 2-31
- Oil Pump ... 2-31
- Pistons ... 2-47
- Thermostat and Housing ... 2-33
- Turbocharger ... 2-25,2-27
- Valve Mechanism ... 2-35
- Water Pump System ... 2-19

Engine Covers ... 9-33
Engine Mounting ... 2-17
Exhaust System and Muffler ... 2-15
Extendahoe ... 9-57,9-59

F

Fan - defroster ... 4-47
Fan - engine cooling ... 2-17
Fan Belt ... 2-17
Fenders ... 9-25
Filters
- Air Cleaner - engine ... 2-11
- Engine Oil ... 2-29
- Fuel ... 3-19
- Hydraulic Oil ... 8-5
- Hydraulic Oil Strainer - in-tank ... 8-3
- Transmission ... 6-13

Floor Plate ... 9-47
Floormat ... 9-47
Flywheel and Housing - engine ... 2-45
Fuel Filter ... 3-19
Fuel Gauge ... 3-3
Fuel Injection Nozzle ... 3-23
Fuel Injection Pump and Drive ... 3-21
Fuel Injection System ... 3-17
Fuel Lift Pump ... 3-19
Fuel Tank and Lines to Engine ... 3-3
Fuses - electrical panel ... 4-25

G

Gasket Kits - engine ... 2-49
Gauges

MidWestTech | Case 1085C Excavator Parts Catalog | Publication 8-5490 Order the manual at mid-west-tech.com >