580K Construction King Loader Backhoe P.I.N. JJG0020000 & After

Parts Catalog

Bur. 8-5581

CASE

MidWestTech | Case 580K Construction King Loader Backhoe Parts Catalog | Publication 8-5581

Order the manual at mid-west-tech.com >

PICTORIAL SECTION INDEX



GENERAL 1



ENGINE 2



FUEL 3



ELECTRICAL 4



TRACK/
STEER. 5



POWER TRAIN 6



BRAKES 7



HYDRAULICS 8

CHASSIS/
MTD. EQUIP. 9



NUMERICAL
INDEX 10

B890932A

Bur 8-5581 Issued September, 1990 Printed in U S A

MidWestTech | Case 580K Construction King Loader Backhoe Parts Catalog | Publication 8... Order the manual at mid-west-tech.com >

GENERAL INFORMATION

Indexes

Section 1 of this catalog contains a SN and P I N location guide, alphabetical index, pictorial index of the sections included, and pictorial index(es) for quick location of hoses and tubes (and other system components in some catalogs) An alphabetical index also appears at the beginning of each section Section 10 is the Numerical Index which lists all part numbers in alpha/numeric order with their page location and reference number

Illustration and Text

The arrangement of this parts catalog is for easy identification of parts All parts are illustrated in "exploded views" in proper relation to each other Reference numbers used in the illustrations refer to those on the text pages The text pages list reference number, part number, part description and the quantity required

Abbreviations

P I N "Product Identification Number"
SN "Serial Number"
NSS "Not Serviced Separately" in the part number column indicates this part is not available for service
REF "Reference" in the part number column indicates this part has special service information The page where this information can be found is given in the part description column
UAR "Use As Required" in the quantity required column indicates the number of parts used is determined by service needs

Right-Hand and Left-Hand Identification

The reference to right-hand and left-hand in this catalog is identified by the operator standing at the rear of the basic unit (without rear attachment), looking toward the front of the machine (in normal forward travel) For pages covering any machine attachments, right-hand and left-hand are defined by the operator sitting in the position for proper operation of the attachment

Catalog Revisions and Supplements

Changes to the product may make it necessary to revise or add pages to this catalog A cover sheet will list all pages released in a revision or supplement Each new or revised page will have a new issue date All revised and new pages must be put into the parts catalog as soon as they are received

Parts Orders

Orders must specify product model, all necessary serial numbers, correct part number, complete description, quantity required, method of shipment, and shipping address

Text Format Explanation

An assembly may contain many service items The component parts of an assembly or subassembly are indented The quantity required column lists the number of assemblies required for a complete machine, and the number of components required in a complete assembly or subassembly

The example below illustrates the use of indents and other text page elements explained on this page

REF	PART NO	DESCRIPTION	REQ'D
1	D43567	FILTER ASSEMBLY - hydraulic oil, PIN 7534840 and after	1
	D61903	HEAD ASSEMBLY - filter	1
2	NSS	HEAD - filter, order D61903 head assembly	1
3	D58199	VALVE - bypass	1
	D43800	KIT - filter element, replaces D35700 kit	1
4	NSS	ELEMENT - filter, order D43800 element kit	1
5	A27994	O-RING - filter	1
6	D61948	HOUSING - filter	1
7	REF	CANOPY - ROPS, machinery item, order from Machinery Price List	1
8	843065C1	HOSE - 132 inch (3353 mm) long, reservoir to pump	1
9	113-323	BOLT - hex head, 7/16 - 14 NC x 1-3/4 inch, plated	2
10	814-8030	BOLT - hex head, 8 mm - 1 25 x 30 mm (8 8), plated	4

MidWestTech | Case 580K Construction King Loader Backhoe Parts Catalog | Publication 8... Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Air Cleaner . . . . 2-5 - 2-9
Air Conditioner
  Blower 9-165
  Compressor 4-13
  Compressor Mounting . . . 4-17
  Condenser . . . 9-173
  Controls . . . 9-155
  Evaporator Core . . . 9-171
  Filter - air 9-163
  Receiver-Drier . . . 9-173
Alarm - warning . . . 4-57
Alarm - backup 4-53,4-55
Alternator - electrical . . 4-7 - 4-11
Alternator Mounting . . . 4-15
Antirollback - loader 9-7
Armrests - seat . . . 9-139
Axle
  Front - four wheel drive
    D139510 Axle . . . . 6-41 - 6-53
    D149174 Axle . . . . 6-53B - 6-53N
    D146847 Axle . . . 6-53P - 6-53BB
  Front - two wheel drive . . 5-23
  Rear 6-67
Axle Mounting - front four wheel drive 6-37,6-37B

B

Backhoe
  Boom 9-49
  Boom Latch 9-53
  Boom Lock 8-77
  Bucket Links - attachments . . 9-57
  Buckets . . . . 9-63 - 9-83
  Controls (See Controls)
  Control Tower 9-19,9-21
  Coupler - bucket 9-55,9-59
  Dipper 9-55
  Extendable Dipper 9-59
  Frame and Mounting Parts . . 9-41,9-43
  Frost Point 9-57
  Hydraulics (See Hydraulic Systems)
  Stabilizers 9-41
  Swing Tower 9-45
Backup Alarm 4-53,4-55
Battery 4-23,4-25
Beacon - rotating 4-61,4-63
Bearings - front wheel 5-25
Belts - fan, alternator, and
  compressor 2-3,4-15,4-17
Belts - seat 9-121
Block - cylinder . . . . 2-41 - 2-47

B

Blower - air conditioner . . . 9-165
Boom Latch 9-53
Box - battery 4-23
Box - operators tool . . . 9-181
Brake - differential, transaxle . . . 7-3
Brake - parking . . . 7-13
Brake - parking, transaxle 7-5
Brake - PTO . . . 6-77,6-79
Brake Master Cylinder . . . 7-11
Brake Pedals . . . 7-7
Buckets - backhoe . . . . 9-63 - 9-83
Buckets - loader . . . 9-15,9-17

C

Cab
  Air Conditioner . . . 9-171 - 9-175
  Air Filter 9-163
  Blower 9-165
  Consoles - control 9-145
  Covers - interior 9-143
  Doors and Windows/
    Glass . . . . 9-141,9-147 - 9-153
  Electrical and
    Lighting 4-41,4-45,4-49,9-155,9-161
  Frame and Roof Cap . . . 9-143
  Headliner, Louvers, and Dome Lamps . . . 9-161
  Heater 9-167,9-169
  Mounting Parts 9-141
  Panel - cab control . . . 9-155
  Windshield Wipers . . . 9-157,9-159
Cables - battery 4-25
Camshaft - engine 2-39
Canopy - ROPS 9-177
Chassis - tractor 9-99
Cluster - electronic instrument . . . 4-31
Cluster - instrument . . . 4-37
Clutch - power shuttle . . . 6-17,6-19
Clutch - PTO 6-77,6-79
Clutch Cutout 4-29
Cold Start System 2-13,4-25
Column - steering . . . 5-3 - 5-7, 5-13, 5-15
Compressor - air conditioner . . . 4-13
Compressor Mounting 4-17
Concrete Breaker Fork 9-85
Control Center - instrument, electronic . . . 4-31
Controls
  Antirollback - loader 9-7
  Backhoe . . . . 9-23 - 9-37
  Brake 7-7,7-13
  Boom Latch 9-53
  Clutch Cutout 4-29
  Engine Speed - throttle . . . . 3-5 - 3-9

MidWestTech | Case 580K Construction King Loader Backhoe Parts Catalog | Publication 8... Order the manual at mid-west-tech.com >